







### Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola TM Series 66 wireless phone.






MOTOROLA, the Stylised M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. TrueSync, Sidekick, Starfish and the Stylised Starfish Logo are registered trademarks of Starfish Software, Inc., a wholly owned independent subsidiary of Motorola, Inc. All other product or service names are the property of their respective owners.


© 2001 Motorola, Inc. All rights reserved. Printed in the EEC.

#### **Software Copyright Notice**

The Motorola products described in this manual may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any licence under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free licence to use that arises by operation of law in the sale of a product.

















# Contents


Menu Map	. 3
Contents	. 5
About This Guide	. 9
Safety and General Information	10
Total Customer Satisfaction	18
Warranty Information	19
Getting Started	24
Installing the SIM Card	24
Installing the Battery	26
Charging the Battery	27
Turning Your Phone On	27
Ending a Call	23
Receiving a Call	30
Displaying Your Phone Number	30
About Your Phone	
Display	31
Changing the Zoom Setting	33
Status Light	34
Volume Keys	35
Smart Key ´	32
Battery Use	36
Making and Receiving Calls	
Redialling a Number	38
Redialling a Number	38
Caller ID	39
Caller ID	39
Dialling an Emergency Number	40
Entering Numbers in the Notepad	40
Muting the Ring or Vibrate Alert	


























### **About This Guide**



#### **Using Your Phone's Features**

This user guide introduces you to the many features in your Motorola phone.

### Navigating To a Menu Feature

You can access many of your phone's features through the menu system. This guide shows you how to navigate to a specific menu feature as follows:



> Recent Calls
> Dialled Calls



The > symbol means that you should scroll to and select the feature. This example shows that you must press ♠, scroll to and select Recent Calls, then scroll to and select Dialled Calls to view the dialled calls list.



#### **Optional Features**



Features marked with this label are optional network, SIM card, and/or subscription-dependent features. These features may not be offered by all service providers in all geographical areas. Contact your service provider for information about availability.

### **Optional Accessories**




Features marked with this label require the use of an optional Motorola Original  $^{\text{TM}}$  accessory.




















### Safety and General Information



READ THIS INFORMATION BEFORE USING YOUR PERSONAL COMMUNICATOR.

The information provided in this document supersedes the general safety information contained in user guides published prior to this date. For information regarding radio use in a hazardous atmosphere please refer to the Factory Mutual (FM) Approval Manual Supplement or Instruction Card, which is included with radio models that offer this capability.



#### RF Operational Characteristics

Your Personal Communicator contains a transmitter and a receiver. When it is ON, it receives and transmits radio frequency (RF) energy. The Personal Communicator operates in the frequency range of 900 MHz to 1990 MHz and employs digital modulation techniques.

When you communicate with your Personal Communicator, the system handling your call controls the power level at which your personal communicator transmits. The output power level typically may vary over a range from 0.063 watts to 1.58 watts.

### Exposure To Radio Frequency Energy

Your Motorola Personal Communicator is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy:




10

















### Safety and General Information






- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86,
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- National Radiological Protection Board of the United Kingdom 1995
- Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation - Human Exposure) Standard 1999 (applicable to wireless phones


To assure optimal performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures:



















### Safety and General Information



#### Antenna Care

**Use only the supplied or an approved replacement antenna.** Unauthorized antennas, modifications, or attachments could damage the Personal Communicator and may violate FCC and/or other applicable regulations.

**DO NOT hold the antenna when the Personal Communicator is "IN USE".** Holding the antenna affects call quality and may cause the Personal Communicator to operate at a higher power level than needed.

### **Phone Operation**

The Personal Communicator is designed to be used with a headset for talking and listening. The Personal Communicator can also be placed inside the holster, then the holster can be clipped onto your belt, pocket, purse, or other apparel and used with the headset.

#### **Body-worn Operation**

To maintain compliance with FCC RF exposure guidelines, if you wear the Personal Communicator on your body when transmitting, always place the Personal Communicator in a **Motorola supplied or approved clip, holder, holster, case, or body harness.** Use of non-Motorola-approved accessories may exceed FCC RF exposure guidelines. **If you do not use a body-worn accessory, ensure the antenna is at least one inch (2.5 cm) from your body when transmitting.** 
























### Safety and General Information :







For a list of approved Motorola accessories, look in the accessory section of this manual.

### Electromagnetic Interference/ Compatibility

Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed or otherwise configured for electromagnetic compatibility.

#### **Facilities**



To avoid electromagnetic interference and/or compatibility conflicts, turn off your Personal Communicator in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.



#### Aircraft

When instructed to do so, turn off your Personal Communicator when on board an aircraft. Any use of a Personal Communicator must be in accordance with applicable regulations per airline crew instructions.

#### **Medical Devices**

#### **Pacemakers**

The Health Industry Manufacturers Association recommends that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of, Wireless Technology Research.













new v66 uk sapphire.book Page 14 Monday, February 4, 2002 4:21 PM





### Safety and General Information

Persons with pacemakers should:

- ALWAYS keep the Personal Communicator more than six inches (15 centimeters) from their pacemaker when the Personal Communicator is turned ON.
- not carry the Personal Communicator in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn the Personal Communicator OFF immediately if you have any reason to suspect that interference is taking place.

#### **Hearing Aids**

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.



If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

### Safety and General

#### Use in Vehicles

Check the laws and regulations on the use of phones in your vehicle. You are advised to always obey them.

When using your Personal Communicator in a vehicle, please:

- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call.























Safety and General Information

### **Operational Warnings**

#### For Vehicles with an Air Bag

Do not place the Personal Communicator in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If the Personal Communicator is placed in the air bag deployment area and the air bag inflates, the Personal Communicator may be propelled with great force and cause serious injury to occupants of the vehicle.


#### Potentially Explosive Atmospheres

Turn off your Personal Communicator prior to entering any area with a potentially explosive atmosphere, unless it is especially qualified for use in such areas as "Intrinsically Safe" (for example, Factory Mutual, CSA, or UL Approved). Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

#### Blasting Caps and Areas

To avoid possible interference with blasting operations, turn off your Personal Communicator when you are near electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio". Obey all signs and instructions.




















### Safety and General Information



### **Operational Cautions**

#### **Antennas**


Do not use the Personal Communicator if it has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

#### **Batteries**


All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.



















### Safety and General Information &











Hereby, Motorola declares that this product is in compliance


- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives

IMEI: 350034/40/394721/9 Product Approval Type: MC2-41H14 Number

















At Motorola, Total Customer Satisfaction is a top priority. If you have a question, a suggestion or a concern about your Motorola Cellular Phone, Motorola wants to hear from you.

For e-mail queries contact: mcrc@ei.css.mot.com












### **Warranty Information**



You must inform Motorola of the lack of conformity to the applicable specifications of any of the Products within a period of two (2) months from the date on which you detect a defect in material, workmanship or lack of conformity and in any event within a term not to exceed the Warranty Term, by submitting the Product for service to Motorola. Motorola shall not be bound by Product related statements not directly made by Motorola.

 $\ensuremath{\mathsf{A}}$  list of the Motorola Call Centre numbers is enclosed with this Product.

During the Warranty term, Motorola will, at its discretion and without extra charge, as your exclusive remedy, repair or replace your Product which does not comply with this warranty; or failing this, to reimburse the price of the Product but reduced to take into account the use you have had of the Product since it was delivered. This warranty will expire at the end of the Warranty Term

This is the complete and exclusive warranty for a Motorola Personal Communicator and accessories and in lieu of all other warranties, terms and conditions, whether express or implied.


Where you purchase the product other than as a consumer, Motorola disclaims all other warranties, terms and conditions express or implied, such as fitness for purpose and satisfactory quality.













In no event shall Motorola be liable for damages nor loss of data in excess of the purchase price nor for any incidental special or consequential damages\* arising out of the use or inability to use the Product, to the full extent such may be disclaimed by law.

This Warranty does not affect any statutory rights that you may have if you are a consumer, such as a warranty of satisfactory quality and fit for the purpose for which products of the same type are normally used under normal use and service, nor any rights against the seller of the Products arising from your purchase and sales contract.

(\*)including without limitation loss of use, loss of time, loss of data, inconvenience, commercial loss, lost profits or savings.

#### How to get Warranty Service

In most cases the authorized Motorola dealer which sold and/or installed your Motorola Personal Communicator and original accessories will honor a warranty claim and/or provide warranty service. Alternatively, for further information on how to get warranty service please contact either the customer service department of your service provider or Motorola's call centre at the telephone numbers below for your country.

In order to claim the warranty service you must return the Personal Communicator and/or accessories in question to Motorola. Please avoid leaving any supplementary items like SIM cards. The Product should also be accompanied by a label with your name, address, and telephone number; name of operator and a description of the problem. In the case of vehicular installation, the vehicle in which the Personal Communicator is installed should be driven to the Authorized Repair Centre, as analysis of any problem may require inspection of the entire vehicular installation.

In order to be eligible to receive warranty service, you must present your receipt of purchase or a comparable substitute

20



new v66 uk sapphire.book Page 21 Monday, February 4, 2002 4:21 PM





### **Warranty Information**

proof of purchase bearing the date of purchase. The phone should also clearly display the original compatible electronic serial number (IMEI) and mechanic serial number [MSN]. Such information is contained with the Product.

#### **Conditions**

This warranty will not apply if the type or serial numbers on the Product has been altered, deleted, duplicated, removed, or made illegible. Motorola reserves the right to refuse free-of-charge warranty service if the requested documentation cannot be presented or if the information is incomplete, illegible or incompatible with the factory records.

Repair, at Motorola's option, may include reflashing of software. the replacement of parts or boards with functionally equivalent, reconditioned or new parts or boards. Replaced parts, accessories, batteries, or boards are warranted for the balance of the original warranty time period. The Warranty Term will not be extended. All original accessories, batteries, parts, and Personal Communicator equipment that have been replaced shall become the property of Motorola. Motorola does not warrant the installation, maintenance or service of the products, accessories, batteries or parts.

Motorola will not be responsible in any way for problems or damage caused by any ancillary equipment not furnished by Motorola which is attached to or used in connection with the Products, or for operation of Motorola equipment with any ancillary equipment and all such equipment is expressly excluded from this warranty.

When the Product is used in conjunction with ancillary or peripheral equipment not supplied by Motorola, Motorola does not warrant the operation of the Product/peripheral combination and Motorola will not honor any warranty claim where the Product is used in such a combination and it is determined by




















## **Warranty Information**



#### What Is Not Covered By The Warranty

This warranty is not valid if the defects are due to damage, misuse, tampering, neglect or lack of care and in case of alterations or repair carried out by unauthorized persons.

- 1. Defects or damage resulting from use of the Product in other than its normal and customary manner.
- 2. Defects or damage from misuse, access to incompatible sources, accident or neglect.
- Defects or damage from improper testing, operation, maintenance, installation, adjustment, unauthorized software applications or any alteration or modification of any kind
- 4. Breakage or damage to antennas unless caused directly by defects in material or workmanship.
- 5. Products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.
- Defects or damage due to range, coverage, availability, grade of service, or operation of the cellular system by the cellular operator.
- 7. Defects or damage due to moist, liquid or spills of food.



22













new v66 uk sapphire.book Page 23 Monday, February 4, 2002 4:21 PM





### **Warranty Information**


- 8. Control unit coil cords in the Product that are stretched or have the modular tab broken.
- 9. All plastic surfaces and all other externally exposed parts that are scratched or damaged due to customer normal use.
- 10. Leather cases (which are covered under separate manufacturer's warranties).
- 11. Products rented on a temporary basis.
- 12. Periodic maintenance and repair or replacement of parts due to normal wear and tear.

**Note:** The talk-time, standby time and total life cycle of a Motorola rechargeable battery for your Personal Communicator will depend on usage conditions and network configurations. As a consumable product, the specifications indicate that you should be able to obtain optimum performance for your Motorola Personal Communicator within the first six months from date of purchase and up to (200) charges.


The warranty for Motorola rechargeable batteries becomes void if (i) the batteries are charged other than by Motorola approved battery chargers specified for the charging of the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, (iii) the battery is used in equipment or service other than the cellular telephone equipment for which it is specified.
























#### What's in the Box?

Your digital wireless phone typically comes equipped with a battery and a charger. Other accessory options can customise your phone for maximum performance and portability.

#### Installing the SIM Card

Your SIM (Subscriber Identity Module) card contains your phone number, service details, and phonebook/message memory. It is stored in a compartment on the flip of your phone.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.

#### Do This

1 Pull up at the base of the SIM card cover plate and lift the cover plate off the phone.

















#### Do This

Slide the SIM card door down (toward the base of the phone) and lift open.



Insert the SIM card into the SIM card door with the notch in the upper left corner and the gold plate facing down.





Close the SIM card door and slide it up to lock the SIM card in place.



Replace the SIM card cover plate, then push down and snap it into place.












25















### Installing the Battery


Before you can use your phone, you need to install and charge the battery.



Your phone is designed to be used only with Motorola Original batteries and accessories. We recommend that you store batteries in their protective cases when not in use.

#### Do This

Remove the battery from its protective clear plastic case.






Push the battery down and snap it into place.























#### **Charging the Battery**


Before you can use your phone, you need to install and charge the battery.


#### Do This

1 Plug the travel charger into your phone with the release tab facing up.










### **Turning Your Phone On**

Do	This	То	
1	Open your phone	expose the keypad	





new v66 uk sapphire.book Page 28 Monday, February 4, 2002 4:21 PM





### **Getting Started**

#### Do This

2 Press and hold **◎** (the power key)



turn on your phone



3 If necessary, enter your SIM card PIN code and press OK (●)

unlock your SIM card


Caution: If you enter an incorrect PIN code three times in a row, your SIM card is disabled and your phone displays the message SIM Blocked. (For more information, see "Protecting the SIM Card" on page 160.)

4 If necessary, enter your four-digit unlock code and press OK (●)

unlock your phone

The unlock code is originally set to 1234. (For more information, see "Locking and Unlocking Your Phone" on page 158.)






















# -(

### Making a Call

To call a number, your phone must be turned on, have a SIM card inserted, be unlocked, and have a network connection with adequate signal strength.

Pre 1	ess keypad keys	<b>To</b> dial the phone number (up to 32 digits)
		<b>Tip:</b> If you make a mistake, press <b>DELETE</b> (♠) to delete the last digit, or press and hold <b>DELETE</b> (♠) to clear all digits.
2	(send key)	make the call


**Note:** You can make an emergency call even when the phone is locked, or when a SIM card is not inserted. See "Dialling an Emergency Number" on page 40.

### **Ending a Call**

Press	То
(end key)	end the call











### Receiving a Call

To receive a call, your phone must be turned on, have a SIM card inserted, and have a network connection with adequate signal strength. If your phone is locked, you must unlock the phone to answer the call.

**Note:** Your phone cannot receive calls when your SIM card is locked.

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press To

**②** or **ANSWER** (**③**) answer the call



### **Displaying Your Phone Number**

From the idle display:

Press To


see your phone number

**Note:** Your phone number must be programmed on your SIM card in order to use this feature.















### **About Your Phone**





See page 1 for a diagram of your phone that describes basic phone components.

#### Display

The top section of the display shows phone status indicators. The following illustration shows some of the common indicators that you may see at the top of the display when using your phone.


Messages, phone numbers, and menu options appear in the middle of the display. Text labels at the bottom corners of the display show the current soft key functions. A 

(menu) indicator in the bottom centre of the display indicates that you can open the main menu or a feature sub-menu to see more options. For more information about the soft key and menu key labels, see "Using the Menu" on page 51.


Some of the phone functions described in this guide must be performed from the idle display. The term *idle display* refers to the standard display that you see when your phone is on and ready to use, when you are not on a call or using the menu systém.





















#### **About Your Phone**




**O Paul Signal Strength Indicator** Shows the strength of your phone's connection with the network.

Strong

 $\mathcal{D}_{\mathrm{ad}}$  $i^{2}\mathrm{ad}$ 

No signal



**2** In Use Indicator Appears when a call is in progress.



**❸ ▲ Roam Indicator** Appears when your phone uses another network system outside your home network. When you leave your home network area, your phone *roams* or seeks another network.




**4** ■ Message Waiting Indicator Appears when your phone receives a text message.




**⊙** ⊠ Voice Message Waiting Indicator Appears when you receive a voicemail message.












more information, while two lines increase text size.





To change the display view, press **⊕** once, then press and hold **⊕** again within two seconds of the first press.

**About Your Phone** 

You can also adjust the zoom setting from the menu. See the "Zoom" item on page 75.

#### Status Light

The status light tells you when you have an incoming call or message, or when your phone is roaming (using a non-home system). The light changes colour to indicate different states:



Indication	State
alternating red/green	incoming call
flashing green	in service, home system
flashing yellow	roaming, non-home system
flashing red	no service
alternating yellow/green	text or voicemail message received

**Note:** You can turn off the status light indicator to increase your phone's standby time (the length of time that your phone's battery retains power when the phone is turned on but is not in use). See the "Status Light" item on page 75 to turn off the status light.









# Volume Keys



Use the upper and lower volume keys to adjust your phone's earpiece and ringer volume, and to mute the incoming call alert.



When	Press	То
you are in a call	volume keys	increase or decrease earpiece speaker volume
the idle display is showing	volume keys	increase or decrease ringer volume
the incoming call alert is ringing or vibrating	volume keys	turn off the ring or vibrate alert

**About Your Phone** 

You can also use the volume keys to scroll up or down through

To change keypad volume, see "Customise an Alert Profile" on page 138.

### Smart Key

The smart key gives you another way to perform many basic phone functions. It's called the smart key because it anticipates the next action you are likely to perform.





new v66 uk sapphire.book Page 36 Monday, February 4, 2002 4:21 PM





#### **About Your Phone**

For example, if you highlight an item and press the smart key, the smart key selects the highlighted item. You can use the smart key to make and end calls, select menu items, toggle features on and off, and open your phonebook. The smart key usually performs the same function as the right soft key (•).

**Note:** The smart key provides an optional way to do some things faster. It is never the only way to perform a task.

### 4-Way Navigation Keys

The 4-way navigation keys let you move through the menu. Simply press the appropriate



directional navigation key to select features and adjust feature settings.


**Tip:** Down and up are your primary movements within menus. Right and left are available for shortcuts (advancing through choices), datebook, adjusting settings (such as contrast or key volume), and when entering or editing text.

#### **Battery Use**

**Caution:** To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximise your battery's performance:

 Always use Motorola Original™ batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.


















### **About Your Phone**






- New batteries or batteries that have been stored for long periods of time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.
- The more you talk on the phone or use phone features (like sending text messages), the less standby time your battery has. You can also extend battery life by turning off the status light. (See the "Status Light" item on page 75.)




The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling centre for proper disposal

methods. Never dispose of batteries in a fire because they may explode.
























This chapter describes features that help you make and receive calls with your phone. For information about other call-related phone functions, see "Recent Calls" on page 78 and "Data and Fax Calls" on page 151.

### Redialling a Number

You can redial a previously dialled phone number, whether the call was connected or busy. From the idle display:



Press		То
1	8	go directly to the dialled calls list
2	Ç	scroll to the entry you want to call
3	8	redial the highlighted number

### **Using Automatic Redial**

If you receive a busy signal, your phone displays the message Call Failed.

When automatic redial is turned on, your phone automatically makes a number of redial attempts until the call goes through. When the call goes through, your phone rings or vibrates one time, displays the message <code>Redial Successful</code>, and then connects the call.

You must turn on automatic redial to use this feature. See the "Auto Redial" item on page 75 to turn on automatic redial.















new v66 uk sapphire.book Page 39 Monday, February 4, 2002 4:21 PM





# Making and Receiving Calls





When automatic redial is turned off, you can manually activate the feature to redial a phone number. When you hear a busy signal and see the  ${\tt Call}$  Failed message:

### **Press**





or RETRY (O)

activate automatic redial

### Caller ID



The *calling line identification* (caller ID) feature lets you see who is calling before you answer.



- If the caller's name is stored in your phonebook, the phone automatically displays the name. Otherwise, the phone displays the caller's phone number.
- If caller ID information is not available, your phone displays the message Incoming Call.



# Returning an Unanswered Call


Your phone keeps a record of your unanswered calls. When you cannot answer a call, your phone displays:

- the (missed call) indicator
- the message X Missed Calls, where X is the total number of missed calls

### **Press**

1 VIEW (•)


see the received calls list, with the most recent call at the top











Press	То
2 💸	scroll through the list and select a call that you want to return
3 6	make the call

### **Dialling an Emergency Number**

Your service provider programs one or more emergency phone numbers (such as 999) that you can call under any circumstances. Provided that your phone has found a network, you will be able to make an emergency call. The call can be made regardless of any security codes and, depending on the network, with or without a SIM card inserted.

**Note:** Emergency numbers vary by country. Your phone's emergency number(s) may not work in all locations.

To call the emergency number at any time:

Press		То
1	keypad keys	dial the emergency number (such as 999)
2	8	call the emergency number

### **Entering Numbers in the Notepad**

Your phone stores the most recent string of digits entered on the keypad in a temporary memory location called the *notepad*. These digits can be the last phone number that you called, or a phone number that you simply entered but did not call. These digits remain in the notepad even when you turn off the phone.





new v66 uk sapphire.book Page 41 Monday, February 4, 2002 4:21 PM





# Making and Receiving Calls





You can use the notepad to store a phone number that you intend to call later (such as a phone number told to you by the other party during a call). To retrieve these digits, see "Using the Notepad" on page 81.

### Muting the Ring or Vibrate Alert

You can mute your phone's incoming call alert before answering the call.

While the phone is ringing or vibrating:

Press	То
either volume key	turn off the ring or vibration alert



To specify a ring or vibration type, see "Ring/Vibrate" on page



# **Terminating an Incoming Call**

While the phone is ringing or vibrating:

Press	То
or IGNORE (•)	cancel the incoming call



Depending on your phone settings and the type of subscription you have with your service provider, the call may be diverted to another number, or the calling party may hear a busy signal.











The *speed dial* feature lets you dial any phonebook entry with a minimal number of keypresses.

Whenever you store an entry in your phonebook, the entry is assigned a unique speed dial number. If you know the speed dial number for the phonebook entry you want to call, you can use the speed dial feature.

Press		То
1	keypad keys	enter the one-, two-, or three-digit speed dial number for the entry you want to dial
2	#	submit the number
3	0	call the entry

To make an entry in the phonebook or view an existing entry's speed dial number, see "Storing a Phonebook Entry" on page 87.

# **Dialling With 1-Touch Dial**

You can call phonebook entries 1 to 9 with the push of a single key. Just press and hold the one-digit speed dial number for one second.

To store entries in locations 1 to 9 in the phonebook, see "Storing a Phonebook Entry" on page 87.

Note: You must specify which phone number list you want to use with this feature: phone memory phonebook, or SIM card phonebook. See "1-Touch Dial Preference" on page 98.
























Dialling a Number In a Text Message



**Find the Feature** 


If you receive a text message with an embedded phone number, you can dial the number directly.

**Note:** You must set up the text message inbox before you can receive text messages. See "Setting Up the Text Message Inbox" on page 110.

**●** > Messages > Text Msgs

Pr	ess	То
1	Ç	scroll to the message with the number
2	•	open the Text Msg Menu
3	Ç	scroll to Call Back
4	SELECT (O)	dial the number in the message

If the message contains more than one phone number, press to scroll to a number and then press **SELECT** (•) to dial.













# **Additional Dialling Features**

In addition to pressing numbers on your keypad, you can insert numbers or characters and make calls in a variety of ways.

To dial the local international access code:

Do This	То
Press 🕩 for two seconds	insert the international access code for the country from which you are calling

While dialling (with digits visible in the display):



Do This	То
Press ⊕ > Attach Number	attach a number from the phonebook or recent calls list to the end of the digits you entered
Press ● > Hide ID/Show ID	Hide (or show) your caller ID for the next call.
Press ● > Send Message	create a text message addressed to the number entered
Press ● > Talk Then Fax	talk and then send a fax to the same phone number within the same call














# new v66 uk sapphire.book Page 45 Monday, February 4, 2002 4:21 PM Making and Receiving Calls





Do This	То
Press ● and then scroll to and select one of the following:	insert a special character when making a call that requires you to dial and send additional digits (for example, to make a calling card call, or to retrieve messages from an answering machine):
• Insert Pause (to insert a p)	<ul> <li>Pause tells your phone to wait until the call connects before it automatically sends the next digit(s) in a series.</li> </ul>
• Insert Wait (to insert a w)	• <b>Wait</b> tells your phone to wait until the call connects, and then to prompt you for confirmation before it sends the next digit(s).
• Insert 'n' (to insert an n)	• 'n' tells your phone to prompt you for a number before dialling the call. The number you enter is inserted into the dialling sequence in place of the n character.















You can also call numbers using these features:

Do This	To Call
Press and release the voice key on the right side of your phone and say the entry's name (in two seconds).  Voice key	a phone number using the voice dial feature See "Recording a Voice Name For a Phonebook Entry" on page 89.
Press ● > Service Dia1 > entry to call	a service dial number programmed on the SIM card
Press ● > Fixed Dial > entry to call	a fixed dial number
Press ● > Recent Calls	a missed call or a number from a call you recently dialled or received







new v66 uk sapphire.book Page 47 Monday, February 4, 2002 4:21 PM





# Using Features While On a Call





# **Using Call Waiting**




If you subscribe to call waiting, an alert tone sounds while you are on a call to indicate that you have received a second call.

To put the first call on hold and answer the second call:

Press		<b>To</b> answer the new call
2	SWITCH (•)	switch back to the first call  Note: You can press SWITCH (●) at any time to switch between calls.
	or LINK (•)	connect the two calls

To end the first call and answer the second call:

end the current call  Your phone rings to sig	nal the new
call.  2 answer the new call	













# Using Features While On a Call




You must activate call waiting in order to use the feature. See the "Call Waiting" item on page 73 to activate call waiting.


# Making a Conference Call



To talk to more than one person on a call, you can make a conference call. Call the first person, call the second person, then link the two calls.

Press		То	
1	keypad keys	dial the first person's number	
2	8	call the number	
3	HOLD (•)	put the first call on hold	
	(if available)	Your phone displays a ∺ (flashing	
	or	phone) indicator next to the call on hold.	
	<b>●</b> > Hold	noid.	
4	keypad keys	dial the next person's number	
5	8	call the number	
	·	Your phone displays an [ (active call) indicator next to the new active call.	
6	LINK (•)	connect the two calls	
7	8	end the entire call	













# Using Features While On a Call




# Transferring a Call

While you are on a call, you can transfer the call to another phone by first talking to the person who answers the other phone, or by directly transferring the call.

### Announce the Call Transfer

You can talk to the person who answers the other phone before you transfer the call, to tell them whom you are transferring.


Fii	nd the Feature	● > Hold
Pr	ess	То
1	keypad keys	enter the phone number where you are transferring the call
2	8	dial the phone number
	•	Speak to the person who answers the target phone.
3	₽	open the menu
4	Ç	scroll to Transfer
5	SELECT (•)	select Transfer
6	0K (•)	confirm the transfer
		Your phone displays the message Transfer: Complete when the call is transferred. You can hang up the phone when you see this message.















# Using Features While On a Call



### Do Not Announce the Call Transfer

You can directly transfer a call without talking to the person who answers.

Find the Feature	● > Transfer
Press  1 keypad keys	<b>To</b> enter the phone number where you
i keypaa keys	are transferring the call
2 6	dial the phone number
	Your phone displays the message Transfer: Complete when the call is transferred. You can hang up the phone when you see this message.






# **Additional On-Call Features**

While you are on a call, you can perform the following tasks:

Do This	То
Press <b>HOLD</b> (♠) (if available)	put a call on hold
or	Your phone displays a
Press ● > Hold	Your phone displays a
Press ● > My Tel. Numbers	see your phone numbers












# Using the Menu






### Navigating to a Feature

You can access many of your phone's features by using these keys to move through the menu system:






This guide shows you how to navigate to a specific menu feature as follows:

The > symbol means that you should scroll to and select the feature. This example shows that you must press ♠, scroll to and select Recent Calls, then scroll to and select Dialled Calls to see the dialled calls list.

### Selecting a Feature Option

Some features require you to select an item from a list:



Select an item by highlighting it. Use one of the following approaches:

- Press to scroll up or down to the item you want.
- In a numbered list, press a number key to highlight the item.














### Using the Menu



 In an alphabetised list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.


### **Entering Feature Information**

Features such as the phonebook and datebook require you to enter information to fill in an entry's details:



- Enter numbers or text with the keypad. (See "Entering Text" on page 55.)
- When an item has a list of possible values, press to the left or right to scroll through and select a value.
- When an item has a list of possible numeric values, press a number key to set the value.
- If you enter or edit information and then decide that you do not want to save your changes, press to exit without saving.















# **Entering Text**





Various text entry methods make it easy for you to enter names, numbers, and text messages on your phone.

You can enter all characters (letters, numbers, and symbols) using the standard tap method. Other text modes let you easily enter numbers and symbols, or insert text already stored on your phone. Finally, a predictive text mode lets you enter text messages with a minimum of keypresses.

### Choosing a Text Mode

To activate a text mode, press • from any text entry screen and select the text mode from the Entry Method menu:

iTAP Let the phone predict each word as you enter it,

then choose the word from a list (see "Predictive Text Entry with iTAPTM Software" on page 60).

Enter characters one at a time by pressing the Tap Method

key for the letter, number, or symbol (see "Tap Method" on page 56). This is the standard mode for entering text on your phone.

Numeric Enter only the number that appears on each key.


Enter symbols only (see "Symbol Mode" on Symbol

page 59).


Browse Browse through your phonebook and recent

calls lists to select a name or number to enter.

**Note:** The text mode you select remains active until you change it by selecting another mode.











new v66 uk sapphire.book Page 56 Monday, February 4, 2002 4:21 PM





# **Entering Text**


Tap method is the default standard mode for entering text on your phone.


To activate tap method from any text entry screen, press  $\ensuremath{\Theta}$  and select the Tap Method menu option.

To enter text using the tap method:

**Tap Method** 


Do This		То
1	Press a number key one or more times	cycle through the characters associated with the key and select the character you want (see the "Character Chart" on page 58).
2	Continue to press number keys	enter the rest of the characters in the text message
3	Press <b>OK</b> ( <b>●</b> )	accept and store the text when you are finished




















### **General Text Entry Rules**

Use the keypad to enter letters, numbers, symbols, and other characters with the tap method. Press the same key repeatedly to cycle through available characters (see the "Character Chart" on page 58):













new v66 uk sapphire.book Page 58 Monday, February 4, 2002 4:21 PM





# **Entering Text**


- If you do not press a key for two seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- The first character of every sentence is capitalised unless you manually change it. (Press down to force the character to lowercase while it is highlighted by the block cursor.)

### **Character Chart**

Use this chart as a guide for entering spaces, numbers, letters, symbols, and other characters with the tap method.



130	space . 1 ? ! , @ _ & : ; " - ( ) ' ¿ ; % £ \$ ¥ €
2 ABC	abc 2 äåáàã $lpha$ $eta$ ç
3 DEF	def3 $\delta$ éèê $\phi$
4 сні	ghi4íγ
5 RL	j k l 5 λ
6 <sup>MN</sup> °	m n o 6 ñ ö ø ó ò ô õ ω
7 <sub>PQES</sub>	pqrs7πβσ
8 TUV	tuv8θüúù
9wxvz	w x y z 9 ξ <b>ψ</b>
0+	+ - 0 x * / \ [ ] = > < # §





















# **Entering Text**






# Symbol Mode

Your phone provides an alternative way to find and enter symbol characters in a text message. You can view and select from a variety of available symbols.

To activate symbol mode from any text entry screen, press  $\mbox{\bf } \mbox{\bf }$  and select the  $\mbox{\bf } \mbox{\bf } \mbox{\bf } \mbox{\bf }$  menu option.

To enter a symbol in symbol mode:


Do	) This	То
1	Press a number key one time	display its symbol options (see the "Symbol Chart" on page 60)
		The symbols associated with the key you pressed are shown at the bottom of the display. If necessary, press other keypad keys to find the symbol you want.
2	Press 💸	highlight the symbol you want
	or	
	Press the number key multiple times	
3	Press <b>SELECT</b> ( <b>●</b> )	add the highlighted symbol to the text area at the top of the display











### Symbol Chart

Use this chart as a guide for entering symbols in symbol mode.

13	space . ? ! , @ _ & : ; " - ( ) ' ; ¡ % f \$ ¥ €
2 ABC	@ _ \
3 DEF	1:;
4сні	" & '
5 JKL	( ) [ ] { }
6 <sup>MNO</sup>	¿ i ~
7 PQRS	< > =
8 TUV	\$ f ¥ €
9wxyz	# % *
0+	+ - x * / = > < # §

### Predictive Text Entry with iTAP™ Software

iTAP™ software provides a predictive text entry method that lets you enter the letters of a word using only one keypress per letter.

You must activate iTAP software prior to entering letters. You can do this from any text entry screen by pressing ● to open the Entry Method menu and selecting the iTAP menu option.













# Entering Text






# **Enter Words**

To enter a word with iTAP software:


Do	Press a number key one time	To enter the first letter of the word The letters associated with the key you pressed are shown at the bottom of the display.	
2	Press number keys (one per letter)	enter the rest of the word Alternative words and letter combinations are shown at the bottom of the display based on the keys you press. These word choices are updated with each keypress.	
3	When you have entered all the letters of the word, press	locate and highlight the word you want	
4	Press <b>SELECT</b> (•)	add the highlighted word to the text area at the top of the display A space is automatically inserted after the word.	



















For example, to spell the word "act," press  ${\color{red} 2000}$   ${\color{red} 3000}$  . The display shows:






### Enter Words not in the iTAP Dictionary

You may enter a word that is not in the iTAP software dictionary. If you enter all the letters of a word but the word is not displayed:

Do	This	То
1	Press <b>DELETE</b> ( <b>●</b> ) one or more times	delete one or more letters until you see a letter combination that matches the start of the word
2	Press 😵	highlight the letter or letter combination
3	Press <b>SELECT</b> (♠), then press ♠ to the left	shift the text entry cursor to the left and "lock" the selected portion of the word



















# **Entering Text**

Τo





Do This

Continue entering letters and highlighting letter combinations

spell the word

### **Punctuation**

The iTAP software automatically adds a space after each word. When you enter punctuation, this space is removed. To enter punctuation with iTAP software:









enter punctuation or other characters as shown in the "Character Chart" on page 58



### Capitalisation

The first word of a sentence is automatically capitalised, with following words in lowercase. To set or adjust character capitalisation with iTAP software:


P	r۵	c	c





up or down

change the words to initial character capitalised, all uppercase characters, or all lowercase characters















new v66 uk sapphire.book Page 64 Monday, February 4, 2002 4:21 PM





# **Entering Text**

### Enter Numbers

To enter a number with iTAP software:

Do	This	То
1	Enter the first digit and then highlight it	put the iTAP software in number entry mode
2	Press number keys	add digits to the number
3	Press <b>SELECT</b> ( <b>●</b> )	enter the number at the insertion point



# **Delete Letters and Words**

Place the cursor to the right of the text that you want to delete, and then do the following:

Do This	То
Press <b>DELETE</b> ( <b>●</b> )	delete one letter at a time
Continue to hold DELETE (•)	delete the entire message





new v66 uk sapphire.book Page 65 Monday, February 4, 2002 4:21 PM





# Menu Feature Descriptions





This chapter describes all of your phone's features in order of the menu map shown on pages 3–4. Some descriptions also include page numbers where you can find more detailed information.

### Main Menu

### RECENT CALLS

Received Calls

**●** > Recent Calls > Received Calls

View a list of recently received calls. See "Viewing the Received Calls or Dialled Calls List" on page 78.

**Dialled Calls** 

● > Recent Calls > Dialled Calls

View a list of recently dialled calls. See "Viewing the Received Calls or Dialled Calls List" on page 78.

Notepad

● > Recent Calls > Notepad

Call or store the last number entered on the keypad. See "Entering Numbers in the Notepad" on page 40, and "Using the Notepad" on page 81.

**Call Times** 

**●** > Recent Calls > Call Times

View call timers that track time spent on your last call, dialled calls, received calls, all calls since reset, and all calls total. See "Viewing and Resetting Call Timers" on page 82.

**Call Cost** 

**●** > Recent Calls > Call Cost



View call cost information. Your network may provide current credit information, and can



















# Menu Feature Descriptions

provide cost information about the amount spent on your last call, dialled calls, received calls, and all calls total. See "Viewing and Resetting Call Costs" on page 84.











● > Fixed Dia1

Dial or edit numbers in the fixed dial list.

When you activate the fixed dial feature, users can only call the numbers in the fixed dial list. To activate fixed dial, see the "Fixed Dial" item on page 73.

Fixed dial list entries can be any length. If there is a fixed dial entry for the digits 555, users can call any number that starts with 555.

You must enter your SIM PIN2 code to edit fixed dial entries. In the fixed dial list, you can create, edit, delete, and sort entries just like in the phonebook list. Fixed dial list entries are stored on your SIM card and do not have Type or Voice Name fields.

Note: Employers can use fixed dial to limit employees' phones to a predefined list of numbers, country codes, or other prefixes.

### **Р**но**м**евоок

● > Phonebook

Store names and numbers as entries in your phonebook, then call numbers by selecting them from the phonebook list. See "Phonebook" on page 86.

**⊕** > Datebook

Use the datebook calendar to schedule and review your appointments. See "Datebook" on page 99.















new v66 uk sapphire.book Page 67 Monday, February 4, 2002 4:21 PM





### Menu Feature Descriptions



### QUICK DIAL

● > Quick Dial

Dial pre-programmed numbers stored on your phone. Your service provider may program your phone with one or more quick dial numbers, such as the customer service number. You can call them by selecting them from the quick dial list.

**Note:** Your service provider may use a different name for this feature.

### **R**ADIO



Listen to FM radio stations with the optional Motorola Original™ FM Stereo Radio Headset accessory. This menu feature is displayed only when the FM Stereo Radio Headset is plugged into the accessory connector port on your phone. See "Radio" on page 105.







Adjust message settings, view and manage the various types of messages your phone can receive and/or send:

Voicemail Listen to your recorded voice

messages. See "Messages-Voicemail" on page 108

Send and receive text messages. See "Messages—Text" on page 110 Text Msgs

Browser Alerts Read alert messages received by your

micro-browser

Info Services Read information services messages

(subscription-based broadcast messages, such as stock updates, news, and weather reports) that you

have received













new v66 uk sapphire.book Page 68 Monday, February 4, 2002 4:21 PM





# Menu Feature Descriptions

**Quick Notes** Select and send pre-written messages

from the quick notes list.

Outbox View all outgoing text messages,

delivered and undelivered

Drafts Store and edit text messages that you

have written but not sent

### **S**HORTCUTS

Shortcuts Create keypad or voice shortcuts to menu features. See "Shortcuts" on page 117.

### **VOICE NOTES**

● > Voice Notes

Use the voice key to record messages and phone calls. See "Voice Notes" on page 121.

Note: Recording phone calls is subject to varying laws regarding privacy and recording of conversations.

### SIM APPLICATIONS

● > SIM Applications

Access information and applications stored on your SIM card.

Your SIM card may contain applications that process your outgoing calls, text messages, and other events. Contact your service provider for details.

### **BROWSER**

**⊕** > Browser


Access Web pages and run Web-based applications. The micro-browser delivers WAP (Wireless Application Protocol) pages from your service provider directly to your phone. See "Micro-Browser" on page 127.



### **CALCULATOR**

● > Calculator


Use your phone as a calculator or currency converter. See "Calculator" on page 129.













new v66 uk sapphire.book Page 70 Monday, February 4, 2002 4:21 PM





# Menu Feature Descriptions

### **PHONE STATUS**

My Tel. Numbers

● > Settings

> Phone Status > My Tel. Numbers



View, enter, and edit information about your name and phone number.

### Credit Info

**●** > Settings

> Phone Status

> Credit Info



View the credit available, its expiry date, and the date of the last deposit. (This feature is available only if you subscribe to a prepay option.)

### Credit Available

**⊕** > Settings

> Phone Status

> Credit Available



View the credit available. (This feature is available only if you subscribe to the advice-of-charge feature.)

### Active Line

 $oldsymbol{\Theta} > {\sf Settings}$ 

> Phone Status

> Active Line



Change the active phone line to send and receive calls from either of the available numbers. (This feature is available only for dual-line enabled SIM cards.)


### **Battery Meter**

● > Settings

> Phone Status

> Battery Meter

View a detailed battery charge meter.









new v66 uk sapphire.book Page 71 Monday, February 4, 2002 4:21 PM





# Menu Feature Descriptions







● > Settings > Phone Status

> Other Information

View your phone's feature specifications (if available from the service provider).

### **BROWSER SETUP**

**●** > Settings

> Browser Setup



Adjust the micro-browser's network connection settings, or create a new network connection profile.

### IN-CALL SETUP

Set the features that are active during a call, such as the in-call timer, call waiting, and call answering options.



**●** > Settings

> In-Call Setup

> In-Call Timer



Adjust call timer display and beep settings. You can set your timer to beep at a selected interval during your calls. (60 seconds is the default.) You can also turn on or off a display timer during calls as follows:

Тіме Display the elapsed time for the

current call

Cost Display the cost of the

current call (if you subscribe to a call cost option or

advice-of-charge)

Total Cost Display the cost of all calls

since the last time you reset the timer (if you subscribe to

a call cost option or advice-of-charge)

















new v66 uk sapphire.book Page 72 Monday, February 4, 2002 4:21 PM





### Menu Feature Descriptions

Credit Available Display how much credit you have left (if you subscribe to

a call cost option or advice-of-charge)



Off

No in-call timer display

### Call Cost Setup

● > Settings > In-Call Setup > Call Cost Setup



Adjust call cost settings.

You can assign a credit limit so that your phone displays your remaining credit during calls. Your phone notifies you when you approach your limit, and ends the call when you

Your phone network expresses cost in the amount of units used, but this feature lets you tell your phone how to translate the units to a currency.

### My Caller ID

● > Settings > In-Call Setup > My Caller ID



Activate and deactivate the display of your phone number as an ID when you call someone.

### Talk and Fax

● > Settings > In-Call Setup > Talk and Fax



Activate and deactivate the talk/fax service.

Use this feature prior to making a call when you want to talk and then send or receive a fax - all to the same phone number and within the same call.

You can also use the talk then fax feature to send a fax during a call. See "Sending a Talk then Fax Call" on page 155.
























# Menu Feature Descriptions





> In-Call Setup

> Answer Options

Turn call answering options on or off:

Multi-Key Answer by pressing any key
Open to Answer Answer by opening the flip

**Call Waiting** 

● > Settings





Activate and deactivate call waiting.

When call waiting is activated and another call arrives while you are on a call, call waiting can play a tone to notify you of the new call. See "Using Call Waiting" on page 47.





**●** > Settings > Security

> Phone Lock

Lock and unlock your phone. See "Locking and Unlocking Your Phone" on page 158.

Lock Application

⇒ Settings > Security 
 ⇒ Lock Application

Lock and unlock specific phone applications (such as phonebook or datebook). When an application is locked, users must enter the unlock code to use the application.

#### Fixed Dial

Settings
Security





Restrict outgoing calls to numbers on the fixed dial list. See "Fixed Dial" on page 66.















new v66 uk sapphire.book Page 74 Monday, February 4, 2002 4:21 PM





# **Menu Feature Descriptions**



● > Settings > Security > Call Barring

Restrict incoming and outgoing calls. See "Barring Calls" on page 159.

SIM PIN

● > Settings > Security > SIM PIN

Switch SIM card protection on and off, so users must enter the SIM card PIN code when they turn on the phone or insert a SIM card. See "Protecting the SIM Card" on page 160.

### New Passwords

⇒ Settings > Security
 ⇒ New Passwords

Change your unlock code (originally set to 1234) or your security code (originally set to 000000). See "Assigning a New Code or Password" on page 156.



#### **OTHER SETTINGS**

Personalise

⇒ Settings > Other Settings > Personalise

Set several personal phone options:

Main Menu Change the order of the main menu.

(See "Reordering Menu Items" on

page 147.)

**Keys** Change the functions of the soft keys

and smart key in the idle display. (See "Customising a Soft Key Function" on

page 147.)

**Greeting** Change the text displayed

when you turn on your

phone




















# **Menu Feature Descriptions**

Animation

Turn animation off (to conserve the battery) or on. Animation makes your phone's menus move smoothly as you

scroll up and down.

Language Set the language for phone menus

**Battery Save** Adjust the phone's power usage

characteristics to conserve power

Contrast Adjust the contrast setting for your display

DTMF Your phone can se

Your phone can send a number to the network as dual tone multi-frequency (DTMF) tones. DTMF tones are used to communicate with automated systems that require you to enter a number such as a code, password, or credit card number. Use this option to set DTMF tones to be long, short, or off.

Master Reset Reset all options back to their original factory settings *except* for the unlock

code, security code, and lifetime timer


Reset all options back to their original factory settings *except* for the unlock code, security code, and lifetime timer, *and* clear all user settings and entries *except* for information on the SIM

card

Master Clear

**Note:** This option erases all user-entered information stored in your phone's memory, including phonebook and datebook entries. Once you erase the information, it

cannot be recovered.
















#### 46tWOIK

⇒ Settings > Other Settings > Network

View and adjust your phone's network settings.

Your service provider registers your phone to a network. You can view information about the current network, change how your phone searches for a network, specify your preferred networks, change your phone's frequency settings for different geographical regions (1900 MHz or 900/1800 MHz), and activate alerts that indicate when a call is dropped or network registration changes.

#### Car Settings

> Settings
> Other Settings





Adjust hands-free car kit settings.

You can set your phone to route calls directly to the Easy-Install Hands-Free Kit when it detects a connection, and automatically answer calls after two rings. See "Hands-Free Use" on page 148.

**Note:** The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

## Headset

**●** > Settings

> Other Settings





Set your phone to automatically answer calls after two rings when connected to a headset. See "Hands-Free Use" on page 148.











You can use the recent calls menu to view received calls or dialled calls, retrieve the last number stored in the notepad, and view or reset call times and costs.

# Viewing the Received Calls or Dialled Calls List


Your phone keeps lists of the numbers from calls you recently received and dialled, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new ones are added. Each entry tells you the person's number (or name, if available) and whether the call connected or not. You can call, store, or delete the numbers on these lists.


**Shortcut:** Press to go directly to the dialled calls list from the idle display.

To open the recent calls menu:

Find the Feature	● > Recent Calls

Pro	ess <b>©</b>	To scroll to Received Calls or Dialled Calls
2	SELECT (•)	select Received Calls or Dialled Calls
3	Ç	scroll to an entry you want to call, store, or delete
		<b>Note:</b> ✓ means the call connected.



















riess	10
4 🙆	call the entry's number
	<b>Tip:</b> Press and hold for two seconds to send the entry number as DTMF tones. To activate DTMF tones, see the "DTMF" item on page 76.

or

view the entry's details if **View** appears above the right ◆ key, or store the entry's details in the phonebook if **Store** appears above the right ◆ key right • key

or

open the Last Calls Menu to perform other procedures as described in the following list





Option	Description
Store	Create a phonebook entry with the selected number in the No. field. (This option is not available if STORE appears above the right ◆ key, or if the number is already stored as a phonebook entry.)
Delete	Delete the entry. (This option is not available if <b>DELETE</b> appears above the left <b>•</b> key.)
Delete All	Delete all entries in the current list.








79















Option	Description
Hide ID/Show ID	Hide (or show) your caller ID for the next call.
Send Message	Create a new text message, with the selected number in the Tel No. field. See "Sending a Text Message" on page 114.
Add Digits	Add digits to the end of the selected number.
Attach Number	Attach another number from the phonebook or recent calls list to the end of the selected number.
Send Tones	Send the selected number to the network as DTMF tones, for credit card calling or password entry. (This option is available only during an active call.)
	To activate DTMF tones, see the "DTMF" item on page 76.
Talk then Fax	Tell the network you want to call and talk to someone, and then send a fax - all to the same number in the same call. See "Sending a Talk then Fax Call" on page 155.


















# **Using the Notepad**


Your phone uses a notepad to store the most recent string of digits entered - either for a phone number that you called or for a number that you entered but did not call.


To call the number, create a phonebook entry, or perform other operations with the number stored in the notepad:

Find the Feature	● > Recent Calls > Notepad
Press	То
<b>a</b>	call the number
or	
€	open the <b>Dialling Menu</b> (to attach a number or insert a special character). See "Additional Dialling Features" on page 44.
or	
STORE (•)	create a new phonebook entry, with the notepad number copied into the <b>No</b> . field. See "Storing a Phonebook Entry" on page 87.















# **Viewing and Resetting Call Timers**

Your phone tracks and records call times. Use the recent calls menu to view and reset a call timer.

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, please contact your service provider directly.

You can view the approximate network connection time elapsed during the following calls:

Timer	Description
Last Call	Time spent on the last call dialled or received. You cannot reset this timer.
Dialled Calls	Total time spent on dialled calls since the last time you reset this timer.
Received Calls	Total time spent on calls received since the last time you reset this timer.
All Calls	Total time spent on dialled and received calls since the last time you reset this timer.
Lifetime	Total time spent on all calls on this phone. You cannot reset this timer.









new v66 uk sapphire.book Page 83 Monday, February 4, 2002 4:21 PM







# Recent Calls





To view a call timer:


Fii	nd the Feature	
Pr	ess	То
1	Ç	scroll to the timer you want to view
2	SELECT (•)	view the recorded time

To reset the call timer:




Pr	ess	То
1	RESET (●)	reset the time (if available)
2	YES (•)	confirm the reset

















Your phone network can provide the following cost information:


Cost Tracker	Description
Credit	Amount of your credit remaining.
Available	For GSM advice-of-charge, this is only available if you set a credit limit.
	<b>Note:</b> Your phone receives cost information from the advice-of-charge feature or third-party prepay software.
Expiry Date	Date that the available credit expires (available only with a subscription to a prepay option).
Last Deposit	Amount of the last deposit (available only with a subscription to a prepay option).
Last Call	Amount spent on the last call you dialled or received. You cannot reset this cost tracker.
Dialled Calls	Amount spent on calls you dialled since the last time you reset this cost tracker.
Received Calls	Amount spent on calls you received since the last time you reset this cost tracker.

















	296
۰	


Cost Tracker	Description
All Calls	Amount spent on all dialled and received calls since the last time you reset this cost tracker.
	You can reset this value separate from Dialled Calls and Received Calls, so Dialled Calls plus Received Calls may not equal All Calls.

To view a cost tracker:

Fir	nd the Feature	● > Recent Calls > Call Cost
Pro 1	ess Ç	<b>To</b> scroll to the cost tracker you want to view
2	SELECT (•)	view the recorded cost

To reset the cost tracker:


Press	То
1 RESET (•)	reset the cost (if available)
2 OK (•)	enter your PIN2 code to confirm the reset
















You can store a list of names and phone numbers in your phone's electronic phonebook. You can view these entries and call them directly from your phone.


To see the list of names stored in your phonebook, press ● > Phonebook from the idle display. Scroll to a name and press VIEW (●) to view details of the phonebook entry as shown in the following display.

# Fields in a Phonebook Entry Form



**Note:** Phonebook entries stored on the SIM card do not have Type or Voice Name information.





Storing a Phonebook Entry











A phone number is required for a phonebook entry. All other information is optional.

You can store a phonebook entry on your phone or on the SIM card. Entries with a speed dial number from 1 to 500 are stored on the phone. To store a phonebook entry on your SIM card, assign a speed dial number of 501 or higher to the entry when you create it. The total number of entries you can store on the SIM card is dependent on your service provider.

**Shortcut:** Enter a phone number in the idle display, then press **STORE** (**●**) to create a phonebook entry with the number in the No. field. Go directly to step 1 in the following procedure to enter additional information and store the entry.

**Note:** You can also use the following procedure to store a fixed dial entry by scrolling to and selecting Fixed Dial.



Find the Feature	<ul><li>⇒ &gt; Phonebook</li><li>⇒ &gt; New</li></ul>
Press	То

Press		То
1	CHANGE (◆)	select Name
2	keypad keys	enter a name for the phonebook entry (see "Entering Text" on page 55)
3	OK (•)	store the name
4	CHANGE (•)	select No.
5	keypad keys	enter the phone number






















Press		То
6	0K (•)	store the phone number
7	CHANGE (•)	select Type
		<b>Note:</b> This option is not available for entries stored on a SIM card.
8	Ç	scroll to the type of phone number
9	SELECT (•)	select the number type
10	RECORD (◆)	record a voice name for the entry, if desired
	Go to step 11 if you do not want	See "Recording a Voice Name For a Phonebook Entry" on page 89.
	to record a voice name for the entry	<b>Note:</b> This option is not available fo entries stored on a SIM card.
11	٥	scroll to <b>Speed No</b> ., the number to speed dial the entry
		The next available speed dial numbe is assigned to a new phonebook number by default.
12	CHANGE (◆)	select <b>Speed No</b> . if you want to change it
13	keypad keys	enter a different speed number, if desired
		<b>Note:</b> Entries with a speed dial number from 1 to 500 are stored on the phone. Entries with a speed dial number of 501 or higher are stored on the SIM card.
























Pre	SS	То
14	0K (•)	save the modified speed number
		If your chosen speed number is already assigned to another entry, you are asked if you want to replace that entry.
15	SELECT (•)	select MORE if you want to create another entry with the same Name
		<b>Note:</b> You must enter a name and number to use this option.



# Complete Phonebook Entry


When you are finished entering information for a phonebook entry:

Press	То
DONE (•)	store the entry and return to the phonebook list




You can record a voice name when you create a new phonebook entry, or when you edit a previously stored phonebook entry. This lets you use voice dial to call the number without dialling (see "Voice Dial" on page 91).


**Note:** You cannot record a voice name for an entry stored on a SIM card.















**Tip:** Make your voice recording in a quiet location. Hold the phone about four inches (10 centimetres) from your mouth, and speak directly into the phone's microphone in a normal tone of

Find the Feature		
Do	This	То
1	Press 😵	scroll to the entry that needs a voice name
2	Press VIEW (◆)	display the entry's detailed view
3	Press <b>EDIT</b> (●)	edit the phonebook entry
4	Press 💸	scroll to Voice Name
5	Press <b>RECORD</b> (◆)	begin the recording process The phone displays Press Voice Key then say name.
6	Press and release the voice key on the right side of your phone and say the entry's name (in two seconds)	•
7	Press the voice key and repeat the name	d confirm the voice name The phone displays Trained: Voice Name.

# Dialling a Phonebook Entry

You can use the phonebook list, voice dial, speed dial, or 1-touch dial to call a number stored in your phonebook. To use































speed dial, see "Dialling With Speed Dial" on page 42. To use 1-touch dial, see "Dialling With 1-Touch Dial" on page 42.

## Phonebook List

To call a number in the phonebook list:

Find the Feature	● > Phonebook
Press	То
1 💸	scroll to the entry you want to call
2 4	make the call



### Voice Dial

Do

To call a number using voice dial:

Press and release the voice key on the right side of your phone and say the entry's name (in two seconds).

Your phone goes to the entry in the phonebook list, repeats the voice name, waits two seconds, then automatically dials the call.

# Editing a Phonebook Entry

You can edit a phonebook entry stored on your phone or the SIM card.

#### Notes:

• If you change an entry's speed dial number, the entry is moved to the new speed dial location and the original entry






















is deleted. Entries with a speed dial number from 1 to 500 are stored on the phone. Entries with a speed dial number of 501 or higher are stored on the SIM card.

 You can also use the following procedure to edit a fixed dial entry by scrolling to and selecting Fixed Dial.

Find the Feature	> Phonebook
Press	<b>To</b> scroll to the entry you want to edit
2 VIEW (•)	display the entry's detailed view

edit the phonebook entry

Edit a phonebook entry or fixed dial entry by following the procedures described in "Storing a Phonebook Entry" on page 87.



To delete a phonebook entry:

EDIT (O)

Find the Feature	● > Phonebook
Press	То
1 💸	scroll to the entry you want to delete
2 😝	open the Phonebook Menu
3 💸	scroll to <b>Delete</b>
4 SELECT (•)	select Delete



















new v66 uk sapphire.book Page 93 Monday, February 4, 2002 4:21 PM











Press
5 YES (•)

confirm the deletion

# Copying Phonebook Entries Between the Phone and SIM Card

Τo

You can copy one or more phonebook entries from your phone to the SIM card or from the SIM card to your phone.

#### Notes:

- This procedure copies the original entry to a new location. It does not delete the original entry.
- The SIM card cannot store **Type** and **Voice Name** data for entries. If you try to copy an entry with a type or voice name to the SIM card, the phone asks you for confirmation before dropping this information and copying the entry.






To copy a single phonebook entry from your phone to the SIM card or from the SIM card to your phone:

**Find the Feature** 

● > Phonebook
















Pr	ess <b>©</b>	To scroll to the entry you want to copy Note: Entries with a speed dial number from 1 to 500 are stored on the phone. Entries with a speed dial number of 501 or higher are stored on the SIM card.
2	€	open the Phonebook Menu
3	Ç	scroll to Copy Entry
4	SELECT (◆)	select Copy Entry The phone displays the Copy To form, with the next available speed dial number.
5	keypad keys	edit the speed dial number on the Copy To form
6	OK (•)	approve the copy to the speed dial number The phone displays the <b>Stored</b> message. You can now delete the old phonebook entry, if desired.

# **Copy Multiple Entries**

To copy multiple phonebook entries from your phone to the SIM card or from the SIM card to your phone:

#### 





new v66 uk sapphire.book Page 95 Monday, February 4, 2002 4:21 PM

Phonebook











Pre	ess	То
1	•	open the Phonebook Menu
2	Ç	scroll to Copy Entries
3	SELECT (•)	select Copy Entries
		The phone displays the <b>Copy Entries</b> form.
4	Ç	scroll to From (start)
5	CHANGE (•)	select From (start)
6	keypad keys	enter the first (lowest) speed dial number in the range of entries that you want to copy
		<b>Note:</b> Entries with a speed dial number from 1 to 500 are stored on the phone. Entries with a speed dial number of 501 or higher are stored on the SIM card.
7	0K (•)	store the number and return to the Copy Entries form
8	Ç	scroll to From (end)
9	CHANGE (•)	select From (end)
10	keypad keys	enter the last (highest) speed dial number in the range of entries that you want to copy
11	0K (•)	store the number and return to the Copy Entries menu
12	Ç	scroll to To (start)

















Pre	SS	То
13	CHANGE (•)	select To (start)
14	keypad keys	enter the first (lowest) new speed dial number for the entries' new location
15	0K (•)	store the number and return to the Copy Entries menu
16	DONE (•)	copy the entries The phone displays the Copied Entries message. You can now delete the old entries, if desired.

# **Checking Phonebook Capacity**

You can check phonebook capacity to see how much space is left for storing phonebook entries on your phone and on the SIM card. For entries stored on the phone, your phone displays a memory meter that shows how much memory space remains to store phonebook and datebook entries. For the SIM card, your phone lists the number of phonebook entries used and the number available.


Find the Feature	■ > Phonebook
Press	То
1 €	open the Phonebook Menu
2 💸	scroll to Phone Capacity or SIM Capacity















To





**Press** 

3 SELECT (•)

select Phone Capacity or SIM Capacity

Your phone displays the phone memory meter, or the number of SIM card phonebook entries available.

# Synchronising with TrueSync Software



You can synchronise phonebook entries between your phone and computer or hand-held device with Starfish TrueSync® software, a Motorola accessory product. See the TrueSync user guide for more information.

**Note:** TrueSync software is designed to synchronise with basic features of many popular Personal Information Management (PIM) software and hardware products.



# Setting Up the Phonebook

You can specify the sort order for your phonebook entries and the location of your 1-touch dial entries.


### Phonebook List Sort Preference

You can set up your phone to sort your phonebook list by speed dial number (the standard), name, or voice dial.

**Tip:** The voice dial sort is identical to the name sort, except that the entries with voice name tags appear first.

Find the Feature 

● > Phonebook













new v66 uk sapphire.book Page 98 Monday, February 4, 2002 4:21 PM





# Phonebook

Pr	ess	То	
1	€	open the Phonebook Menu	
2	Ç	scroll to Setup	
3	SELECT (•)	select Setup	
4	Ç	scroll to Sort by	
5	CHANGE (•)	select Sort by	
6	Ç	scroll to the entry you want	
7	SELECT (●)	select the entry you want	




# 1-Touch Dial Preference


Your phone lets you specify whether your 1-touch dial entries are located on the phone or the SIM card:



● > Settings > Other Settings > Initial Setup

Pr	ess	То
1	Ç	scroll to 1-Touch Dia1
2	CHANGE (•)	select 1-Touch Dial
3	Ç	scroll to the list you want
4	SELECT (•)	select the list you want

















The datebook is a calendar that lets you schedule and organise events such as appointments and meetings. You can review your schedule of events for the week or by the day, and have the datebook play a reminder alarm for specific events.

**Note:** You must set the correct time and date in order to use the datebook. Use the Time and Date feature (see page 75) to set the time and date.

To schedule or review events in the datebook:

**Find the Feature** 


● > Datebook





### Week View

When you open the datebook, your phone displays a calendar for the week. Lines or filled boxes under each day indicate scheduled events.


















# **Day View**

Select a day in the week view and press VIEW (◆) to see the day's events. You can store, edit, view, copy, and delete any event from the day view.







Select an event in the day view and press **VIEW** (●) to open the detailed event view. You can edit, copy, and delete events from the event view.




























# Storing a New Event


A title is required for a datebook event. All other information is optional.


Find the Feature	$\Theta$ > Datebook > $day$
	<b>●</b> > New

See "Selecting a Feature Option" on page 52 for instructions on scrolling to and selecting options.


Pr	ess	То
1	CHANGE (•)	select Title
2	keypad keys	enter a title for the event (see "Entering Text" on page 55)
3	0K (•)	store the event title
4	Ç	scroll to other fields and enter information as necessary
		Other fields let you enter start time, duration, date, repeating events, and reminder alarm.
5	DONE (•)	store the new event and return to the day view
















# **Changing Event Information**

To change information about an existing event:

Fi	nd the Feature	● > Datebook
Pr	ess	То
1	left or right	scroll to the scheduled event day
2	VIEW (•)	display the day view
3	٥	scroll to the event you want to change
4	VIEW (•)	display the event view
5	EDIT (•)	edit the event
6	٧	scroll to the detail you want to change
7	CHANGE (•)	edit the information
8	keypad keys	enter the new information
9	DONE (•)	store the information and return to the day view



















# Copying an Event

To copy information from a current event to a new event:

Fir	nd the Feature	<b>⊖</b> > Datebook
Pre	ess	То
1	💸 left or right	scroll to the scheduled event day
2	VIEW (•)	display the day view
3	Ç	scroll to the event to copy
4	•	open the Datebook Menu
5	Ç	scroll to Copy
6	SELECT (•)	copy the event
7	YES (•)	confirm the copy
		Your phone assumes that you want to change the date, and displays the <b>Date</b> field.
8	keypad keys	enter the date information
9	▶ (•)	move to the month, day, and year
	<b>or</b> to the right	
10	DONE (•)	save the copy of the event
11	Ç	scroll to event details and edit the information as necessary
12	DONE (•)	store the new event and return to the day view
		103





















Deleting	đП	Event	

Find the Feature	k
------------------	---

Press		То
1	left or right	scroll to the scheduled event day
2	VIEW (•)	display the day view
3	<b>©</b>	scroll to the event to delete
4	€	open the Datebook Menu
5	Ç	scroll to Delete
6	SELECT (◆)	select Delete
		For non-repeating events, go to step 7. For repeating events, the phone displays a delete event menu:
	a 🐯	scroll to This Event Only or Repeat Events
	b SELECT (●)	select the event(s) to delete
7	YES (•)	confirm the deletion
		The phone briefly displays a <b>Deleted</b> : message and returns you to the day view.















# Radio








You can use your phone to tune, store presets, and listen to FM radio stations when the optional Motorola Original<sup>TM</sup> FM Stereo Radio Headset accessory is plugged into the phone's accessory connector port.

# Turning the Radio On and Off

Press	То
Radio (●)	turn the radio on and off

Alternatively, you can use the following procedure:



**Note:** The **Radio** (•) soft key option and **Radio** menu feature are displayed only when the FM Stereo Radio Headset is plugged into the accessory connector port.

# **Tuning a Station**

Do This Press or	<b>To</b> scroll up or down to the next frequency
Press and hold 💸	scroll up or down to the next available stereo station
	105


















# Radio

# Storing a Preset

To store a station to a preset that you can recall later:

Do This	То
Press and hold a number key (  to   to   to   to   to   to   to   t	assign its preset number to the tuned station

# Selecting a Preset

To select a preset radio station:

Press	То
a number key ( to •••)	tune the station stored at that preset location



# Making and Receiving Calls With the Radio On

Your phone interrupts the radio signal and rings or vibrates as usual to notify you of an incoming call, message, or other event. When you receive a call:

Do This	То
Press <b>IGNORE</b> (•)	ignore the call
Press ANSWER (●)	answer the call
or Press the button on the FM Stereo Radio Headset microphone	<b>Note:</b> You can use the FM Stereo Radio Headset microphone to converse with the other party during a call
















Turn the radio off before dialling outgoing calls from the phone keypad. You do not have to turn off the FM radio feature to dial emergency numbers, or numbers selected from your phonebook or other lists.







Messages—Voicemail









You can listen to your voicemail messages by calling your network voicemail phone number. Voicemail messages are stored on the network - not on your phone. Contact your service provider for more details.

# Storing Your Voicemail Number


Store your voicemail number in your phone to make it faster and easier to use voicemail. Your voicemail number is provided by your service provider.

Fii	nd the Feature	<ul><li>→ &gt; Messages</li><li>→ &gt; VoiceMail Setup</li></ul>
Pr 1	<b>ess</b> keypad keys	<b>To</b> enter the phone number for your voicemail
2	0K (•)	store the number

# Receiving a New Voicemail Message

When you receive a voicemail message, your phone displays New VoiceMail . (Some networks only indicate when you have messages, whether they are new or not.) If reminders are turned on, your phone sends a reminder every five minutes until you close the new message notification, listen to the message, or turn off your phone. (See "Reminders" on page 144.)





# Listening to a Voicemail Message

To listen to your voicemail messages at any time:

Your phone calls the voicemail phone number you stored. If you do not have a voicemail number stored, the phone guides you through storing a number.













Text messages are brief messages that you can send and receive (such as Where are we meeting?). Received messages appear on your phone display or in your text message inbox.

You must set up the text message inbox *before* you can send and receive these messages. The total number of messages the inbox can hold depends on the length of the messages, and the number of other messages and drafts stored in your phone.

**Note:** Your service provider may have already programmed the text message inbox settings for you.

## Setting Up the Text Message Inbox

Find the Feature	<b>●</b> > Messages
	<b>⊕</b> > Text Msg Setup

Pr	Press To	
1	CHANGE (◆)	change the <b>Srvce Centre No</b> . which is provided by your service provider
2	keypad keys	enter the phone number for the service centre that handles your outgoing messages
3	0K (•)	store your service centre number
4	CHANGE (◆)	change the Expire After period
5	keypad keys	enter the expiry period - the number of days your network tries to send unreceived messages



























Press To		То
6	0K (•)	store the expiry period
7	CHANGE (◆)	change the Reply Type
8	<b>©</b>	scroll to the default type of replies you want to send - text messages, or other formats
9	0K (•)	store the reply type
10	CHANGE (◆)	change the <b>Cleanup</b> setting
11	٥	scroll to the period of time that messages stay in your inbox
12	SELECT (●)	select the cleanup period If you select <b>Custom</b> , continue. Otherwise, the procedure is complete.
13	Ç	change the entry for the number or label
14	left or right	switch between the number and the label
15	DONE (•)	store the custom cleanup period after you finish entering all information











**Note:** You must set up the text message inbox before you can receive text messages. See "Setting Up the Text Message Inbox" on page 110.

When you receive a new message, your phone displays **New Message** □ and gives an alert. If reminders are turned on, your phone sends a reminder every five minutes until you close the new message notification, read the message, or turn off your phone. (See "Reminders" on page 144.)

When your inbox is full, any new message replaces the oldest unlocked message.

From the new message notification:

Receiving a Text Message




Press	То
READ (•)	open the message (or your text message inbox if there are multiple messages)

# Reading, Locking, or Deleting a Text Message

You can open your text message inbox to read, lock, or delete messages at any time.

Messages in the text message inbox are sorted from newest to oldest. The oldest messages are deleted as new ones are added. If you want to save a message, you should lock it to prevent it from being overwritten as new messages are received.
















Pr 1	ess 🗳	To scroll to the message you want (□! = unread and urgent, □ = read, 🚹 = read and locked)
2	READ (•)	open the message
3	SAVE (•)	close the message without changes
	or DELETE (◆)	delete the message
	or ⊕	open the <b>Text Msg Menu</b> to perform other procedures as described in the following list





Option	Description	
Call Back	Call the number in the message header or the message text.	
Go To	Go to a Web address (URL) in the message.	
Reply	Open a new text message, with the message's Reply To number in the To field.	
Forward	Open a copy of the text message, with an empty To field.	
Lock/Unlock	Lock or unlock the message.	

















Option	Description	
Store Number	Open a new phonebook entry with the message's embedded number in the <b>No</b> . field.	
Delete	Delete the message or all inbox messages.	
or	Press <b>Yes</b> ( <b>○</b> ) to confirm the deletion.	
Delete All		
Create Message	Open a new text message form.	
Setup	Open the inbox setup menu.	



# Sending a Text Message

You can create and send a text message to one or more recipients. The text message feature lets you manually enter each recipient's phone number, or select one or more numbers from the phonebook or recent calls lists.


**Note:** When you manually enter multiple phone numbers in the **To** field, you must insert a space between each number. Press and hold to insert a space as needed.

Find the Feature


**●** > Messages

● > Create Message

Press		To
1	CHANGE (O)	select To
























Pr	ess	То
2	keypad keys	enter one or more phone numbers where you want to send the message
		<b>Tip:</b> Remember to press and hold to add a space between numbers that you enter manually.
	or BROWSE (♠)	select one or more phone numbers from the phonebook or recent calls lists
3	0K (•)	store the number(s)
4	CHANGE (•)	select Msg
5	keypad keys	enter the text message (see "Entering Text" on page 55)
		<b>Note:</b> Message length is limited. When 40 or fewer characters remain, a two-digit counter at the top of the display shows how many are left.

store the text message


finish the message Your phone displays Send Message Now?





6 OK (•)

7 DONE (•)





new v66 uk sapphire.book Page 116 Monday, February 4, 2002 4:21 PM





# Messages—Text

Press		То
8	YES (•)	send the message
	or	
	N0 (•)	cancel the message or save it as a draft
		A saved message is stored in the drafts folder, where you can edit it and send it at a later time.

# Viewing the Status of Sent Text Messages



Text messages that you send are stored in the outbox. To view the contents of your outbox:  $\begin{tabular}{ll} \hline \end{tabular}$ 

 $\label{thm:messages} \mbox{Messages are sorted from newest to oldest.}$ 


The following icons indicate message status:

 $\gg =$  sending in progress  $\square =$  delivered

**X** = sending failed







Your phone includes several pre-programmed shortcuts. You can create additional shortcuts, if you like, to mark frequently used menu items.

#### **Standard Shortcuts**

The following shortcuts are pre-programmed in your phone. You cannot edit or delete these shortcuts.

Do This	То
Press	zoom in/out your phone's display view
two seconds)	(See "Changing the Zoom Setting" on page 33.)
Press 🗈 🐠	display your phone number
Press 🕏	go to the dialled calls list
	(See "Recent Calls" on page 78.)
Press a	exit the menu system, return to the idle display

### **User-Settable Shortcuts**

You can create shortcuts to many menu features and applications. A shortcut takes you directly to the menu item, or performs the menu action (if applicable).









## **Shortcuts**



# Creating a Shortcut


You can assign a keypad shortcut, or both a keypad shortcut *and* a voice shortcut to a menu item.

A voice shortcut lets you go directly to a menu item by saying its shortcut name.

**Tip:** Make your voice recording in a quiet location. Hold the phone about four inches (10 centimetres) from your mouth, and speak directly into the phone's microphone in a normal tone of voice


Do	o This	To
1	Press	enter the menu system
2	Scroll to the item to which you want to assign a shortcut	highlight the menu item
3	Press and hold €	open the shortcut editor The phone displays:  Assign Shortcut for: "Item"? where Item is the name of the item you selected.
4	Press YES (•)	view shortcut options


















# Shortcuts


Do	This	То
5	Press CHANGE (◆)	change the keypad shortcut number, if necessary


or

OI .	
Press <b>DONE</b> (●)	select the default keypad shortcut number and close the shortcut editor if you do not want to assign a voice shortcut

	or Press 😵	scroll to <b>Voice</b> if you want to assign a voice shortcut
6	Press <b>RECORD</b> (●)	begin the recording process The phone displays Press Voice key then say voice shortcut.
7	Press and release the voice key on the right side of your phone and	record the shortcut name The phone displays Press Voice















## **Shortcuts**

# **Using Shortcuts**

You can use a shortcut from the idle display, while on a call, or while scrolling through a menu.

## Use a Keypad Shortcut

If you know the shortcut number:

Pr	ess	То
1	•	open the menu
2	the shortcut's number	go to the menu item, or perform the menu action



### Select a Shortcut From the List

To select a shortcut from the shortcut list:

Find the Feature

● > Shortcuts

> the shortcut you want

### Use a Voice Shortcut

To use a voice shortcut:

0	Oo This	То	
1	Press	open the menu	
2	Press and release the voice key on the right side of your phone and say the shortcut's name (in two seconds)	go to the menu item, or perform the menu action	
120			
<u> </u>		_	А









new v66 uk sapphire.book Page 121 Monday, February 4, 2002 4:21 PM







# **Voice Notes**

The voice note feature lets you record personal messages or phone calls. You can play back a voice note at any time. There are no pre-recorded voice notes on your phone.

### Recording a Voice Note

Use this procedure to record a voice note when the idle display is visible, or use it during a phone call to record the call. Your phone plays an alert tone to notify the other party that the call is being recorded.

**Note:** Recording phone calls is subject to varying laws regarding privacy and recording of conversations.

**Tip:** Make your voice recording in a quiet location. Hold the phone about four inches (10 centimetres) from your mouth, and speak directly into the phone's microphone in a normal tone of voice.





#### Do This

#### Press and hold the voice key on the right side of your phone for the duration of the recording.

2 Speak your voice note into the phone while continuing to hold the voice key.

**3** Release the voice key to stop recording.

#### Result

A tone sounds in the earpiece and the phone displays the **Recording Voice Note** message.

The phone records your voice note and displays a recording timer.

The phone displays the voice notes list number and the total recording time.















# **Viewing the Voice Notes List**

The voice notes list shows all your voice notes along with other important information and features.

#### 



**New Voice Note** appears at the end of the list or by itself if no voice notes are stored. Select **New Voice Note** to view instructions on how to record a new voice note.





new v66 uk sapphire.book Page 123 Monday, February 4, 2002 4:21 PM





### **Voice Notes**





# Playing a Voice Note

**Find the Feature** 

Pre	ess	То
1	Ç	scroll to the voice note
2	PLAY (o)	play the voice note

● > Voice Notes


When an optional Motorola Original™ headset accessory or FM Stereo Radio Headset accessory is connected to your phone, voice note playback is automatically routed to the headset.


**Tip:** You can play a voice note while taking a call. It won't be transmitted to the other party.




### Playback Screen


While the voice note is playing, the playback screen is displayed.






















## **Voice Notes**

# Locking and Unlocking a Voice Note

You can prevent a voice note from being accidentally deleted by locking it. To delete a locked voice note, you must first unlock it.

Find the Feature	● > Voice Notes
Press	То
1 💸	scroll to the voice note you want to lock or unlock
2	open the Voice Notes Menu
3 💸	scroll to Lock or Unlock
4 SELECT (♠)	lock or unlock the voice note




Press	То
1 €	open the Voice Notes Menu
2 💸	scroll to Lock or Unlock
3 SELECT (•)	lock or unlock the voice note

Playback stops when you lock or unlock a voice note. Press any number key to resume playback.















# **Deleting a Voice Note**

You can delete a single unlocked voice note or all unlocked voice notes. To delete a locked voice note, you must first unlock it. See "Locking and Unlocking a Voice Note" on page 125.

Fi	nd the Feature	<b>●</b> > Voice Notes
Pr	ess	То
1	Ç	scroll to the voice note you want to delete
2	•	open the Voice Notes Menu
3	Ç	scroll to Delete or Delete All
4	SELECT (●)	select the highlighted option The phone displays Delete Voice Note X?, or Delete All Voice Notes?
5	YES (•)	delete the selected voice note, or delete all voice notes

# Notes:


- You can always press № (•) to cancel deletion.
- A deleted voice note cannot be recovered.

















# Micro-Browser







The micro-browser lets you access Web pages on your phone. Contact your service provider to set up access, if necessary.

**Note:** Your phone may be configured to use a high-speed GPRS (General Packet Radio Service) network connection. This type of connection can be identified by a **GPRS** indicator in the idle display that disappears when you start a micro-browser session. If a \(\mathbb{c}\) (connected call) indicator is displayed when you start a micro-browser session, your phone is using a standard voice channel connection. Your network connection charges may vary depending on the type of connection used.



### Starting a Micro-Browser Session

To open the micro-browser:




● > Browser

The micro-browser displays the home page set up by your service provider.

Pr	ess	То
1	Ç	scroll to a bookmark or service
2	SELECT (●)	select the service

**Shortcut:** If you open a text message with a Web address (URL) in it, you can go directly to the URL by selecting  $\Theta > Go$  To.

If you are unable to establish a network connection with the micro-browser, contact your service provider.





















# Micro-Browser


# **Interacting With Web Pages**

You can perform the following operations on a Web page:

Do This	То
Press 💸	scroll through a text message
Press and then SELECT (•)	scroll through and select items in a list
Press keypad keys	enter requested information
and then OK (●)	<b>Tip:</b> Press ◆ to delete one letter at a time if you make a mistake.
Press to scroll to a phone number on a Web page, then press	call the number from the micro-browser
Press *	go back to the previous Web page
Press	open the Browser Menu














You can use your phone as a convenient calculator and currency converter.

# **Calculating Numbers**

Fir	nd the Feature	● > Calculator	
Pre	ess	То	
1	number keys	enter a number in the calculator	
2	💸 left or right	highlight a calculator function	
3	SELECT (•)	perform the highlighted function	
Pre left to h	ected function pears here ss to rright nighlight a ction	Entered number  Press scroll to confunctions  SELECT  Perform t	other













# Calculator

The calculator can perform the following functions:

Function	Description	
	Insert a decimal point	
C	Clear the calculation	
CE	Clear entry (replaces the C function when you enter subsequent values in a calculation)	
=	Calculate the result	
+	Add	
-	Subtract	
Х	Multiply	
÷	Divide	
%	Divide the displayed value by 100	
±	Change the entry's sign (positive/negative)	
\$	Calculate the exchange rate	
MS	Store the current value in memory (overwrites values already stored)	
MC	Clear the value stored in memory	
MR	Replace the displayed value with the value stored in memory	







new v66 uk sapphire.book Page 131 Monday, February 4, 2002 4:21 PM





# Calculator





# **Converting Currency**

**Find the Feature** 


The currency converter works just like the calculator, but uses the \$ (currency) function:

lacktriangle > Calculator


		● > Exchange Rate
Press		То
1	number keys	enter the exchange rate
2	0K (•)	store the exchange rate
3	number keys	enter the amount to convert (amount to multiply by the exchange rate)
4	left or right	highlight the \$ function
5	SFLECT (a)	nerform the conversion





















# **Games**

**Find the Feature** 


Your phone contains three games that you can play between phone calls. If you get an incoming call, message, alarm, or alert, the game ends automatically.

# Selecting and Starting a New Game


Pr	ess	То
1	Ç	scroll to the game of your choice
2	SELECT (●)	start the game


**●** > Games





Press	То
BACK (•)	return to the games menu
or	
N0 (•)	
NEW (•)	start another session of the game you
or	just played
YES (•)	











#### Games





## Ending a Game

You can end a game at any time.

Press BACK (◆)	<b>To</b> end the game session and return to
or	the games menu
8	


# Playing a Game

### Blackjack

In this classic Las Vegas card game, you play against the dealer to see who can get closer to 21 points without going over.

#### Rules of the game

- With each new hand, the first card is dealt to the dealer.
   The dealer's cards are shown at the top of the display, and your cards are shown at the bottom.
- All picture cards count as 10 points.
- All number cards count as the points shown on their face.
- An Ace counts as 11 points, unless that would put you over 21 points. Otherwise, an Ace is counted as 1 point. An Ace that was originally counted as 11 may later be counted as 1 point if it will bring your points under or equal to 21 points.
- An initial deal of an Ace and a card with a face value of 10 points counts as exactly 21 points or Blackjack.
- Blackjack automatically wins against any other hand that totals 21 points.
- If you score more than 21 points, you go "bust" or lose.























#### **Games**

- If you get five cards without going bust, you win.
- If you and the dealer have the same score, the dealer wins.
- You can ask for a "hit" or another card as long as you do not go bust.
- As long as the dealer's total is less than 17 points, the dealer must continue to take a hit.

#### How to Play

When the game begins, you are dealt two cards. Based on their total face value, you can:

Press	То
STAY (•)	see the results of the hand
HIT ME (•)	request another card






#### Mindblaster

Your goal is to guess a secret four-symbol code. You play by entering symbols into four spaces and then submitting a guess.

#### Rules of the Game

- Your score is the number of guesses it takes to reveal the secret code.
- When you submit a guess, you are given clues that indicate how many symbols you have identified correctly and how many are in the correct position. The position of the clues does *not* correspond to the location of the symbols.
  - = correct symbol in correct position
  - $\blacksquare$  = correct symbol in wrong position









new v66 uk sapphire.book Page 135 Monday, February 4, 2002 4:21 PM





### **Games**





- You can see a history of your last 10 guesses.
- Once you enter a symbol into a blank space, you can change the symbol but you cannot make the space blank again.
- When you correctly guess the four-symbol code, the display shows your score and the level of your next game.
- After you win one game, you progress from level 1 to level
- After you win two more games, you progress from level 2 to level 3.
- When you exit the game or turn off the phone, you begin again at level 1.




#### How to Play

When the game begins, you see four blank spaces. To play the game:



Do This	То
Press 😵 left or right	move from space to space
Press 😵 up or down	place a symbol in a space
Press <b>GUESS</b> (●)	submit a guess (when all four spaces contain symbols)
Select   and then press   up or down	scroll through and view a history of your last 10 guesses




















### **Paddleball**

In this test of endurance, your mission is move your paddle to strike a bouncing ball. The more you succeed, the smaller your paddle gets.

### Rules of the game


- Your score is the number of times your paddle hits the ball.
- You lose when the paddle misses the ball.

#### How to play


Press	То
😵 up or down	move your paddle so that it hits the bouncing ball













new v66 uk sapphire.book Page 137 Monday, February 4, 2002 4:21 PM





# **Adjusting Your Settings**





You can adjust a wide variety of phone settings to suit your needs.

## Ring/Vibrate

Your phone rings or vibrates to notify you of an incoming call, message, or other event. This ring or vibration is called an *alert*. You can select one of five different alert profiles:

> Δ)) Loud ring

△୬ Soft ring

Vibrate 808

♠△ Ring and vibrate

Silent



The alert setting indicator in your display shows the current alert profile (see illustration on page 32).

Each alert profile contains settings for ringer and keypad volume. It also includes alert tone settings for different events: incoming calls, text messages, voicemail messages, data calls, fax calls, alarms, and reminders. You can modify the settings in each

## Select an Alert Profile

**Find the Feature** Settings > Ring/Vibrate > Alert


**Press** To

scroll to the alert profile you want to 




















Press To 2 SELECT (♠) sele

select the alert profile


The phone displays the

The phone displays the **Changed: Alert** message.

### Customise an Alert Profile

You can customise a profile by changing the alerts used for specific events (such as incoming calls, text messages, etc.). Your phone includes a variety of preset alert tones and vibrations. Any changes you make are saved to the current alert profile.

**Tip:** This feature also lets you set the profile's ringer volume and keypad volume.



Press		То
1	٥	scroll to the event for which you want to set a new alert
2	CHANGE (◆)	select the event
		The phone displays the list of available alerts.
3	٥	scroll to the alert you want for the event
4	SELECT (•)	select the alert
		The phone displays the <b>Changed</b> : <b>Event Alert</b> message.






















# Use the My Tones Feature

The my tones feature lets you create up to 32 custom alert tones for your phone. The tones you create appear in the list of available alerts (see "Customise an Alert Profile" on page 138).

### Creating a Tone

Find the Feature	> Settings > Ring/Vibrate
	> My Tones

Press		То
1	Ç	scroll to <b>ENew Tone</b>
2	SELECT (•)	select ENew Tone]
3	CHANGE (•)	select Notes
4	keypad keys	enter notes for the tone (see "Entering Notes" on page 140)
5	0K (•)	store the notes
6	CHANGE (•)	select Name
7	keypad keys	enter the name for the tone
8	0K (•)	store the name
9	DONE (•)	store the tone





















### **Entering Notes**

To create a new tone, use the keypad keys to enter each note. Press a key multiple times to cycle through its available notes or options (pitch, octave, or length). The default setting for a new tone is a quarter note in octave two.

Key	Phone Display	Description
13	1	set octave one
	2	set octave two
	3	set octave three
2 <sub>ABC</sub>	A	note A
	В	note B
	C	note C
3 DEF	D	note D
	E	note E
	F	note F
4 сні	G	note G
	R	rest
7 <sub>PQRS</sub>	#	sharp
	b	flat
0+	q	quarter note or quarter rest
	h	half note or half rest
	W	whole note or whole rest

























Enter a note as follows:

Task	Action
Change the octave	Set the new octave (1, 2, or 3) before selecting the note. The new octave applies to the note and all following notes until you change it again.
Select the note (required)	Press a keypad key to enter a note.
Change a note to a sharp or flat	Enter a sharp or flat (# or b) after selecting the note.
	Some sharps and flats are played as standard notes. For example, <b>B</b> # is the same as <b>C</b> . Press to scroll to valid notes when entering a new note.
Change a note's length	Set the new length (h, w, or q) after selecting the note. The new length applies to the note and all following notes until you change it again.
Add a rest	Enter one or more rests (R characters) as needed in the tone sequence. You can set the length of the rest by entering an h, w, or q character after the rest, just as you can for a note.
Listen to a new tone as you compose it	Press ● to enter the Compose Menu, and select Play All to play the notes you have entered.















# Example

Press the following keys to play this sequence of notes and rests in octave three: C (quarter note), E flat (quarter note), half rest, and G (whole note):

Pr	ess	То	Phone Display
1	<b>(b)</b> (b)	set octave three	3
2	2 ABC 2 ABC 2 ABC	enter a quarter note C	С
3	3 off 3 off 7ress 7ress	enter a quarter note <b>E flat</b>	Eb
4	4cm 4cm 0+ 0+	enter a half rest	Rh
5	4 cm 0+ 0+ 0+	enter a whole note <b>G</b>	Gw



### Playing a Tone

Find the Feature	Settings > Ring/Vibrate
	> My Tones

Press		То
1	<b>Ç</b>	scroll to the tone you want to play
2	•	open the My Tones Menu
3	Ç	scroll to <b>Play</b>
4	SELECT (•)	select Play
		The phone displays the playback meter and plays the tone.











new v66 uk sapphire.book Page 143 Monday, February 4, 2002 4:21 PM





# **Adjusting Your Settings**





Press	То
5 PLAY (•)	play the tone again
or	
CANCEL (◆)	return to the my tones list

### **Editing a Tone**

You cannot edit the standard alert tones included with your phone. To edit a custom tone that you created:


Fii	nd the Feature	
Pr	ess	То
1	Ç.	scroll to the tone you want to edit
2	EDIT (•)	open the tone details
3	٥	scroll to the details you want to edit (Name or Notes)
4	CHANGE (•)	select the details you want to edit
5	keypad keys	enter new text or notes (see "Entering Notes" on page 140)

store the details

#### **Deleting a Tone**

OK (•)

You cannot delete the standard alert tones included with your phone. To delete a custom tone that you created:







143



new v66 uk sapphire.book Page 144 Monday, February 4, 2002 4:21 PM






# **Adjusting Your Settings**

Press		То
1	Ç	scroll to the tone you want to delete
2	€	open the My Tones Menu
3	Ç	scroll to Delete
4	SELECT (•)	select Delete
5	YES (•)	confirm the deletion


## Reminders

Reminders are alerts that ring or vibrate to notify you about a voicemail or text message that you have received, or a datebook event that you have scheduled.

To set or turn off reminders:



Press	То
1 💸	scroll to the reminder alert you want: Beep, Vibrate, or Off
	<b>Beep</b> or <b>Vibrate</b> sets the corresponding reminder alert type. <b>Off</b> turns off all reminders.
2 SELECT (♠)	select the reminder alert







new v66 uk sapphire.book Page 145 Monday, February 4, 2002 4:21 PM





## **Adjusting Your Settings**





## **Call Diverting**



Call diverting sends your phone's incoming voice, fax, and/or data calls directly to another phone number. Use call diverting options to specify which calls your phone should divert. When you are ready to accept calls on your phone again, you can turn off call diverting.

#### Set Up or Cancel Call Diverting

The call diverting options for voice, fax, or data calls are:

All Calls diverts all calls


If Unavailable diverts calls if your phone is unavailable

uses different diverting numbers if you are Detailed

out of range, unable to answer, or busy (voice calls only)

Off does not divert calls





Pre	ess	То
1	<b>©</b>	scroll to the type of calls you want to divert
		(Cancel All cancels all call diverting and ends the procedure.)
2	SELECT (◆)	open the call divert details for that call type











Adjusting Your Settings		
Pr	ess	То
3	Ç	scroll to Divert
4	CHANGE (•)	change the <b>Divert</b> option
5	Ç,	scroll to the call divert option you want
6	SELECT (●)	store the option
7	Ç	scroll to To (same for If Busy, If No Answer, or If Unreachable)
8	CHANGE (•)	change the phone number
9	keypad keys	enter the diverting phone number
	or Browse (◆)	browse through your phonebook or

**Note:** You can repeat this procedure to enter diverting information for other call types.

number

### Check Call Diverting Status


10

OK (**o**)

Your network may store call diverting status for you. If you change your phone's call divert settings (see "Set Up or Cancel Call Diverting" on page 145), then you should confirm that the network call divert status matches your preferences.


other lists for the diverting phone

store the diverting phone number















## **Adjusting Your Settings**





Press	То
1 💸	scroll to Voice, Fax, or Data calls
2 View (•)	confirm that the network settings are correct

## **Reordering Menu Items**

**Find the Feature** 


You can customise the order of the items in your phone's main menu, depending upon your usage.

● > Settings > Other Settings

		> Personalise > Main Menu
Pr	ess	То
1	<b>©</b>	scroll to the menu item you want to move
2	GRAB (◆)	grab the menu item you want to move
3	Ç	move the item up or down the menu
4	INSERT (•)	insert the item in the new location

## **Customising a Soft Key Function**

You can relabel the soft keys (left  $\bullet$  and right  $\bullet$ ) and the smart key to access different main menu items from the idle display.











new v66 uk sapphire.book Page 148 Monday, February 4, 2002 4:21 PM





Press		То
1	Ç	scroll to Left, Right, or Smart
2	CHANGE (•)	open the key editor
3	Ç	scroll to the new key function
4	SELECT (•)	confirm the new function
		The key will have the new function whenever the phone is idle.


Adjusting Your Settings

## Hands-Free Use





You can purchase an optional Motorola Original™ Easy-Install Hands-Free Kit for your car, or an optional Motorola Original phone headset. These accessories provide alternative ways for you to use your phone without using your hands.



#### **Automatic Answer**

When you activate automatic answer and connect your phone to the Easy-Install Hands-Free Kit or phone headset, your phone automatically answers calls after two rings.

Find the Feature	● > Settings > Other Settings	
Press 1 🚱	To scroll to Car Settings or Headset	
148		
		•









Pr	ess	То
2	SELECT (•)	select the feature
3	Ç	scroll to Auto Answer
4	SELECT (•)	select Auto Answer
5	Ç	scroll to On or Off
6	SELECT (•)	confirm the setting

### **Automatic Hands-Free**


You can set up your phone to automatically route calls to the Easy-Install Hands-Free Kit when it detects a connection.



Press		То
1	<b>©</b>	scroll to On or Off
2	SELECT (•)	confirm the setting

### Power-Off Delay

When your phone is connected to the Easy-Install Hands-Free Kit, you can set it to stay on for a specified time period after you switch off the ignition. This keeps your phone from draining your vehicle battery by staying on indefinitely, but leaves your phone on long enough that you do not have to re-enter your unlock code when you make short stops.









## **Adjusting Your Settings**

Find the Feature	Settings > Other Settings
	> Car Settings
	> Power-Off Delay

Pre	ess	То
1	Ç	scroll to the time delay option you want
2	SELECT (●)	confirm your selection

**Caution:** If you select **Continuous**, the phone does not power off when you turn off the ignition. Be careful not to accidentally drain your vehicle battery if you select this option.

## Charger Time

When your phone is connected to the Easy-Install Hands-Free Kit, you can set it to charge itself for a specified time period after you switch off the ignition. This helps ensure that the phone battery gets fully charged while the vehicle is parked.

Find the Feature	● > Settings > Other Settings > Car Settings
	> Charger Time

Pr	ess	То
1	٥	scroll to the charge time option you want
2	SELECT (•)	confirm your selection























## Data and Fax Calls







A Motorola Original™ data kit lets you transfer data between your phone and a computer or other external device. You can:

synchronise data between your phone and an external device with Starfish TrueSync® software, a Motorola accessory product. See the TrueSync user guide for more information.

**Note:** TrueSync software is designed to synchronise with basic features of many popular Personal Information Management (PIM) software and hardware products.

- use your phone as a modem to connect to the Internet
- use your phone to send and receive data and fax calls on your computer or hand-held device.




Connect your phone to an external device (such as a computer or hand-held device) using a serial cable or a USB cable.

**Note:** Not all devices are compatible with infrared, serial cable or USB cable connections. Check your external device for specifications.

#### Set Up a Cable Connection

Attach a serial cable or Motorola Original USB cable to the phone and external device as follows.

Note: Check your computer or hand-held device to determine the type of cable you need.






















### **Data and Fax Calls**

# Attaching a Serial Cable

Use the interchangeable head on the Motorola Multi-Connect Serial Cable to connect a computer, Palm III device, or Palm V device to your phone.

#### Do This

1 Plug the serial cable into the detachable head. Make sure that the Motorola logo on the detachable head and the metal shielding on the serial cable plug are both facing you.








3 Plug the other end of the cable into the serial interface connection on the external device and tighten the screws.





#### Do This

1 Plug the end of the cable with the Motorola logo into your phone's accessory connector port. Make sure that the logo and the phone are both facing you.



2 Plug the other end - the USB connection - into the USB port on the external device.



#### Install the Software

Install the software from the CD-ROM that comes with your Motorola Original data kit. See the data kit's user guide for more information.




## Sending a Data or Fax Call

You can connect your phone to a computer or hand-held device to send data or a fax from the connected device.

Use this feature to transfer data from your computer onto another device, and to synchronise phonebook and datebook information between your phone, computer, and/or hand-held device









## Data and Fax Calls



Connect your phone (see "Connecting Your Phone to an External Device" on page 151) and do the following:

Do 1	• This Check the phone	<b>To</b> make sure that the phone is connected and powered on
2	Open the application on your computer	place the call through the application (such as dial-up-networking or fax) <b>Note:</b> You cannot dial data or fax numbers through your phone's keypad. You must dial them through your computer.
3	End the transfer on your computer	close the call and connection when the transfer is complete

# -

## Receiving a Data or Fax Call

You can connect your phone to a computer or hand-held device to receive data or a fax.

Use this feature to transfer data to your computer from another device.


#### Transfer the Data or Fax

Connect your phone (see "Connecting Your Phone to an External Device" on page 151).

Your phone notifies you when the data or fax call arrives, and transfers the call to the connected device. You must use the application running on the connected device to answer the call.











### **Data and Fax Calls**



End the Data/Fax Connection

When the data or fax transfer is complete: **Do This To** 


End the call from the close the connection connected device

## Sending a Talk then Fax Call

You can place a call where you talk and then send a fax to the same phone number within the same call.

Connect to the device that will send the fax (see "Connecting Your Phone to an External Device" on page 151) and do the following:

Press		То
1	keypad keys	enter the phone number for the call
2	•	open the Dialling Menu
3	<b>₽</b>	scroll to Talk Then Fax
4	SELECT (•)	select Talk Then Fax (for the next call only)
5	0	dial the call
		Speak and, when ready, initiate the fax transfer on the connected device.
		When transfer is complete, end the call from the connected device.










155











## Security



Your phone's four-digit unlock code is originally set to 1234, and the six-digit security code is originally set to 000000 at the factory. Your service provider may reset these numbers before you receive your phone.

If your service provider has not reset these numbers, we recommend that you change them to prevent other users from accessing your personal information or modifying your phone settings. The unlock code must contain four digits, and the security code must contain six digits. Be sure to make a note of the new numbers.



- Your service provider may retain your phone's security code for customer service purposes. In this case, you will not be able to use phone features that require you to enter the security code (such as master clear, master reset, and the unlock code bypass feature).
- If the only password you can change is the unlock code, the New Passwords menu is unavailable and the Unlock Code option appears on the Phone Lock menu. In this case, open the unlock code editor by selecting: ● > Settings > Security > Phone Lock > Unlock Code.

To change a code or password:

**Find the Feature** 

Settings > Security > New Passwords















	Security		
Pr	ess	To To	
1	©	scroll to the code or password you want to change	
2	CHANGE (•)	select the code or password	
3	keypad keys	enter your old code	
		If you do not know your code, see "If You Forget a Code or Password" on page 157.	
4	OK (•)	submit your old code	
5	keypad keys	enter the new code	
6	OK (•)	assign the new code	
7	keypad keys	re-enter the new code	
8	0K (•)	confirm the new code	

## If You Forget a Code or Password

If you forget your security code (originally set to 000000), SIM PIN, SIM PIN2, or call barring password, contact your service provider.

If you forget your unlock code, try entering 1234 or the last four digits of your phone number. If that does not work, do the following when you see the **Enter Unlock Code** message:

Pr	ess	То
1	•	go to the unlock code bypass screen
2	keypad keys	enter your security code
3	0K ( <b>o</b> )	submit your security code













## **Locking and Unlocking Your Phone**

You can lock your phone manually or set your phone to lock automatically whenever you turn it off.

When you try to use a locked phone, it asks you to enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, *but you must unlock it to answer*.

You can make emergency calls on your phone even when it is locked. See "Dialling an Emergency Number" on page 40.

### Lock Your Phone Manually

Fi	nd the Feature	● > Settings > Security > Phone Lock > Lock Now
Press		То
1	keypad keys	enter your four-digit unlock code
2	0K (•)	lock the phone

#### Set Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off:

Find the Feature	> Settings > Security
	> Phone Lock > Automatic Lock
	> On

Pr	ess	То
1	keypad keys	enter your four-digit unlock code
2	OK (•)	set the phone to lock automatically
158		



















## Security





#### **Unlock Your Phone**

At the Enter Unlock Code prompt:

Press		То
1	keypad keys	enter your four-digit unlock code
		The unlock code is originally set to 1234. If necessary, see "If You Forget a Code or Password" on page 157.
2	0K (•)	unlock your phone

## **Barring Calls**





Call barring lets you restrict outgoing or incoming calls. You can restrict all calls, calls to international numbers, or calls while roaming.



**Find the Feature** 

● > Settings > Security > Call Barring

Press		То
1	٧	scroll to Outgoing or Incoming calls
2	CHANGE (●)	select barring for Outgoing or Incoming calls
3	Ç	scroll to a restriction for the barred calls
4	SELECT (●)	select the restriction for the barred calls
5	keypad keys	enter your call barring password
		4-0



















Press	То
6 OK ( <b>○</b> )	submit your password

## **Protecting the SIM Card**

Your PIN (Personal Identification Number) code protects the information stored on your SIM card. When the SIM PIN feature is activated, you must enter your SIM card PIN code each time you turn on the phone or insert a SIM card. Your SIM card PIN code is given to you by your service provider.


Find the Feature	<b>●</b> > Settings > Security
	> SIM PIN

Press		То
1	Ç	scroll to <b>On</b> or <b>Off</b>
2	SELECT (●)	switch protection on or off
3	keypad keys	enter your SIM card PIN code
4	0K (•)	submit your code

#### Unblock the SIM Card PIN Code

If you enter an incorrect SIM card PIN code three times in a row, your SIM card is disabled and your phone displays the message **SIM Blocked**. You need to enter a PIN unblocking key (PUK) code, which you can obtain from your service provider.

















## Accessories



The use of non-original accessories may damage your phone or your other accessories and invalidate your warranty. Use Motorola Original accessories for optimal performance.

#### Coloured covers

Full range of coloured covers available in triple packs to personalise the phone. Fashionable removable snap-on covers in hard plastic materials. More covers available through local or regional licence partners.








#### 500 mAh Lithium Battery - BLM8050 (Silver) & BLM8051 (Blue)


Performance: up to 5 full days standby time or 3 hours of talk time (depending on network and SIM card configuration).

#### 1000 mAh Lithium Battery - BLM8100 (Silver) & **BLM8101** (Blue)


Performance: up to 10 full days standby time or 4.5 hours of talk time (depending on network and SIM card configuration).


















#### Accessories



## Chargers

#### Mini Travel Charger - CHA8000

Small, compact and light, true pocket sized charger. Both Euro & UK plugs included. Powers and rapid charges your phone. Charge time from 2 to 4 hours according to battery technology and capacity.

#### **Desktop Charger – CHA8300**

Holds and rapid charges your phone and one additional battery. For EP+ batteries. To be used with a Motorola travel charger. Charge time from 2 to 4 hours according to battery technology and capacity.

#### In-car Charger – CLA8000

The in-car charger connects to your phone and allows you to charge your phone's battery while driving. When the phone is in use, the in-car charger overrides the battery, therefore preserving battery life. Charge time from 90 minutes to 3 hours according to battery technology and capacity.



To communicate hands-free in all situations, in your car, on the street, at home or in your office.

#### Standard Mono Headset - HSK8000

Simple headset solution including quality ear-piece and microphone with send/end button to answer and terminate calls as well as to call the last number dialled.

#### Headset with Whip Microphone - HSK7500

Performance professional boom microphone headset featuring improved audio with noise cancellation.

### FM Radio Stereo Headset – HFM8000

FM radio with volume control and quality hands-free ear-pieces and microphone with smart button to answer and terminate calls as well as to call the last number dialled.



























### **Accessories**

# •

#### Car Kits

#### Easy Install HF Car Kit - HFK8000

Easy Install portable hands-free car kit for maximum flexibility. Integrated 3-watt speaker and microphone for ultimate full duplex audio performance.

#### **Data Kits**

Connects your computer to your cellular phone to send and receive fax/data (subscription to data services required) and Short Message Service (SMS) over the GSM cellular networks. TrueSync<sup>TM</sup> synchronisation software included for easy phone book management. Software included to access email accounts and the Internet. CD-ROM compatible with Windows 98/2000/ME.



#### Multi Connect Data Kit – PCC8000


Connect your Motorola mobile telephone directly to your compatible PC's serial port. Optional cables available to connect your PDA (Personal Digital Assistant).

#### USB Data Kit- PCC8500

Connect your Motorola mobile telephone directly to your compatible PC's USB port.


















# **Troubleshooting**





Check these questions first if you have problems with your phone:

Question	Answer
Is your battery charged? Do you see ☐ in the display?	The battery level indicator should have at least one segment showing (□→). If it does not, recharge your battery. (See "Charging the Battery" on page 27 and "Battery Use" on page 36.)
Is the phone set to the proper frequency for your geographical region?	Phones in different regions of the world use different frequencies to establish a network connection. If necessary, use the <b>Network</b> feature (see page 77) to reset your phone's frequency to either 1900 MHz or 900/1800 MHz when you travel to a new location.
Do you have a valid SIM card inserted in your phone?	If necessary, turn off your phone and make sure that you have inserted a valid SIM card. (See "Installing the SIM Card" on page 24.)
Does the handset have a signal? Do you see P in the display?	The signal strength indicator should have at least one segment showing (2). If it does not, move to an area with a stronger signal to use your phone.
Is the earpiece volume too low?	While on a call, press the upper volume key on the side of your phone.















# Troubleshooting


Question	Answer
Is the other party unable to hear you?	Your phone may be muted. Press UNMUTE (●) if necessary to unmute the phone.
	Also, make sure that your phone's microphone is not blocked by its carrying case or a sticker.
Has the phone been damaged, dropped, or got wet?	Dropping your phone, getting it wet, or using a non-Motorola battery or battery charger can damage the phone. The phone's limited warranty does not cover liquid damage or damage caused from using non-Motorola accessories.
Was a non-Motorola battery or battery charger used?	





The following refer to specific problems:


Problem	Solution
My phone was stolen. To whom should I report this?	Report a stolen phone to the police and to your service provider (the company that sends you your monthly wireless service bill).
I forgot my password.	See "If You Forget a Code or Password" on page 157.


















Problem	Solution
I pressed the power key, but nothing happened.	Be sure to press and hold (the power key) until the display appears and you hear an audible alert (this could take a couple of seconds). If nothing happens, check that a charged battery is installed. (See "Installing the Battery" on page 26.)
The display says: Insert SIM Card or Check SIM Card even though I	The SIM card may be incorrectly inserted. Check the SIM card to make sure that it is inserted properly. See "Installing the SIM Card" on page 24.
have inserted my SIM card in the phone.	<b>Note:</b> Be sure to turn your phone off and then back on after you re-insert the SIM card.
The display says: SIM Blocked. How do I unblock my SIM card?	Call your service provider (the company that sends you your monthly wireless service bill) to obtain the PIN unblocking key (PUK) code. See "Unblock the SIM Card PIN Code" on page 160.
The display says: Enter Unlock Code. How do I unlock my phone?	Enter the factory-preset unlock code (1234), or the last four digits of your phone number. (See "Locking and Unlocking Your Phone" on page 158.) If this fails, call your service provider (the company that sends you your monthly wireless service bill).









Problem	Solution
My phone asks for an unlock code when I try to open a feature.	The application you want is locked. If you own the phone but do not know the unlock code, see "If You Forget a Code or Password" on page 157.
My phone does not ring.	If you see ﷺ or ﷺ in the display, then the ringer is turned off. See "Ring/Vibrate" on page 137.
	Also, the ringer may be set to <b>Silent</b> even though your phone is set to a ring alert profile. See "Customise an Alert Profile" on page 138.
My phone rings even though I selected the Silent (or Vibrate) alert profile.	The ringer may be set to play a tone even though your phone is set to a silent alert profile. See "Customise an Alert Profile" on page 138.
I tried to place a call and heard an alternating high/ low tone.	Your call did not reach the wireless system. You may have dialled the number too soon after turning the phone on. Wait until the display shows the name of your service provider before making a call.




















|--|

Problem	Solution
I cannot make/ receive calls.	Make sure that you have a phone signal (see the "Signal Strength Indicator" item on page 32). Avoid electrical or radio interference, and obstructions such as bridges, parking garages, or tall buildings.
	Your phone also may have the Call Barring feature turned on. If you know the unlock code, you can change this setting in the security menu (● > Settings > Security).
	Also, check to be sure your SIM card is installed and working.
My phone has poor reception	Make sure that your antenna is not bent or damaged.
and drops calls.	Also, make sure you have a phone signal (see the "Signal Strength Indicator" item on page 32). Stay clear of any obstructions such as bridges, car parks, or tall buildings.
I cannot hear others on my phone.	While on a call, press the upper volume key on the left side of your phone. Your phone display should show the volume increasing.
	Also, make sure that your phone's earpiece is not blocked by its carrying case.
I cannot open my inbox.	Before you can use text or information services messages, you must set up the appropriate inbox. See "Setting Up the Text Message Inbox" on page 110.















Problem	Solution
How do I see the calls I made or received?	To see the most recent calls you dialled or received, open the "Recent Calls" lists:
	⇒ Recent Calls > Received Calls or Dialled Calls
My phone will not send voicemail commands, passwords, or other codes.	Your phone sends commands and passwords as DTMF tones. You can set your phone's DTMF tones to be <b>Long</b> , <b>Short</b> , or <b>Off</b> . If you have trouble sending numbers, check your DTMF setting.
	<b>1</b> From the idle display, press:
	<ul><li>Settings</li><li>&gt; Other Settings</li><li>&gt; Initial Setup</li><li>&gt; DTMF</li></ul>
	2 Press to scroll to Long or Short.
	<b>3</b> Press <b>SELECT</b> ( <b>●</b> ) to select it.
My phone's display is too dark.	You can use the <b>Contrast Setting</b> feature (see page 76) to change the level of contrast in your phone display.
	You can also use the <b>Backlight</b> feature (see page 75) to change the length of time that your phone's display backlight stays on, or to change the display's backlight colour.










<b>D</b> 11	
Problem	Solution
My battery didn't last as long as I expected. What can I do to extend battery life?	Your battery's performance is affected by charge time, feature use, temperature changes, and other factors. For tips on extending your battery life, see "Battery Use" on page 36.
I am unable to record a voice note, voice name, or voice shortcut	Try moving to a quieter location to make your voice recording. Hold the phone about four inches (10 centimetres) away from your mouth, and speak directly into your phone's microphone in a normal tone of voice.
I plugged the data cable into my phone but my phone did not beep. How do I know if the data cable is ready to go?	The beep indicates that you are set up correctly. If you did not hear a beep, make sure that both ends of the data cable are connected - the smaller end to your phone and the larger end to your computer.  Finally, your computer may have deactivated the port to save power. Try opening an application that uses the port, like a fax or dial-up application, and your computer will automatically activate the port.
My phone beeped when I attached the data cable, but my fax and data applications don't work.	Some wireless networks may not support data or fax transmission. If you are roaming on an unfamiliar network, this may be the case.  Also, remember that data and fax transmission usually requires a subscription. Call your service provider for more information.









Problem	Solution
When sending data with the data cable, why does the computer show a connection rate of 19.2 Kbps (19200 bps)?	19.2 Kbps (19200 bps) is the data transfer rate of the connection between your computer and the phone in a standard CSD (Circuit Switch Data) connection. The rate of the connection between your phone and the network is displayed on your phone, and will be either 14.4 or 9.6 Kbps (14400 or 9600 bps).
	<b>Note:</b> A GPRS connection may have a higher data transfer rate.
I can't end my data call by closing the application on my computer. What can I do?	Try pressing on your phone. Also try disconnecting the cable or turning off the phone. If possible, always close the connection through your computer. These alternative methods may disrupt the application on your computer.
I launched the micro-browser but the display says: Service Not Available.	You may be in an area without service, or you may be connected to a network that does not support Internet access.
I launched the micro-browser but the display says: Data Server Unavailable.	Try again in a few minutes. The servers may be temporarily busy.











Accessories 162 accessories optional 9, 105, 123, 148, 151 standard 24 accessory connector port 1 Add Digits feature 80 alert creating 139–144 defined 137 indicators 33, 137 muting 35, 41 reminders 144 type, selecting 138 alert profile customising 138 defined 137 setting 137-138 alert setting indicator defined 33, 137 illustration 32 animation 76 application, locking 73 appointments. See datebook Attach Number feature 44, 80

backlight 75 barring calls 159-160 battery car kit charger time 150 charging 27 extending battery life 34, 36–37, 75, 76, 171 installing 26 level indicator 27, 32, 33 meter 70 blackjack 133–134 block cursor, defined 54 browse text mode 55 browser alerts 67 browser setup micro-browser browser setup 71 browser. See micro-browser

#### С

calculator 129-131 calendar. See datebook adding digits after phone number 80 alert profile, setting 137-138 alert type, selecting 138 alert, creating 139–144 alert, muting 35, 41











automatic redial

using 38-39

turning on/off 75














defined 145 status, checking 146-147 using 145–146 Call Failed message 38 call timers described 82 resetting 83 viewing 83 call waiting activating/deactivating 73 using 47–48 caller ID incoming calls 39 outgoing calls 44, 72, 80 calling card call 45 calling line identification. See caller ID car kit automatic answer 148-149 automatic hands-free 149 charger time 150 power-off delay 149-150 defined 33 illustration 32 codes. See passwords computer connecting to phone 151–153 synchronising data 97, 151 conference call 48 contrast, display 76 cost trackers described 84-85





resetting 85 viewing 85 credit available 70, 84 credit information 70, 84 currency converter 131 cursor 54 customer service, calling 67 customising the menu 147

D data call connecting to external device 151–153 receiving 154–155 sending 153–154 date, setting 75 datebook adding an event 101 alarm 101 calendar 99 changing event information 102 copying an event 103 day view 100 deleting an event 104 event view 100 reminders 101, 144 week view 99 Datebook Menu 99, 100 default passwords 156 deleting a call 78-80 dialled calls list 46, 78-80 dialling a number 29

### Index

Dialling Menu 155 display animation 76 backlight 75 contrast 76 described 31-33 greeting 74 idle display 31 illustration 32 language 76 zoom setting 33-34, 75 diverting calls 145 drafts folder 68 DTMF tones 76, 79, 80, 170

#### Ε

earpiece illustration 1 volume, adjusting 35 emergency number 40 end key functions 1, 29 menu functions 51 ending a call 29 Enter Unlock Code message 157, 159 Entry Method menu 60 event alert 138 exchange rate, calculating 131 external device connecting to phone 151–153

175









factory settings, resetting 76 fax call connecting to external device 151–153 receiving 72, 154–155 sending 72, 153–154 talk then fax call 155 fixed dial activating/deactivating 73 defined 66 dialling numbers 46, 66 editing an entry 66, 91–92 storing an entry 87–89 flashing cursor, defined 54 open to answer call 73 turning the phone on 27 FM Stereo Radio Headset 67,

105-107, 123

4-way navigation keys 1, 36,

frequency, changing 77, 165

games 132-136 **GPRS** indicator defined 33 displayed 127 GPRS, defined 127 greeting, display 74

### Н

hands-free mode automatic answer 148-149 automatic call routing 149 charger time 150 defined 148 power-off delay 149-150 headset automatic answer 148-149 FM Stereo Radio Headset 67, 105–107, 123 headset jack 1 Hide ID feature 44, 80 hold a call 50

idle display, defined 31 ignoring a call 41 in use indicator defined 32 illustration 32 inbox, text message 110-111 in-call timer 71–72 incoming call cancelling 41 ignoring 41 terminating 41 Incoming Call message 39 indicators alert setting 32, 33, 137 battery level 27, 32, 33 GPRS 33, 127 in use 32











ring alert 33, 137
roam 32
signal strength 32
silent alort 33, 137
Last Calls Me
opening 79
options 79
left coff key

silent alert 33, 137 left soft key
vibrate alert 33, 137 customising 14

voice message waiting 32 voice name 86 lo international access code 44

iTAP software
activating 60

capitalisation 63 deleting text 64 entering numbers 64 entering words 61–63

punctuation 63

#### K

key
end 1, 29, 51
4-way navigation 1, 36, 51
left soft key 1, 51, 147–148
menu 1, 30, 51
power 1, 28
right soft key 1, 51,
147–148
send 1, 29, 30, 78
smart 1, 35–36
voice 1, 90, 121
volume control 1, 35, 51
keypad

answering calls 73

volume, setting 138

language, setting 76

Last Calls Menu
opening 79
options 79–80
left soft key
customising 147–148
functions 1, 51
lock
applications 73
phone 158–159
SIM card 160
voice notes 125
lock application feature 73
loud ring alert 33, 137

#### М

making a call 29 master clear 76 master reset 76 menu

Browser Menu 128
customising 147
Datebook Menu 99, 100
Dialling Menu 155
entering text 53–54, 55–64
Entry Method menu 60
features 65–77
language, setting 76
Last Calls Menu 79–80
lists 52–53
locking applications 73
My Tones Menu 142, 144

177

navigating 9, 36, 51–52 **Phonebook Menu** 86

rearranging features 147

Text Msg Menu 113-114

using features 9, 52–54

Voice Notes Menu 122,

123, 124

scroll feature 75

menu indicator

message

defined 31, 33

illustration 32

menu key 1, 30, 51

browser alert 67

deleting 112-114

reading 112-114

144

sending 44, 114-116

voicemail 108-109

message waiting indicator

receiving 112

status 116

defined 32

illustration 32 micro-browser

browser alerts 67

Browser Menu 128

dialling number from 43 drafts folder 68

inbox setup 110–111 locking 112-114 outbox 68, 116


reminders, text message

112, 144

reminders, voicemail 108,







'n' character 45 network settings 77, 165 notepad defined 40-41 entering digits 40-41 retrieving digits 81 number, viewing your own 30, 50, 70 numeric text mode 55

#### 0

1-touch dial defined 42 setting preference 75, 98




















outbox 68, 116 paddleball 136 passwords changing 156 default 156 if you forget a password 1<u>5</u>7 pause character 45 phone accessories, optional 9 accessories, standard 24 active phone line, changing alert, muting 35, 41 answer options 73 connecting to external device 151–153 credit available 70, 84 credit information 70 credit limit 72 date, setting 75 erase user-entered information 76feature specifications 71 flip 27 frequency, changing 77, 165 keypad, answering calls with 73 language, setting 76

locking 158–159 network settings 77, 165 1-touch dial 42 passwords 156, 157 reset all options 76 security code 157 specifications 71 speed dial, using 42 startup greeting 74 time, setting 75 turning on/off 28 unlock code 157 unlocking 28, 158–159 voice dial 46 phone number adding digits after 80 attaching to prefix digits 44 attaching two numbers 80 international access code, dialling 44 redialling 38 sending text message to 44 storing in phonebook 87–89 viewing your own 30, 50, 70 voice dial 46 phonebook attaching two numbers 80 capacity, checking 96-97 copying entries 93–96 deleting an entry 92-93 dialling a number 90-91

editing an entry 91–92

entry name 86

fields 86









number type indicator 86 1-touch dial 42 Q quick dial phone number 86 prefix digits, inserting 44 sorting entries 97–98 using 67 speed dial number 42, 86, 88-89 speed dial, using 42 storing an entry 87-89 synchronising entries 97, 151 voice name entry 89-90 voice name indicator 86 redial Phonebook Menu 86 PIN code reminders activating/deactivating 160 defined 160 protecting the SIM card 160 unblocking 160–161 PIN2 code 66 power key 1, 28 predictive text entry activating 60 capitalisation 63 ring alert deleting text 64 entering numbers 64 entering words 61–63 punctuation 63 profile customising 138 defined 137 setting 137–138 PUK code 160 ringer setting 137-138

setting number 75


radio 105-107 received calls list 46, 78-80 receiving a call 30 recent calls 78-80 automatic redial 38-39 busy number 38 datebook 101 setting 144 text message 112, 144 voicemail message 108, 144 right soft key customising 147-148 functions 1, 51 creating 139-144 indicators 33, 137 muting 35, 41 setting 137–138 type, selecting 138 ring and vibrate alert indicator 33, 137 muting 35, 41











S Safety and General Information 10 scroll feature 75 security code 157 send key 1, 29, 30, 78 sending a call 29 service dial defined 66 dialling numbers 46 short message service. See text message shortcuts creating 118–119 standard 117 using 120 Show ID feature 44, 80 signal strength indicator defined 32 illustration 32 silent alert indicator 33, 137 SIM applications 68 SIM Blocked message 28, 160 SIM card applications 68 defined 24

installing 24–25 PIN code entry 28 precautions 24 protecting 160 service phone numbers 66 SIM Blocked message 28, 160 SIM Disabled message 161 unblocking 160-161 unlocking 28 SIM Disabled message 161 SIM PIN code activating/deactivating 160 protecting the SIM card 160 unblocking 160–161 SIM PIN2 code 66 smart key customising 147–148 defined 35–36 functions 35-36 illustration 1 SMS. See text message soft keys customising 147-148 functions 51 illustration 1 soft ring alert 33, 137 speed dial changing number 88-89 number, defined 42 sorting phonebook entries by 97 using 42

standby time


defined 34

181









talk and fax call 72 talk then fax call 155 tap method text entry 56-58 telephone number, viewing your own 30, 50, 70

block cursor 54 browse mode 55 character chart 58 entering from keypad 55–64 entry mode, changing 55 flashing cursor 54 iTAP software predictive text entry 60-64 numeric mode 55 symbol chart 60 symbol mode 59–60 tap method 56–58 text message deleting 112-114 dialling number from 43

inbox setup 110–111 locking 112–114 reading 112-114

receiving 112

182

reminders 112, 144 sending 44, 114–116 status 116 text mode, changing 55 Text Msg Menu opening 113 options 113–114 time, setting 75 timers described 82 resetting 83 viewing 83 Total Customer Satisfaction 18 transfer a call 49-50 travel charger, using 27 TrueSync 97, 151

#### U

unblocking the SIM card 160–161 phone 158-159 unlock code 157

vibrate alert indicator 33, 137 muting 35, 41 setting 137–138 type, selecting 138 voice dial dialling a number 46, 91













