


# ZTE Quick start guide



## LEGAL INFORMATION

Copyright © 2011 ZTE CORPORATION

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

Version No.: R1.0  
Edition Time : 20110408  
Manual No. : 079584503655

## Product Safety Information



For more information, please read the user manual stored in the preinstalled microSD card.

	Read the Safety Information section of this Quick Start Guide on this page		Do not use while re-fueling
	Do not use hand-held while driving		This device may produce a bright or flashing light
	For body-worn operation maintain a separation of 15 mm		Do not dispose of it in a fire
	Small parts may cause a choking hazard		Avoid contact with magnetic media
	This device may produce a loud sound		Avoid Extreme Temperatures
	Keep away from pacemakers and other personal medical devices		Avoid any contact with liquid, keep it dry
	Switch off when instructed in hospitals and medical facilities		Do not attempt to disassemble
	Switch off when instructed in aircrafts and airports		Do not rely on this device for emergency communications
	Switch off in explosive environments		Only use approved accessories

## Notes:

microSD logo is a trademark of the SD Card Association.

## Getting to know your phone



### Power Key

- Hold to select phone modes: Silent, Vibration, Airplane, or to power off.
- Press to switch your phone to Sleep mode.
- Press to wake up your phone.

### Home Key


- Press to return to the Home Screen from any application or screen.
- Hold to see recently used applications.

### Menu Key

Press to get the options on the current screen.

### Back Key

Press to go to the previous screen.



**ZTE**

**ZTE CORPORATION**

NO. 55, Hi-Tech Road South, ShenZhen, P.R.China

Postcode: 518057

<http://www.zte.com.cn> [mobile@zte.com.cn](mailto:mobile@zte.com.cn)

Service Hotline: +44(0)20 3450 8722, 0800 783 0094

The information on the package is only for your reference. Images are for your reference only. Please check the product model before purchasing. ZTE reserves the rights to change specifications and parameters of the products without further notice.

#### Volume Key (Volume +/-)


Press higher end of the key to turn the volume up and the lower end of the key to turn it down.

#### Before getting started


##### Removing the back cover




##### Installing the SIM card




#### Installing the memory card



#### Installing the battery



#### Charging the battery



When you first get your new phone you'll need to charge the battery like this...

1. Connect the adapter to the charger jack.
2. Connect the charger to a standard AC wall outlet.
3. Disconnect the charger when the battery is fully charged.

#### Powering on/off your phone

1. Make sure the SIM is in your device and the battery is charged.
2. Hold **Power Key** to switch on your phone.
3. To switch it off, hold **Power Key** to get the phone options. Select **Power off**, and then tap **OK**.


#### Switching to sleep mode

To save battery power, Sleep Mode suspends your device to a low-power-consumption state while the display is off. Your device also goes into Sleep Mode automatically when the display is automatically turned off after a certain period of time, which you can set in **Screen timeout** of the display settings.

Press **Power Key** to switch to Sleep Mode.

#### Waking up your phone

If your phone is in Sleep Mode, you can wake it up by...

1. Pressing **Power Key** to activate your screen display.
2. Drag the  icon to the right.

#### Notes:

If you have set an 'unlock pattern', a PIN, or a password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock the screen.