



Display Icons

Service Icons

	Signal Strength – Your phone's current signal strength. (More bars = stronger signal.)
	No Service – Your phone cannot find a usable signal.
	Roaming – Your phone is "roaming" off the Boost Mobile network.
	Data Service – Data service is available. When active, the icon is animated.
	Data Service Dormant – Data service is currently dormant.
	Data Service Unavailable – Data Service is currently unavailable.

Status Icons

	Battery – Your phone's current battery charge level. (The icon to the left shows the battery is fully charged.) The icon is animated while the battery is charging.
	Location On – Your phone's location feature is on and available for location-based services such as GPS Navigation.
	Location Off – Your phone's location feature is off. Your location is available only for 911.
	Silence All – Your phone's sound is turned off.
	Vibrate All – Your phone's sound is turned off but vibrate is turned on.
	Ringer Off – Your phone's ringer is turned off.
	1 Beep – A beep sounds when you receive an incoming call, a message, etc.
	1 Beep and Vibrate – 1 Beep and vibrate are set.
	Ringer and Vibrate – The volume level is set to between 1 and 8 and vibrate is turned on.
	Speaker Mode – Your phone is in speaker mode.

Messaging Icons

	Email – You have new email message(s) waiting.
	Picture Messages – You have new picture message(s) waiting.
	SMS Voice Messages – You have new SMS voice message(s) waiting.
	Text Messages – You have new text message(s) waiting.
	Voicemail – You have new voicemail message(s) waiting.
	Urgent Messages – You have new urgent message(s) waiting.
	Multiple Messages – You have two or more different types of new messages waiting.

Bluetooth Icons

	Visible – Your phone is discoverable by (visible to) other Bluetooth devices.*
	Connected – Your phone is connected to a Bluetooth device.*
	Enable – Your phone's Bluetooth feature is enabled.*

Voice Call Icons

	Missed Call – You have missed voice calls.
	Bluetooth Device – A call is in progress using a Bluetooth device.
	Headset – A call is in progress using an optional wired headset.
	Car Kit – A call is in progress using an optional car kit device.

Others

	TTY – Your phone is connected to a TTY device.
	Alarm Clock – Alarm clock or countdown is set.
	Notification – You have events, call reminders, alarm clock, or countdown notification(s).
	HAC Enabled – Your phone's HAC setting is enabled.

* Icon will blink while your phone is communicating with a Bluetooth device.

Technical Specifications

Talk Time

Up to 4.8 hours

Screen Resolution

Main: 2.2", 320 x 240 pixels, 65K-color QVGA

Chipset

QSC6055

Banding

1xRTT, dual-band (800, 1900 MHz)

Size

4.3 x 2.4 x 0.6 in (109.7 x 59.8 x 14.9 mm)

Weight

3.4 ounces (96 grams)

Battery Type

SANYO 840 mAh Lithium Ion battery

Bluetooth® (version 2.0)

Profiles:

- SPP, GOEP (General)
- HSP (Headsets)
- HFP 1.5 (Hands-free car kits)
- OPP (vCard transfer)
- DUN (Dial-up networking)
- BPP (Bluetooth Printing)
- PBAP (Phone Book Access)

Product Training

www.kyocera-wireless.com/iteachu

Product Information

www.sanyowireless.com

Consumer Support

1-866-726-9692

phone-help@kyocera-wireless.com

Kyocera Communications, Inc.

10300 Campus Point Drive, San Diego, CA 92121

USA 1-800-349-4188, Outside USA +1-858-882-1400



© Kyocera Communications, Inc. (KCI), a wholly-owned subsidiary of Kyocera International, Inc. All rights reserved. SANYO is a registered trademark of SANYO Electric Co., Ltd. and is used under license. Sprint and other trademarks are the trademarks of Sprint. The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Kyocera Communications, Inc., is under license. Other trademarks and trade names are those of their respective owners. Because its products are subject to continuous improvements, KCI reserves the right to modify design, features and specifications without notice. Certain features may require optional services and may involve additional charges. Screen images are simulated.

Printed in USA 7/09
Part #: TMM001847-1



Juno™ SCP2700



Kyocera manufactures and markets the SANYO wireless line of products.

www.kyocera-wireless.com/iteachu



Make A Statement Without Saying A Word.

A full QWERTY keyboard with an easy-to-use menu, the Juno™ SCP2700 makes texting, emailing and chatting a snap. Staying connected has never been so easy.


Messaging
Threaded text messaging
Multimedia Messaging Service (MMS)
Mobile Email capable
Instant messaging
Camera
1.3 megapixel camera with digital zoom
Picture sharing capable
Web & Tools
Mobile web (WAP 2.0) – download ringers, games and screen savers
GPS Navigation capable
Bluetooth® wireless technology
Restrict and Lock – great for parents and business owners
Voice memo recorder
Phone as Modem capable
Alarm clock, calendar, to do list, calculator, stopwatch, countdown timer, world clock
Additional Features
2.2", 65K-color QVGA LCD display
Speakerphone with dedicated access key
Speaker-independent voice-activated dialing
Caller ID capable (Number/Picture/Ringer)
Vibrating alerts (4 types)
Micro USB connector – supports power and data connectivity
Bilingual user interface – English and Spanish supported
TTY capable
Hearing aid compatible (M4/T4 rating)

1	Earpiece Earpiece lets you hear the caller and automated prompts.	11	END/POWER key Lets you turn the phone on or off, end a call, or cancel your input and return to standby mode.
2	Display Screen Display Screen displays all the information needed to operate your phone, such as the call status, the Contacts list, the date and time, and the signal and battery strength.	12	Back key Deletes characters from the display in text input mode. When in a menu, pressing it returns you to the previous menu. This key also allows you to return to the previous screen in a data session.
3	MENU/OK key Lets you access the phone's menus and selects the highlighted choice when navigating through a menu.	13	QWERTY keyboard Lets you enter numbers, letters, and characters, and perform functions with single key press or combined key presses.
4	TALK key Allows you to place or receive calls, answer Call Waiting, use Three-Way Calling, or activate Automatic Speech Recognition (ASR).	14	Battery Release Latch Lets you open the battery cover to replace the battery.
5	TEXT key Lets you access the text message entry screen.	15	.com key
6	Navigation key Scrolls through the phone's menu options and acts as a shortcut key from standby mode. These keys can be reassigned to create customized shortcuts.	16	Internal Antenna Facilitates reception and transmission. To maximize performance, do not obstruct the internal antenna while communicating.
7	Microphone Allows other callers to hear you clearly when you are speaking to them.	17	Volume Button Allows you to adjust the ringer volume in standby mode or the voice volume during a call. The volume button can also be used to scroll up or down to navigate through the different menu options.
8	Camera Lens Camera Lens, as part of the built-in camera, lets you take pictures.	18	Camera Button Lets you open the Photos menu. Press and hold to activate the camera mode and take pictures.
9	Speaker Lets you hear the different ringers and sounds. You can mute the ringer when receiving incoming calls by pressing [BACK] or side buttons. The speaker also lets you hear the caller's voice in speakerphone mode.	19	Micro-USB Connector Allows you to connect a charging cable or optional USB data cable.
10	Softkeys Lets you select softkey actions or menu items corresponding to the bottom left and right lines on the screen.	20	Headset Jack Allows you to plug in an optional headset for convenient, hands-free conversations.




Mobile Email

The SCP2700 supports “push” email from popular sites such as Yahoo!, Google, AOL, MSN as well as IMAP/POP3 accounts. Also stay up-to speed with work email if you have either a Microsoft Exchange or Lotus Domino corporate email server.



GPS Navigation Capable

The SCP2700 offers easy access to GPS Navigation right from the main menu. GPS Navigation is an optional application that can be downloaded. It provides audio and visual turn-by-turn directions with full color moving maps.



Threaded Text Messaging

Easily follow a chain of text messages to and from a particular contact, in reverse chronological order.

How to view threaded text messages

1. To display the thread list from standby mode, press MESSAGES (left soft key) > Text Messages
2. Highlighting a thread shows the first few words of the most recent message in that thread.
3. Press to view the highlighted thread.
4. Press to view the highlighted messages detail's, including date and time of the message.

Bluetooth

Supports wireless headsets, hands-free car kits, wireless printing, dial-up networking (Phone as modem) and vCard transfer.

How to Pair a Bluetooth Device

1. Press > Tools > Bluetooth.
2. Highlight an option and press .
 - Handsfree Pairing to find a headset or hands-free device.
 - Add to Trusted to find a device per device type. Select a device type to be searched.
 - Trusted List to find all device types. Select Add New to start searching.
3. Highlight a device and press .
4. Enter the passkey and press . When the owner of the other device enters the same passkey, the pairing is complete.

Restrict and Lock

With easy access under Settings menu, parents and business owners can:

- Restrict incoming and/or outgoing calls
- Lock or unlock data services
- Input up to 3 “special numbers” that are always available
- Lock contact list
- Lock camera and any pictures that are saved in the phone

How to use Restrict and Lock

1. From the Main Menu go to Settings > More... > Restrict and Lock.
2. Select Voice and enter your lock code.
3. Restrict > Outgoing Calls or Incoming Calls.
4. Select Allow All, Contacts Only, or Special #s Only.

Auto Key Guard

The auto key guard will lock keys automatically after one minute or once the sleep mode time elapses (options for sleep mode: Off, 5, 30 or 60 seconds). To unlock keys press [Space] and then [Back]. To manually lock the keys, press and hold [Back].

How to disable the Auto Key Guard

1. Press > Settings > More... > Auto Key Guard
2. Select off

Menu & Submenu Items

1: Missed Alerts	2: History	3: Maps <ol style="list-style-type: none">1. Navigation2. Family Locator	4: Web
5: Messages <ol style="list-style-type: none">1. Voicemail<ol style="list-style-type: none">1. Call Voicemail2. Details3. Reset Indicator2. Send Message<ol style="list-style-type: none">1. Text Message2. Picture Mail3. Email4. IM5. Voice SMS3. Text Messages4. Picture Mail5. Email6. IM7. Chat & Dating8. Voice SMS9. Settings<ol style="list-style-type: none">1. Notification2. Callback Number3. Signature4. Preset Messages5. Voice SMS Options	6: Contacts	7: Photos <ol style="list-style-type: none">1. Camera - Press the right soft key for the following options:<ol style="list-style-type: none">1. Picture Mode2. Zoom3. Self-Timer4. Fun Tools5. Image Controls6. Camera Settings7. Review Media8. Key Guidance9. User Settings2. Picture Mail3. My Albums<ol style="list-style-type: none">1. In Phone2. Online Albums4. PictBridge5. Order Prints6. Settings & Info<ol style="list-style-type: none">1. Location2. Status Bar3. Slideshow Interval4. Account Info5. Help	8: My Stuff <ol style="list-style-type: none">1. Games2. Ringers3. Screen Savers4. Applications5. IM & Email6. Call Tones
9: Shopping	0: Tools <ol style="list-style-type: none">1. Alarm Clock2. Assigned Media3. Bluetooth<ol style="list-style-type: none">1. Handsfree Pairing2. Send Contact3. Print Picture4. Add to Trusted5. Trusted List6. Send Biz Card7. More...4. Calculator5. Calendar6. Countdown7. Stopwatch8. Update Firmware9. Voice Memo<ol style="list-style-type: none">1. Record2. List0. World Clock	*: My Account <ol style="list-style-type: none">1. Account Details2. Hear Minutes3. Hear Balance	#: Settings <ol style="list-style-type: none">1. Display2. Sounds3. Bluetooth4. Messages5. Text Entry6. Phone Info7. More...<ol style="list-style-type: none">1. Accessibility2. Airplane Mode3. Browser4. Call Setup5. Contacts6. Data7. Headset Mode8. Location9. Power On to Alert0. Restrictions and Lock*. Roaming#. Security<ol style="list-style-type: none">Navigation keysAuto Key GuardWireless Backup