

Display Icons

Service Icons	
	Signal Strength – Your phone’s current signal strength. (More bars = stronger signal.)
	No Service – Your phone cannot find a usable signal.
	Roaming – Your phone is “roaming” off the Nationwide Sprint Network.
	Data Service – Sprint 1xRTT data service is available. When active, the icon is animated.
	Data Service Dormant – Data service is currently dormant.
	Data Service Unavailable – Data service is currently unavailable.

Status Icons	
	Battery – Your phone’s current battery charge level. (The icon to the left shows the battery is fully charged.) The icon is animated while the battery is charging.
	Location On – Your phone’s location feature is on and available for location-based services such as GPS Navigation.
	Location Off – Your phone’s location feature is off. Your location is available only for 911.
	Silence All – Your phone’s sound is turned off.
	Vibrate All – Your phone’s sound is turned off but vibrate is turned on.
	Ringer Off – Your phone’s ringer is turned off.
	1 Beep – A beep sounds when you receive an incoming call, a message, etc.
	1 Beep and Vibrate – 1 beep and vibrate are set.
	Ringer and Vibrate – The volume level is set to between 1 and 8 and vibrate is turned on.
	Speaker Mode – Your phone is in speaker mode.

Messaging and Alerts Icons	
	New Messages – You have one or more new messages waiting.
	New Voicemail – You have one or more new voicemail messages waiting.
	Urgent Messages – You have one or more urgent messages (including Commercial Mobile Alert System [CMAS] alert message) waiting.
	Multiple Alerts – You have different kinds of alerts waiting.
	Urgent Multiple Alerts – You have different kinds of alerts (including urgent message) waiting.
	Application Alerts – You have alert messages from Java apps activated in the background.

Bluetooth Icons	
	Visible – Your phone is discoverable by (visible to) other Bluetooth devices.*
	Connected – Your phone is connected to a Bluetooth device.*
	Enable – Your phone’s Bluetooth feature is enabled.*

Voice Call Icons	
	Missed Call – You have one or more missed voice calls.
	Bluetooth Device – A call is in progress using a Bluetooth device.
	Headset – A call is in progress using an optional wired headset.
	Car Kit – A call is in progress using an optional car kit device.

Others	
	TTY – Your phone is connected to a TTY device.
	Alarm Clock – Alarm clock or countdown is set.
	Notification – You have events, call reminders, alarm clock, or countdown notification, or your Contacts list has been backed up to Sprint’s website.
	HAC Enabled – Your phone’s HAC setting is enabled.

\* Icon will blink while your phone is communicating with a Bluetooth device.



Technical Specifications

Talk Time
Up to 5.2 hours

Screen Resolution
Main display: 2.4", QVGA (240 x 320 pixels) TFT LCD, 65K-color
Sub-display: 1.3", glow-thru sub OLED

Chipset
QSC6055

Banding
1xRTT, dual-band digital only (800, 1900 MHz)

Size
3.8 x 2.0 x 0.6 in (96.0 x 52.0 x 16.1 mm)

Weight
3.4 ounces (97 grams)

Battery Type
SANYO 840 mAh Lithium Ion battery

Bluetooth® (version 2.0)
Profiles:
<ul style="list-style-type: none"><li>• SPP, GOEP (General)</li><li>• HSP (Headsets)</li><li>• HFP 1.5 (Hands-free car kits)</li><li>• OPP (vCard transfer)</li><li>• DUN (Dial-up networking)</li><li>• BPP (Bluetooth Printing)</li><li>• PBAP (Phone Book Access)</li></ul>

Product Training  
<http://iteachu.kyocera-wireless.com/sprint>

Product Information  
[www.kyocera-wireless.com](http://www.kyocera-wireless.com)

Consumer Support  
1-800-349-4478  
[phone-help@kyocera-wireless.com](mailto:phone-help@kyocera-wireless.com)

Kyocera Communications, Inc.  
10300 Campus Point Drive, San Diego, CA 92121  
USA 1-800-349-4188, Outside USA +1-858-882-1400



©2010 Kyocera Communications, Inc. (KCI), San Diego, CA, USA. All rights reserved. KYOCERA is a registered trademark of Kyocera Corporation. “SANYO” is a registered trademark of SANYO Electric Co., Ltd. and is used under license. Sprint and other trademarks are the trademarks of Sprint. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are those of their respective owners. Because its products are subject to continuous improvements, KCI reserves the right to modify design, features and specifications without notice. Certain features may require optional services and may involve additional charges. Screen Images are simulated. Not all products may be available in your area.

Use only Kyocera Communications, Inc. approved accessories with the Vero phone. Use of unauthorized accessories may be dangerous and may invalidate the warranty if they cause damage to the phone.

Printed in USA 10/10  
TMM002071-1

SANYO Vero™  
by KYOCERA



Kyocera manufactures and markets the SANYO line of wireless products.  
<http://iteachu.kyocera-wireless.com/sprint>

# Essence of ease.

## Everything you want—and exactly what you need.

Vero™ stays true to simplicity with a sizable screen, large menu fonts, and user-friendly keypad for effortless dialing—plus a 1.3 megapixel camera for snapping shots that are easy to share.

### User-friendly

Big, bright 2.4", QVGA LCD display

Large keypad buttons with easy-to-read numbers

Normal or large font option for menus

Long battery life (up to 5.2 hours)

Speaker-independent voice dialing

Speakerphone with dedicated access key

### Camera

1.3 MP camera with digital zoom

Multimedia Messaging Service (MMS)

### Web & Tools

Mobile web (WAP 2.0) – download ringtones, games and screen savers

Threaded text messaging

Bluetooth® wireless technology

Parental Controls – great for parents and business managers

Sprint Family Locator capable

Voice memo recorder

Alarm clock, calendar, to-do list, calculator, stopwatch, countdown timer, world clock

### Additional Features

Caller ID capable (Number/Picture/Ringer)

Vibrating alerts (4 types)

Micro USB connector

Bilingual user interface – English and Spanish supported

TTY capable

Hearing aid compatible (M4/T4 rating)

## Highlights

### 1 1.3" Exterior Display

Monitor the phone's status icons (like power, signal and battery) plus easily see who is calling without opening the phone.

### 2 Organic Design

Vero's round, comfortable shape and traditional flip design help to provide a straightforward and intuitive user experience. It has been designed for comfort in your hand and fits beautifully when held to your head while making a call.

### 3 Speakerphone

A large back-ported speakerphone is helpful when you need an extra hand.

### 4 Camera

The 1.3 megapixel camera is always ready for action.

### 5 2.4" QVGA Main Display

Vero's interior screen is bright and large, perfect for reading text messages and viewing pictures. Make the font larger and take full advantage of the high resolution and large size.

### 6 One-touch Buttons

Dedicated buttons for camera and speakerphone right on the keypad make these often-used features even easier to access.

### 7 User-friendly Keypad

Well spaced and easy-to-use, Vero's large keypad makes it effortless for all types of users. Oversized numbers are easy to see and allow you to quickly dial or send text messages.


## Larger Keypad and Menus

In addition to the large, easy-to-use keypad with big numbers, Vero allows you to quickly change the size of the font in most of the menus. Default font size is set to Normal, but it's very easy to switch to Large.

Note: Not all applications support the large font option.

### How to quickly change the font size

1. Press [menu/ok] > OPTIONS (right softkey).
2. Select Large Font and press [menu/ok].
3. Same procedure to return to normal font size.



Normal Font

Large Font

## Parental Controls


With easy access under the Settings menu, parents and business managers can:

- > Restrict voice calls and text messages.
- > Lock or unlock web and camera usage.
- > Force GPS to be visible.

### How to use Parental Controls

1. From the Main Menu go to Settings > Parental Controls.
2. Select On/Off > create your lock code.
3. Restriction > Select an option to restrict usage.

Note: For Voice Calls and Text Messages you can select All Contacts or add up to 5 contacts. For Web, Camera and Force GPS, it is only an On or Off option.




## Bluetooth

Supports wireless headsets, hands-free car kits, wireless printing, dial-up networking (Phone as modem) and vCard transfer.

### How to Pair a Bluetooth Device

1. Press [menu/ok] > Tools > Bluetooth.
2. Select Add New.
3. Select the device you wish to pair with and press [menu/ok].
4. Enter the passkey of your device or the other's and press [menu/ok].
5. (optional) Edit the device name and press SAVE (left softkey).




## Camera

Capture the moment with Vero's 1.3 megapixel camera and share instantly with family and friends. It's as easy as sending a text message.

### How to add a picture to a message:

1. From standby mode, press MESSAGING (left softkey) > Send Message.
2. Select a recipient from the list or from the following options:
  - > Go to Contacts to select a recipient from your Contacts.
  - > MULTIPLE (left softkey) to select multiple recipients.
  - > NEW ADDRESS (right softkey) to enter a recipient's phone number or email address directly.
3. Press CONTINUE (left softkey) when you have finished selecting recipients and compose a message.
4. To attach a picture, select <Add Attachment>, and select Picture. > If you select Picture, select Take New Picture or > My Photos.
5. Select files you would like to attach.
6. Review your message and press SEND (left softkey).



## Speaker-independent Voice Dialing

Vero allows use of your phone's built-in Automatic Speech Recognition (ASR) software to dial a phone number or to launch phone functions. All you have to do is to talk into the phone, and ASR will recognize your voice and complete tasks by itself.

### How to Make a Voice Call Using ASR

1. Press and hold "Talk" or "Speaker."
2. When you hear "Say a command," say "Call."
3. When you hear "Say the name or number," say a name or a phone number.
4. When you hear "Which location?," say a number type (for example, "Mobile").

Tip: You can skip steps 3 and 4 by saying a name and location after "Call" without pausing (for example, "Call John Jones mobile").

