

Part List, Mechanical

Applicable for S500, W580

Contents









| | | |
|----------|----------------------------------|-----------|
| 1 | General | 2 |
| | 1.1 View of S500 and W580..... | 2 |
| 2 | S500 and W580 Parts | 3 |
| 3 | Revision History | 17 |











1 General











1.1 View of S500 and W580




















2 S500 and W580 Parts

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|------------------------|-------------|----------|
|  |  | Vibrator | VIBRATOR/ML | BKE90324 | |
|  |  | Camera | Camera (2Mega) | KNC20135/2 | |
|  |  | Bluetooth Antenna | ANTENNA/BLUETOOTH | KRE1011535 | |
|  |  | Bluetooth Antenna Tape | TAPE/BT ANTENNA/KAPTON | SXA1097958 | |







| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|----------------------|-------------|----------|
|  |  | Antenna Assembly | ASSY/ANTENNA ELEMENT | KRE1011536 | |
|  |  | Antenna Coaxial Cable | ANTENNA COAX | SXA1097327 | |
|  |  | Microphone | MICROPHONE | RLC509422/2 | |
|  |  | Microphone Gasket | MICROPHONE GASKET | SXA1097280 | |
|  |  | Receiver | RECEIVER/10mm | RLE90731 | |







| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|----------------------------|-------------|----------|
|  |  | Receiver Gasket | RECEIVER GROMMET | SXA1097275 | |
|  |  | LCD | 2.0 QVGA LCD w/Glass Cover | RNH942223 | |
|  |  | System Connector | System Connector | RNV79935 | |
|  |  | KRH Label | LABEL/KRH | SVF9302621 | |
|  |  | Liquid Intrusion Indicator | Liquid Intrusion Indicator | SXA1094884 | |

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|--|--------------------------------|--------------|----------|
|  |  | Volume Key | KEY/VOLUME | SXA1097341 | |
|  |  | Power Key | KEY/POWER | SXA1097343 | |
|  |  | M1.6 screw with red threadlock (2.7MM in length) | SCREW/M1.6X2.7/Red Threadlock | SXA1097355/1 | |
|  |  | M1.6 screw with blue threadlock (2.7MM in length) | SCREW/M1.6X2.7/Blue Threadlock | SXA1097355/2 | |



| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|-----------------------|-----------------|---------------------------------|
|  |  | Wear Strip (Left) | KYPD WEAR STRIP/LEFT | SXA1097461 | |
|  |  | Wear Strip (Right) | KYPD WEAR STRIP/RIGHT | SXA1097462 | |
|  |  | Bonzer Flex | BONZER FLEX | SXK1097454/1 | M-FLEX/SMK (No Dot) |
| | | | | SXK 109 7454/22 | FUJIKURA/Panasonic (Yellow Dot) |
|  |  | Hinge Assembly | HINGE ASSEMBLY | SXK1097455/1Z | M-Flex/SMK (No Dot) |
| | | | | SXK1097455/12Z | M-Flex/Panasonic (White Dot) |
|  |  | Hinge tape | ESD Battery Area Tape | SXA1344109 | |



| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|----------------------------------|---------------|---------------------------------|
|  |  | Main Keypad Flex | MAIN KEYPAD FLEX | SXK1097466/1 | M-FLEX (No dot or white dot) |
|  |  | Coax Cable Ground Pad | PORON PAD/COAX RSE Ground | SXA1098108 | |
|  |  | Bonzer Flex Tape | 2-sided adhesive tape - 2MMX20MM | SXA1098151 | |
|  |  | Rear Frame - S500 | REAR FRAME | SXA1097321/54 | WHITE |
| | | | | SXA1097321/58 | COPPER |
|  |  | Rear Frame – W580 | REAR FRAME | SXA1097321/57 | DARK BLUE |
| | | | | SXA1097321/55 | WHITE |







| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|---------------------|----------------|------------------|
|  |  | Navigation Keypad – S500 | NAVIGATION KEYPAD | SXA1097340/201 | BLACK |
| | | | | SXA1097340/222 | BLACK/CMCC |
| | | | | SXA1097340/301 | YELLOW |
| | | | | SXA1097340/322 | YELLOW/CMCC |
| | | | | SXA1097340/401 | WHITE |
| | | | | SXA1097340/501 | PURPLE |
|  |  | Navigation Keypad - W580 | KEYPAD/NAVIGATION | SXA1097705/101 | WHITE/GENERIC |
| | | | | SXA1097705/117 | WHITE/ORANGE |
| | | | | SXA1097705/122 | WHITE/CMCC |
| | | | | SXA1097705/201 | GREY |
| | | | | SXA1097705/217 | GREY/ORANGE |
| | | | | SXA1097705/222 | GREY/CMCC |
| | | | | SXA1097705/301 | BLACK |
| | | | | SXA1097705/322 | BLACK/CMCC |
| | | | | SXA1097705/401 | PINK |
| | | | | SXA1097705/417 | PINK/ORANGE |
| | | | | SXA1097705/501 | GREEN |
| | | | | SXA1098104/1 | WHT/AT&T |
| | | | | SXA1098104/2 | GRY/AT&T |
| | | | | SXA1098104/3 | BLK/AT&T |
| | | | | SXA1098104/4 | PINK/AT&T |
| SXA1098104/5 | JGL GREEN/AT&T | | | | |
|  |  | Battery Cover – S500 | BATTERY DOOR | SXA1097360/201 | BLACK SOFT TOUCH |
| | | | | SXA1097360/301 | YELLOW |
| | | | | SXA1097360/401 | WHITE |
| | | | | SXA1097360/501 | PURPLE |





| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|-------------------------------------|---------------------|---------------------|---------------------------|
|  |  | Battery Cover – W580 | BATTERY COVER | SXK1097683/1 | WHITE |
| | | | | SXK1097683/2 | GREY |
| | | | | SXK1097683/3 | BLACK |
| | | | | SXK1097683/4 | PINK |
| | | | | SXK1097683/5 | JGL GREEN |
|  |  | Decorative Chin Cover – S500 | CHIN COVER | SXA1097352/201 | BLACK CLEAR COAT |
| | | | | SXA1097352/301 | YELLOW |
| | | | | SXA1097352/401 | WHITE |
| | | | | SXA1097352/501 | PURPLE |
|  |  | Decorative Chin Cover – W580 | CHIN COVER | SXA1097700/1 | WHITE |
| | | | | SXA1097700/102 | WHITE/WALKMAN |
| | | | | SXA1097700/122 | WHITE/CMCC |
| | | | | SXA1097700/123 | WHITE/TELEFONICA-MOVISTAR |
| | | | | SXA1097700/129 | WHITE/VIRGIN |
| | | | | SXA1097700/131 | WHITE/TIM |
| | | | | SXA1097700/132 | WHITE/ROGERS |
| | | | | SXA1097700/133 | WHITE/T-MOBILE |
| | | | | SXA1097700/2 | GREY |
| | | | | SXA1097700/202 | GREY/WALKMAN |
| | | | | SXA1097700/218 | GREY/O2 |
| | | | | SXA1097700/222 | GREY/CMCC |
| | | | | SXA1097700/223 | GREY/MOVISTAR |
| | | | | SXA1097700/231 | GREY/TIM |
| | | | | SXA1097700/232 | GREY/ROGERS |
| SXA1097700/233 | GREY/T-MOBILE | | | | |
| SXA1097700/3 | BLACK | | | | |
| SXA1097700/302 | BLACK/ WALKMAN | | | | |
| SXA1097700/322 | BLACK/CMCC | | | | |







| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|----------------------------------|---------------------|-----------------------|--------------------------|
| | | | | SXA1097700/4 | PINK |
| | | | | SXA1097700/402 | PINK/WALKMAN |
| | | | | SXA1097700/423 | PINK/TELEFONICA-MOVISTAR |
| | | | | SXA1097700/432 | PINK /ROGERS |
| | | | | SXA1097700/433 | PINK/T-MOBILE |
| | | | | SXA1097700/502 | JGL GREEN/WALKMAN |
|  |  | Memory Stick Cover – S500 | DOOR/M2 MEMORY | SXA1097957/54 | WHITE |
| | | | | SXA1097957/58 | COPPER |
|  |  | Memory Stick Cover – W580 | DOOR/M2 MEMORY | SXA1097957/57 | DK BLUE |
| | | | | SXA1097957/54 | WHITE |
|  |  | Front Frame – S500 | FRONT FRAME CPL | SXK1097453/54 | WHITE |
| | | | | SXK1097453/58 | COPPER |
|  |  | Front Frame – W580 | FRONT FRAME CPL | SXK1097453/57 | DK BLUE |
| | | | | SXK1097453/54 | WHITE |

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|---------------------|----------------|--------------------------------|
|  |  | Numeric Keypad – S500 | NUMERIC KEYPAD | SXA1097787/201 | GRN KEYS – GRN MAT |
| | | | | SXA1097787/203 | GRN KEYS – GRN MAT/CYRILLIC |
| | | | | SXA1097787/204 | GRN KEYS – GRN MAT/ARABIC |
| | | | | SXA1097787/205 | GRN KEYS – GRN MAT/THAI |
| | | | | SXA1097787/206 | GRN KEYS – GRN MAT/CN-STROKE |
| | | | | SXA1097787/207 | GRN KEYS – GRN MAT/BOPOMOFO |
| | | | | SXA1097787/301 | SLVR KEYS – SLVR MAT/LATIN |
| | | | | SXA1097787/303 | SLVR KEYS – SLVR MAT/CYRILLIC |
| | | | | SXA1097787/304 | SLVR KEYS – SLVR MAT/ARABIC |
| | | | | SXA1097787/305 | SLVR KEYS – SLVR MAT/THAI |
| | | | | SXA1097787/306 | SLVR KEYS – SLVR MAT/CN-STROKE |
| | | | | SXA1097787/307 | SLVR KEYS – SLVR MAT/BOPOMOFO |
| | | | | SXA1097787/401 | WHT KEYS – WHT MAT/LATIN |
| | | | | SXA1097787/405 | WHT KEYS – WHT MAT/THAI |
| | | | | SXA1097787/406 | WHT KEYS – WHT MAT/CHINESE |
| | | | | SXA1097787/407 | WHT KEYS – WHT MAT/BOPOMOFO |

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|---------------------|----------------|---|
|  |  | Numeric Keypad – W580 | NUMERIC KEYPAD | SXA1097984/101 | ORG KEYS – WHT MAT/LATIN |
| | | | | SXA1097984/103 | ORG KEYS – WHT MAT/CYRILLIC |
| | | | | SXA1097984/104 | ORG KEYS – WHT MAT/ARABIC |
| | | | | SXA1097984/105 | ORG KEYS – WHT MAT/THAI |
| | | | | SXA1097984/106 | ORG KEYS – WHT MAT/CHINESE STROKE |
| | | | | SXA1097984/107 | ORG KEYS – WHT MAT/CHINESE BOPOMOFO |
| | | | | SXA1097984/201 | DARK BLUE KEYS – BLK MAT/LATIN |
| | | | | SXA1097984/203 | DARK BLUE KEYS – BLK MAT/CYRILLIC |
| | | | | SXA1097984/204 | DARK BLUE KEYS – BLK MAT/ARABIC |
| | | | | SXA1097984/205 | DARK BLUE KEYS – BLK MAT/THAI |
| | | | | SXA1097984/206 | DARK BLUE KEYS – BLK MAT/CHINESE STRK |
| | | | | SXA1097984/207 | DARK BLUE KEYS – BLK MAT/CHINESE BOPOMOFO |
| | | | | SXA1097984/301 | ORG KEYS – BLK MAT/LATIN |
| | | | | SXA1097984/305 | ORG KEYS – BLK MAT/THAI |
| | | | | SXA1097984/306 | ORG KEYS – BLK MAT/CHINESE STROKE |
| SXA1097984/307 | ORG KEYS – BLK MAT/CHINESE BOPOMOFO | | | | |

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------------|---------------------|----------------|--|
| | | | | SXA1097984/401 | WHT KEYS – SLVR MAT-PINK DOTS/LATIN |
| | | | | SXA1097984/403 | WHT KEYS – SLVR MAT-PINK DOTS/CYRILLIC |
| | | | | SXA1097984/405 | WHT KEYS – SLVR MAT-PINK DOTS/THAI |
| | | | | SXA1097984/406 | WHT KEYS-PINK DOTS – SLVR MAT/CN-STROKE |
| | | | | SXA1097984/407 | WHT KEYS – SLVR MAT-PINK DOTS/CHINESE BOPOMOFO |
| | | | | SXA1097984/501 | WHT KEYS – SLVR MAT – GREEN DOTS/LATIN |
|  |  | Decorative Camera Cover – S500 | DECOR CAM CVR | SXK1097468/201 | GREEN |
| | | | | SXK1097468/301 | SILVER w YELLOW TXT |
| | | | | SXK1097468/401 | COPPER |
| | | | | SXK1097468/501 | SILVER w PURPLE TXT |
|  |  | Decorative Camera Cover – W580 | CAMERA COVER | SXK1097684/1 | ORANGE |
| | | | | SXK1097684/2 | BLUE |
| | | | | SXK1097684/3 | PINK |
|  |  | Rear Cover - S500 | REAR CVR | SXK1097469/201 | BLACK SOFT TCH |
| | | | | SXK1097469/301 | YELLOW |
| | | | | SXK1097469/401 | WHITE |
| | | | | SXK1097469/501 | PURPLE |

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|---------------------|---------------------|--------------------------|
|  |  | Rear Cover - W580 | REAR COVER | SXK1097682/1 | WHITE |
| | | | | SXK1097682/2 | GREY |
| | | | | SXK1097682/3 | BLACK |
| | | | | SXK1097682/4 | PINK |
| | | | | SXK1097682/5 | JGL GREEN |
|  |  | Front Cover – S500 | Front Cover | SXK1097504/201 | BLK CLR COAT |
| | | | | SXK1097504/205 | BLK/GENERIC C.VERSION |
| | | | | SXK1097504/222 | BLK CLR COAT/CMCC |
| | | | | SXK1097504/240 | BLK CLR COAT/TIM |
| | | | | SXK1097504/301 | YELLOW |
| | | | | SXK1097504/305 | YELLOW/GENERIC C.VERSION |
| | | | | SXK1097504/322 | YELLOW/CMCC |
| | | | | SXK1097504/340 | YELLOW/TIM |
| | | | | SXK1097504/401 | WHITE |
| | | | | SXK1097504/405 | WHITE/C.VERSION |
| | | | | SXK1097504/422 | WHITE/CMCC |
| | | | | SXK1097504/440 | WHITE/TIM |
| | | | | SXK1097504/501 | PURPLE |
| SXK1097504/540 | PURPLE/TIM | | | | |

| Part | Part Location on Phone | Working Instruction Description | Webshop Description | Part Number | Comments |
|---|---|---------------------------------|-------------------------------|----------------|-----------------------|
|  |  | Front Cover – W580 | Front Cover | SXK1097681/1 | WHITE |
| | | | | SXK1097681/2 | GREY |
| | | | | SXK1097681/3 | BLACK |
| | | | | SXK1097681/4 | PINK |
| | | | | SXK1097859/117 | WHITE/ORANGE CO-BRAND |
| | | | | SXK1097859/118 | WHITE/AT&T CO-BRAND |
| | | | | SXK1097859/217 | GREY/ORANGE CO-BRAND |
| | | | | SXK1097859/218 | GREY/AT&T CO-BRAND |
| | | | | SXK1097859/318 | BLACK/AT&T CO-BRAND |
| | | | | SXK1097859/417 | PINK/ORANGE CO-BRAND |
| | | | | SXK1097859/418 | PINK/AT+T CO-BRAND |
| | | | | | |
|  |  | Large Shim | Anti-easy press bottom gasket | SXA1098115 | |
|  |  | Small Shim | Anti-easy press top gasket | SXA1098117 | |

3 Revision History

| Rev. | Date | Changes / Comments | | | | | | | | | | | | | | | |
|-----------------|------------------|--|----------------|-----------------|-----------------|----------------|----------------|-----------------|------------------|----------------|-----------------|------------------|----------------|--------------|---------------|--------------|----------------|
| 1 | May 16, 2007 | Initial Release | | | | | | | | | | | | | | | |
| 2 | July 19, 2007 | Updated to include W580 parts | | | | | | | | | | | | | | | |
| 3 | Aug. 24, 2007 | <p>Added the following parts:</p> <table border="1"> <tr> <td>SXA1097321/55</td> <td>SXA1097705/417</td> <td>SXA1097700/4</td> <td>SXA1097984/401</td> <td>SXK1097681/3</td> </tr> <tr> <td>SXA1097705/301</td> <td>SXK1097683/3</td> <td>SXA1097700/402</td> <td>SXK1097684/3</td> <td>SXK1097681/4</td> </tr> <tr> <td>SXA1097705/401</td> <td>SXK1097683/4</td> <td>SXA1097957/54</td> <td>SXK1097682/4</td> <td>SXK1097681/417</td> </tr> </table> | SXA1097321/55 | SXA1097705/417 | SXA1097700/4 | SXA1097984/401 | SXK1097681/3 | SXA1097705/301 | SXK1097683/3 | SXA1097700/402 | SXK1097684/3 | SXK1097681/4 | SXA1097705/401 | SXK1097683/4 | SXA1097957/54 | SXK1097682/4 | SXK1097681/417 |
| SXA1097321/55 | SXA1097705/417 | SXA1097700/4 | SXA1097984/401 | SXK1097681/3 | | | | | | | | | | | | | |
| SXA1097705/301 | SXK1097683/3 | SXA1097700/402 | SXK1097684/3 | SXK1097681/4 | | | | | | | | | | | | | |
| SXA1097705/401 | SXK1097683/4 | SXA1097957/54 | SXK1097682/4 | SXK1097681/417 | | | | | | | | | | | | | |
| 4 | Aug. 30, 2007 | <p>Changed the description of SXA1097705/201 from "SLVR-WHT" to "GREY"</p> <p>Changed work instructions descriptions of three parts to:</p> <ul style="list-style-type: none"> • Memory Stick Cover • Battery Cover • Bonzer Flex Tape <p>So that the descriptions match the naming used in the mechanical working Instructions</p> <p>Added the following parts:</p> <table border="1"> <tr> <td>SXK 109 7454/1</td> <td>SXK 109 7454/22</td> <td>SXK 109 7455/2Z</td> <td>SXK 109 7466/2</td> </tr> <tr> <td>SXK 109 7454/2</td> <td>SXK 109 7455/1Z</td> <td>SXK 109 7455/22Z</td> <td></td> </tr> <tr> <td>SXK 109 7454/12</td> <td>SXK 109 7455/12Z</td> <td>SXK 109 7466/1</td> <td></td> </tr> </table> <p>Removed the following parts:</p> <table border="1"> <tr> <td>SXK1097454</td> </tr> <tr> <td>SXK1097455/Z</td> </tr> <tr> <td>SXK1097466</td> </tr> </table> | SXK 109 7454/1 | SXK 109 7454/22 | SXK 109 7455/2Z | SXK 109 7466/2 | SXK 109 7454/2 | SXK 109 7455/1Z | SXK 109 7455/22Z | | SXK 109 7454/12 | SXK 109 7455/12Z | SXK 109 7466/1 | | SXK1097454 | SXK1097455/Z | SXK1097466 |
| SXK 109 7454/1 | SXK 109 7454/22 | SXK 109 7455/2Z | SXK 109 7466/2 | | | | | | | | | | | | | | |
| SXK 109 7454/2 | SXK 109 7455/1Z | SXK 109 7455/22Z | | | | | | | | | | | | | | | |
| SXK 109 7454/12 | SXK 109 7455/12Z | SXK 109 7466/1 | | | | | | | | | | | | | | | |
| SXK1097454 | | | | | | | | | | | | | | | | | |
| SXK1097455/Z | | | | | | | | | | | | | | | | | |
| SXK1097466 | | | | | | | | | | | | | | | | | |

| Rev. | Date | Changes / Comments | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|------------------|---|---|----------------|----------------------|----------------|-----------------------------|----------------|--|----------------|--------------------------------|----------------|----------|------------|---------------------------------------|--------------|-------------------------------|------------|----------------------------|------------|-----------------------------------|----------------|---|-----------------|--------------------------------------|-----------------|---|------------------|---|----------------|
| 5 | Oct. 18, 2007 | <p>Added the following parts:</p> <table border="1"> <tr> <td>CHIN COVER - SLVR-WHT / TELEFONICA-MOVISTAR</td> <td>SXA1097700/123</td> </tr> <tr> <td>CHIN COVER - Grey/O2</td> <td>SXA1097700/218</td> </tr> <tr> <td>CHIN COVER - BLK W/ORG/CMCC</td> <td>SXA1097700/322</td> </tr> <tr> <td>CHIN COVER - PINK with Org/Telefonica-Movistar</td> <td>SXA1097700/423</td> </tr> <tr> <td>KEYPAD/NAVIGATION - BLACK/CMCC</td> <td>SXA1097705/322</td> </tr> <tr> <td>ESD shim</td> <td>SXA1098116</td> </tr> <tr> <td>Top Flip Cover Adhesive - 0.3MM thick</td> <td>SXA1343482/3</td> </tr> <tr> <td>Anti-easy press bottom gasket</td> <td>SXA1098115</td> </tr> <tr> <td>Anti-easy press top gasket</td> <td>SXA1098117</td> </tr> <tr> <td>BONZER FLEX - M-FLEX/SMK (No Dot)</td> <td>SXK 109 7454/1</td> </tr> <tr> <td>BONZER FLEX - FUJIKURA/Panasonic (Yellow Dot)</td> <td>SXK 109 7454/22</td> </tr> <tr> <td>Hinge Assembly - M-Flex/SMK (No Dot)</td> <td>SXK 109 7455/1Z</td> </tr> <tr> <td>Hinge Assembly - M-Flex/Panasonic (White Dot)</td> <td>SXK 109 7455/12Z</td> </tr> <tr> <td>MAIN KYPD FLEX - M-FLEX (No dot or white dot)</td> <td>SXK 109 7466/1</td> </tr> </table> <p>Removed the following parts: Chin Cover/ SLVR-WHT/S-E - SXA1097700/101</p> | CHIN COVER - SLVR-WHT / TELEFONICA-MOVISTAR | SXA1097700/123 | CHIN COVER - Grey/O2 | SXA1097700/218 | CHIN COVER - BLK W/ORG/CMCC | SXA1097700/322 | CHIN COVER - PINK with Org/Telefonica-Movistar | SXA1097700/423 | KEYPAD/NAVIGATION - BLACK/CMCC | SXA1097705/322 | ESD shim | SXA1098116 | Top Flip Cover Adhesive - 0.3MM thick | SXA1343482/3 | Anti-easy press bottom gasket | SXA1098115 | Anti-easy press top gasket | SXA1098117 | BONZER FLEX - M-FLEX/SMK (No Dot) | SXK 109 7454/1 | BONZER FLEX - FUJIKURA/Panasonic (Yellow Dot) | SXK 109 7454/22 | Hinge Assembly - M-Flex/SMK (No Dot) | SXK 109 7455/1Z | Hinge Assembly - M-Flex/Panasonic (White Dot) | SXK 109 7455/12Z | MAIN KYPD FLEX - M-FLEX (No dot or white dot) | SXK 109 7466/1 |
| CHIN COVER - SLVR-WHT / TELEFONICA-MOVISTAR | SXA1097700/123 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER - Grey/O2 | SXA1097700/218 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER - BLK W/ORG/CMCC | SXA1097700/322 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER - PINK with Org/Telefonica-Movistar | SXA1097700/423 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| KEYPAD/NAVIGATION - BLACK/CMCC | SXA1097705/322 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ESD shim | SXA1098116 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Top Flip Cover Adhesive - 0.3MM thick | SXA1343482/3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Anti-easy press bottom gasket | SXA1098115 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Anti-easy press top gasket | SXA1098117 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BONZER FLEX - M-FLEX/SMK (No Dot) | SXK 109 7454/1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BONZER FLEX - FUJIKURA/Panasonic (Yellow Dot) | SXK 109 7454/22 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Hinge Assembly - M-Flex/SMK (No Dot) | SXK 109 7455/1Z | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Hinge Assembly - M-Flex/Panasonic (White Dot) | SXK 109 7455/12Z | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAIN KYPD FLEX - M-FLEX (No dot or white dot) | SXK 109 7466/1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Oct. 18, 2007 | <ul style="list-style-type: none"> • Changed the color descriptions on the any cosmetic parts where the actual color of the part was not reflexed in the description • Changed the Webshop system connector description <p>Added the following parts:</p> <table border="1"> <tr> <td>CHIN COVER - GREY</td> <td>SXA1097700/233</td> </tr> <tr> <td>CHIN COVER - PINK</td> <td>SXA1097700/433</td> </tr> </table> | CHIN COVER - GREY | SXA1097700/233 | CHIN COVER - PINK | SXA1097700/433 | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER - GREY | SXA1097700/233 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER - PINK | SXA1097700/433 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Rev. | Date | Changes / Comments | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|----------------|--|---------------------|---------------|--------------------------------|----------------|---------------------------------|----------------|---------------------------|----------------|----------------------------|----------------|-----------------------|----------------|----------------------|----------------|-----------------------|----------------|--------------------|----------------|---------------------|----------------|----------------------------|----------------|----------------------------|----------------|-------------------------|---------------|--------------------------|---------------|-------------------------|---------------|--|----------------|---|----------------|--|----------------|--|----------------|---|----------------|--|----------------|---|----------------|--|----------------|---|----------------|--|----------------|--|----------------|---|----------------|---|----------------|
| 7 | Nov. 08, 2007 | <ul style="list-style-type: none"> Changed the name of several parts to match the names in the parts tracker <p>Added the following parts:</p> <table border="1"> <tbody> <tr><td>REAR FRAME - COPPER</td><td>SXA1097321/58</td></tr> <tr><td>NAVIGATION KEYPAD – BLACK/CMCC</td><td>SXA1097340/222</td></tr> <tr><td>NAVIGATION KEYPAD – YELLOW/CMCC</td><td>SXA1097340/322</td></tr> <tr><td>NAVIGATION KEYPAD – WHITE</td><td>SXA1097340/401</td></tr> <tr><td>NAVIGATION KEYPAD – PURPLE</td><td>SXA1097340/501</td></tr> <tr><td>BATTERY DOOR – YELLOW</td><td>SXA1097360/301</td></tr> <tr><td>BATTERY DOOR – WHITE</td><td>SXA1097360/401</td></tr> <tr><td>BATTERY DOOR – PURPLE</td><td>SXA1097360/501</td></tr> <tr><td>CHIN COVER – WHITE</td><td>SXA1097352/401</td></tr> <tr><td>CHIN COVER – PURPLE</td><td>SXA1097352/501</td></tr> <tr><td>CHIN COVER – GREY/T-MOBILE</td><td>SXA1097700/233</td></tr> <tr><td>CHIN COVER – PINK/T-MOBILE</td><td>SXA1097700/433</td></tr> <tr><td>DOOR/M2 MEMORY - COPPER</td><td>SXA1097957/58</td></tr> <tr><td>FRONT FRAME CPL - COPPER</td><td>SXK1097453/58</td></tr> <tr><td>FRONT FRAME CPL - WHITE</td><td>SXK1097453/54</td></tr> <tr><td>NUMERIC KEYPAD - GRN KEYS – GRN MAT/THAI</td><td>SXA1097787/205</td></tr> <tr><td>NUMERIC KEYPAD - GRN KEYS – GRN MAT/CN-STROKE</td><td>SXA1097787/206</td></tr> <tr><td>NUMERIC KEYPAD – GRN KEYS – GRN MAT/BOPOMOFO</td><td>SXA1097787/207</td></tr> <tr><td>NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/THAI</td><td>SXA1097787/305</td></tr> <tr><td>NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/CN-STROKE</td><td>SXA1097787/306</td></tr> <tr><td>NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/BOPOMOFO</td><td>SXA1097787/307</td></tr> <tr><td>NUMERIC KEYPAD - WHT KEYS – WHY MAT/LATIN</td><td>SXA1097787/401</td></tr> <tr><td>NUMERIC KEYPAD - WHT KEYS – WHY MAT/THAI</td><td>SXA1097787/405</td></tr> <tr><td>NUMERIC KEYPAD - WHT KEYS – WHY MAT/CHINESE</td><td>SXA1097787/406</td></tr> <tr><td>NUMERIC KEYPAD - WHT KEYS – WHY MAT/BOPOMOFO</td><td>SXA1097787/407</td></tr> <tr><td>NUMERIC KEYPAD - ORG KEYS - BLK MAT/THAI</td><td>SXA1097984/305</td></tr> <tr><td>NUMERIC KEYPAD - ORG KEYS - BLK MAT/CHINESE STROKE</td><td>SXA1097984/306</td></tr> <tr><td>NUMERIC KEYPAD - ORG KEYS - BLK MAT/CHINESE BOPOMOFO</td><td>SXA1097984/307</td></tr> </tbody> </table> | REAR FRAME - COPPER | SXA1097321/58 | NAVIGATION KEYPAD – BLACK/CMCC | SXA1097340/222 | NAVIGATION KEYPAD – YELLOW/CMCC | SXA1097340/322 | NAVIGATION KEYPAD – WHITE | SXA1097340/401 | NAVIGATION KEYPAD – PURPLE | SXA1097340/501 | BATTERY DOOR – YELLOW | SXA1097360/301 | BATTERY DOOR – WHITE | SXA1097360/401 | BATTERY DOOR – PURPLE | SXA1097360/501 | CHIN COVER – WHITE | SXA1097352/401 | CHIN COVER – PURPLE | SXA1097352/501 | CHIN COVER – GREY/T-MOBILE | SXA1097700/233 | CHIN COVER – PINK/T-MOBILE | SXA1097700/433 | DOOR/M2 MEMORY - COPPER | SXA1097957/58 | FRONT FRAME CPL - COPPER | SXK1097453/58 | FRONT FRAME CPL - WHITE | SXK1097453/54 | NUMERIC KEYPAD - GRN KEYS – GRN MAT/THAI | SXA1097787/205 | NUMERIC KEYPAD - GRN KEYS – GRN MAT/CN-STROKE | SXA1097787/206 | NUMERIC KEYPAD – GRN KEYS – GRN MAT/BOPOMOFO | SXA1097787/207 | NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/THAI | SXA1097787/305 | NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/CN-STROKE | SXA1097787/306 | NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/BOPOMOFO | SXA1097787/307 | NUMERIC KEYPAD - WHT KEYS – WHY MAT/LATIN | SXA1097787/401 | NUMERIC KEYPAD - WHT KEYS – WHY MAT/THAI | SXA1097787/405 | NUMERIC KEYPAD - WHT KEYS – WHY MAT/CHINESE | SXA1097787/406 | NUMERIC KEYPAD - WHT KEYS – WHY MAT/BOPOMOFO | SXA1097787/407 | NUMERIC KEYPAD - ORG KEYS - BLK MAT/THAI | SXA1097984/305 | NUMERIC KEYPAD - ORG KEYS - BLK MAT/CHINESE STROKE | SXA1097984/306 | NUMERIC KEYPAD - ORG KEYS - BLK MAT/CHINESE BOPOMOFO | SXA1097984/307 |
| REAR FRAME - COPPER | SXA1097321/58 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NAVIGATION KEYPAD – BLACK/CMCC | SXA1097340/222 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NAVIGATION KEYPAD – YELLOW/CMCC | SXA1097340/322 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NAVIGATION KEYPAD – WHITE | SXA1097340/401 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NAVIGATION KEYPAD – PURPLE | SXA1097340/501 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BATTERY DOOR – YELLOW | SXA1097360/301 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BATTERY DOOR – WHITE | SXA1097360/401 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BATTERY DOOR – PURPLE | SXA1097360/501 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER – WHITE | SXA1097352/401 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER – PURPLE | SXA1097352/501 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER – GREY/T-MOBILE | SXA1097700/233 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CHIN COVER – PINK/T-MOBILE | SXA1097700/433 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DOOR/M2 MEMORY - COPPER | SXA1097957/58 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FRONT FRAME CPL - COPPER | SXK1097453/58 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FRONT FRAME CPL - WHITE | SXK1097453/54 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - GRN KEYS – GRN MAT/THAI | SXA1097787/205 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - GRN KEYS – GRN MAT/CN-STROKE | SXA1097787/206 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD – GRN KEYS – GRN MAT/BOPOMOFO | SXA1097787/207 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/THAI | SXA1097787/305 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/CN-STROKE | SXA1097787/306 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - SLVR KEYS – SLVR MAT/BOPOMOFO | SXA1097787/307 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - WHT KEYS – WHY MAT/LATIN | SXA1097787/401 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - WHT KEYS – WHY MAT/THAI | SXA1097787/405 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - WHT KEYS – WHY MAT/CHINESE | SXA1097787/406 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - WHT KEYS – WHY MAT/BOPOMOFO | SXA1097787/407 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - ORG KEYS - BLK MAT/THAI | SXA1097984/305 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - ORG KEYS - BLK MAT/CHINESE STROKE | SXA1097984/306 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NUMERIC KEYPAD - ORG KEYS - BLK MAT/CHINESE BOPOMOFO | SXA1097984/307 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



| Rev. | Date | Changes / Comments | |
|------|------|---|----------------|
| | | NUMERIC KEYPAD - WHT KEYS - SLVR MAT/CYRILLIC | SXA1097984/403 |
| | | NUMERIC KEYPAD - WHT KEYS - SLVR MAT/THAI | SXA1097984/405 |
| | | NUMERIC KEYPAD - WHT KEYS - SLVR MAT/CHINESE BOPOMOFO | SXA1097984/407 |
| | | DÉCOR CAM CVR - COPPER | SXK1097468/401 |
| | | DÉCOR CAM CVR - SILVER w PURPLE TXT | SXK1097468/501 |
| | | REAR CVR - WHITE | SXK1097469/401 |
| | | REAR CVR - PURPLE | SXK1097469/501 |
| | | Front Cover - BLK/GENERIC C-VERSION | SXK1097504/205 |
| | | Front Cover - BLK CLR COAT/CMCC | SXK1097504/222 |
| | | Front Cover - YELLOW/GENERIC C-VERSION | SXK1097504/305 |
| | | Front Cover - YELLOW/CMCC | SXK1097504/322 |
| | | Front Cover - WHITE | SXK1097504/401 |
| | | Front Cover - WHITE/C-VERSION | SXK1097504/405 |
| | | Front Cover - WHITE/CMCC | SXK1097504/422 |
| | | Front Cover - WHITE/TIM | SXK1097504/440 |
| | | Front Cover - PURPLE | SXK1097504/501 |
| | | Front Cover - PURPLE/TIM | SXK1097504/540 |
| | | Removed the following parts: | |
| | | NUMERIC KEYPAD - ORG KEYS - WHT MAT/HEBREW | SXA1097984/102 |
| | | NUMERIC KEYPAD - ORG KEYS - WHT MAT/GREEK | SXA1097984/108 |
| | | NUMERIC KEYPAD - ORG KEYS - WHT MAT/HINDI | SXA1097984/109 |
| | | NUMERIC KEYPAD - DARK BLUE KEYS - BLK MAT/HEBREW | SXA1097984/202 |
| | | NUMERIC KEYPAD - DARK BLUE KEYS - BLK MAT/GREEK | SXA1097984/208 |
| | | NUMERIC KEYPAD - DARK BLUE KEYS - BLK MAT/HINIDI | SXA1097984/209 |
| | | ESD shim | SXA1098116 |

| Rev. | Date | Changes / Comments |
|-------------|---------------|---|
| 8 | Feb. 7, 2008 | <ul style="list-style-type: none"> • Added SXA1097984/406 - NUMERIC KEYPAD-WHT KEYS – SLVR MAT/CN-STROKE • Added SXA1097705/502 - KEYPAD/NAVIGATION – Jungle GREEN • Added SXA1097700/432 – CHIN COVER – PINK/Rogers • Added SXX1097859/417 – Pink Cover/Orange • Removed SXX1097681/417 – Pink Cover/Orange • Changed screw part number for screw with red thread lock from SXA 109 7355 to SXA 109 7355/1 • Added screw with blue thread lock - SXA 109 7355/2 • Removed Top Flip Cover Adhesive - SXA1343482/3 • Added ESD battery area tape - SXA1344109 • Added SXA1098104/4 - KEYPAD/NAVIGATION – PINK/AT+T • Added SXX1097859/418 – Front Cover – PINK/AT+T co-brand • Changed the LCD part number from RNH942222 to RNH942223 |
| 9 | Feb. 22, 2008 | <p>Added:</p> <ul style="list-style-type: none"> • SXA1097984/501 - W580i/KYPD/WIDE-NUM/JGL GRN/LATIN • SXA1097700/502 – W580i/CHIN COVER/JGL GRN/WALKMAN • SXA1098104/5 - W580i/KEYPAD/NAVIGATION/JGL GRN/AT&T • SXX1097682/5 - W580i/ASSY/REAR COVER/JGL GRN • SXX1097859/518 - W580i/ASSY/CVR/FRT BLANK/JGL GRN/AT&T CO-BRAND • SXX1097683/5 - W580i/ASSY/BATTERY CVR/JGL GRN <p>Changed Description: SXA1097984/401 - NUMERIC KEYPAD -WHT KEYS – SLVR MAT-PINK DOTS/LATIN SXA1097984/403 - NUMERIC KEYPAD - WHT KEYS – SLVR MAT-PINK DOTS/CYRILLIC SXA1097984/405 - NUMERIC KEYPAD - WHT KEYS – SLVR MAT-PINK DOTS/THAI SXA1097984/406 - NUMERIC KEYPAD - WHT KEYS-PINK DOTS – SLVR MAT/CN-STROKE SXA1097984/407 - NUMERIC KEYPAD - WHT KEYS – SLVR MAT-PINK DOTS/CHINESE BOPOMOFO</p> |