

Part List, Mechanical

Applicable for W380

Contents


1	General.....	2
1.1	View of W380	2
2	W380 Parts.....	3
3	Revision History.....	11





1 General






1.1 View of W380









2 W380 Parts



Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Upper Front Cover Assembly	Upper Front Cover Assy - Black	1206-9497	
			Upper Front Cover Assy - Dark Grey	1206-9465	
			Upper Front Cover Assy - Purple	1206-9498	
		Antenna Assembly	Antenna assy - 850	1200-9463	
			Antenna assy - 900	1201-8563	
		Battery Cover	Battery Cover - Black	1205-4137	
			Battery Cover - Dark Grey	1202-0683	
			Battery Cover – Purple	1200-7793	
		Camera	Camera - 1.3 MPixel	1200-8192	










Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Coax Cable Gasket	Coax Cable Gasket	1201-1484	
		Cobrand Inlay Assembly	Cobrand Inlay Assy	1201-0785	
			Cobrand Inlay assy, CMCC - Silver	1206-7053	
			Cobrand Inlay assy, Orange - Black	1206-7039	
			Cobrand Inlay assy, Orange - Silver	1206-7033	
			Cobrand Inlay assy, Telefonica - Black	1206-7047	
			Cobrand Inlay assy, Telefonica - Silver	1206-7043	
			Cobrand Inlay assy, TIM - Black	1206-7058	
			Cobrand Inlay assy, TIM - Silver	1206-7057	
		Cover Light Panel	Cover Light panel Assy - Black	1202-0680	
			Cover Light panel Assy - Silver	1201-1916	
		Ear Speaker	Ear Speaker	1201-3599	





Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		ESD gasket	ESD gasket	1206-6016	
		ESD cushion	ESD hinge flex gasket	1206-6021	
		Flex Plug	Flex plug - Black	1205-3427	
			Flex plug - Dark Grey	1202-0488	
			Flex plug - Purple	1200-7760	
		Hinge	Hinge	1200-9865	
		Hinge FPC	Hinge FPC	1200-6761	



Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Hinge Plug	Hinge plug - Black	1205-3195	
			Hinge plug - Dark Grey	1202-0479	
			Hinge plug - Purple	1201-5672	
		Key Locking Assembly	Key Locking Assembly - Champagne	1205-9618	
			Key Locking Assy - Orange	1205-9617	
			Key Locking Assembly - Turquoise	1205-9615	
			Key Locking Assy - Pink	1205-9614	
		Keyboard FPC Assembly	Keyboard FPC Assy	1201-0039	
		Keyboard	Keyboard Arabic - Silver	1204-3633	
			Keyboard Arabic - Black	1204-5026	
			Keyboard Bopomofo - Silver	1204-3655	
			Keyboard Bopomofo - Black	1204-5029	
			Keyboard Chinese Stroke - Silver	1204-4621	
			Keyboard Chinese Stroke CMCC - Black	1206-4541	
			Keyboard Chinese Stroke CMCC - Silver	1206-4318	
			Keyboard Chinese Stroke - Black	1204-5028	
			Keyboard Cyrillic - Silver	1204-3654	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Keyboard (Cont)	Keyboard Cyrillic - Black	1204-5027	
			Keyboard Hebrew - Black	1205-6776	
			Keyboard Hebrew - Silver	1205-6771	
			Keyboard Hindi - Silver	1205-6783	
			Keyboard Hindi - Black	1205-6779	
			Keyboard Latin - Black	1202-0882	
			Keyboard Latin - Silver	1200-7788	
			Keyboard Latin Orange - Black	1204-5035	
			Keyboard Latin Orange - Silver	1204-5034	
			Keyboard Latin TIM - Black	1206-4562	
			Keyboard Latin TIM - Silver	1206-4550	
			Keyboard Thai - Silver	1205-6784	
			Keyboard Thai - Black	1205-6781	
		Keyboard Rubber Base	Keyboard Rubber Base - Pink Center Select	1201-4706	
			Keyboard Rubber Base - Blue Center Select	1202-0897	
			Keyboard Rubber Base - Orange Center Select	1204-3441	
			Keyboard Rubber Base - Champagne Center Select	1204-3443	
		Core Unit Label	Core Unit Label	1200-7792	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Touch Key Assembly	Touch Keys Light Guide/Flex Assy	1206-9506	
		Liquid Intrusion Indicator	Liquid Intrusion Indicator	SXA1094884	
		Loudspeaker	Loudspeaker	1200-9563	
		Lower Back Cover Assembly	Lower Back Cover Assy - Black	1205-3129	
			Lower Back Cover Assy - Dark Grey	1202-0657	
			Lower Back Cover Assy - Purple	1200-7775	
		Lower Front Cover Assembly	Lower front cover assy - Black	1205-3253	
			Lower front cover assy - Dark Grey	1202-0466	
			Lower front cover assy - Purple	1200-7763	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Main Window Label	Main window Label - Black	1202-0861	
			Main window Label - Silver	1200-7790	
		Outer Display	Outer Display	1200-7550	
		5IP screw	Screw - 5IP - 1.6X4	1200-9961	
		Philips Screw	Screw - Philips 00 -1.4X2.5	1201-7762	
		Screw Cover	Screw Cover - Black	1205-4140	
			Screw Cover - Purple	1201-2564	
			Screw Cover - Dark Grey	1202-0686	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		SIM/M2 Flex	SIM/M2 Flex	1200-6773	
		Outer Display Adhesive	Sub Display Adhesive	1200-9964	
		System Connector Gasket	System Connector Gasket	1202-7371	
		Upper Back Cover Assembly	Upper Back Cover Assy - Black w/ Champagne logo	1205-3114	
			Upper Back Cover Assy - Black w/ Orange logo	1205-3094	
			Upper Back Cover Assy - Greyy w/ Blue logo	1202-0454	
			Upper Back Cover Assy - Purple	1200-7780	
		Upper PBA	Upper PBA	1200-6777	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Vibrator	Vibrator	1200-8802	
		Vibrator Clip	Vibrator Clip	1201-8051	
		Volume Key	Volume Key - Black	1204-3461	
			Volume Key - Grey	1202-0852	
			Volume Key - Pink	1200-7787	

3 Revision History

Rev.	Date	Changes / Comments
1	Feb. 29, 2008	Initial Release
2	May 21, 2008	Added 1205-9615 - Key Locking Assembly - Turquoise