




10. Flow Chart of Troubleshooting


10-1. Baseband




10-1-1. Power ON








10-1-2. Initial








10-1-3. Sim Part




10-1-4. Microphone Part


* Call with Sim before testing.







10-1-5. Speaker Part







10-1-6. LCD backlight




10-2. RF


10-2-1. GSM Rx







10-2-2. DCS Rx







10-2-3. PCS Rx







10-2-4. GSM Tx



10-2-5. DCS/PCS Tx

