

Your mobile



- 1 Information bar
- 2 Desktop
- 3 Send key
- 4 Voicemail key
- 5 Shift key
- 6 Fn key
- 7 Left/right navigation key
- 8 Space key
- 9 Tool bar
- 10 Status bar
- 11 End key
- 12 Vibration key
- 13 Delete key
- 14 Enter key
- 15 Sym key
- 16 Wi-Fi key
- 17 Micro-USB connector
- 18 Headset connector
- 19 Volume key

OT-806
OT-807
ALCATEL
mobile phones
English - CJB31E0ALAAA

- Pick up/Send a call
- Enter Call log
- Short key press: End a call
Lock the screen
Return to the main screen
- Long key press: Power on/off
- Long key press: Access your voicemail
- Press once: Input a capitalized character
- Press twice: Lock the keyboard in capital letter input mode
- Short key press: Press once: Input a top-half character
Press twice: Lock the keyboard in top-half key input mode
- Fn + B: Access Bluetooth
- Fn+ M: Access Music player
- Fn + P: Access Profiles
- Fn + J: Access Java applications
- Press to go left and right
- Short key press: Enter a space
- Long key press: Access language list
- Hold down Fn key, then press space key to select input method
- Enter a dot
- Hold down Fn key, then press sym key to enter symbol table
- Confirm an option
- Enter the next line
- Vibration alert
- Volume up/down
- Scroll up/down
- Press to enter Wi-Fi function

1.1 Status bar icons ⁽¹⁾

- Battery charge level**
- Vibrate alert:** your phone vibrates, but does not ring or beep with the exception of the alarm.
- Bluetooth status (Activated).**
- Bluetooth status (Connected to an audio device).**
- Java status (Activated).**
- Headset connected.**
- Keypad & LCD touch locked.**
- Keypad& LCD touch unlocked.**
- Call forwarding activated:** your calls are forwarded.
- Alarm or appointments programmed.**
- Level of network reception.**
- Wi-Fi connected.**
- Wi-Fi disconnected.**
- Voicemail message arrived.**
- Missed calls.**
- Stopwatch is active.**
- Radio is on.**

⁽¹⁾ The icons and illustrations in this guide are provided for information purposes only.

- WAP alerts ⁽¹⁾.**
- Roaming.**
- Memory card scanning in progress.**
- Memory card scanning completed.**
- SIM card unavailable.**
- Line switching ⁽¹⁾:** indicates the selected line.
- GPRS connection status (Activated).**
- GPRS connecting.**
- EDGE attached.**
- EDGE connecting.**
- Music player active.**
- Message receipt in progress.**
- Sending a SMS.**
- Sending a MMS.**
- Silence mode:** your phone does not ring, beep or vibrate with the exception of the alarm.
- SMS unread.**
- (In red) Message list is full:** your phone cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
- Flight mode.**
- A2DP connected.**
- Broadcast is on.**

⁽¹⁾ Depending on your network operator.

1.2 Status list

Tap the status bar and drag down to open, drag up to close. To open an application, tap it from the list.

1.3 Desktop

Adding items

To add an item from the main menu, you can select one of the following ways:

- Tap and hold an item from the main menu list.
- Tap from the tool bar and select an item.
- Touch and hold an empty area from the main screen, select "Add widgets" from the window that opens, then tap the item you want to add to desktop.

Removing items

Touch and hold the widget you want to remove from the desktop to enter the edit mode, and then tap to remove it, finally tap "Done" to confirm.

Re-organizing items

Touch and hold the widget you want to move from the desktop editing screen until a location frame shows up, then drag it to the desired location, finally tap "Done" to confirm.

Wallpaper

To personalize your wallpaper, you can select one of the following two ways:

- Touch and hold an empty area from the desktop, select "Wallpaper", then tap a folder that displayed to select an image as your wallpaper.
- Tap from the tool bar, then tap a folder to select an image as your wallpaper.

1.4 Toolbar

Toolbar with menu items by default as a shortcut for quick access. Scrolling left and right, you can view more items.

2 Getting started

2.1 Set-up

Removing or installing the back cover



Inserting or removing the SIM card

You must insert your SIM card to make phone calls. Please power off your phone and remove battery before inserting or removing the SIM card.



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press and slide it out.

Installing or removing the battery



- Insert and click the battery into place, then close the telephone cover.
- Unclip the cover, then remove the battery.

2.2 Power on your phone

Hold down the key until the telephone powers on.

2.3 Power off your phone

Hold down the key from the main screen.

2.4 Using the touchscreen

- Tap** To access an application, tap it with your finger.
- Drag** Place your finger on the screen to drag the object to the destination.
- Scroll** Slide the screen to scroll up and down the applications, images, web pages... at your convenience.

3 Making a call.....

Enter the desired number on the on-screen keypad directly or select a contact from Call log or Directory by tapping or respectively, then tap or press key to place the call. The number you entered can be saved to Directory by selecting . If you make a mistake, you can delete the incorrect digits by tapping .

To hang up the call, press the key.

4 Menu arrange.....

The main menu is designed to vary according to your preference. To access this function, select to enter the main menu, then tap .

Change the order

Access "Menu arrange", focus on the main menu item you want to move, and then tap "Options\Move", it will go to the main menu screen and tick "✓" will be shown on the main menu you selected, then release it to your favourite destination.

Show/Hide

Access "Menu arrange", tap the left check box of the selected menu once to show/hide, then tap "Options\Save" to save the operation.

Restore default

From main menu, select "Menu arrange", then tap "Options\Restore default settings" to return to the default menu display.

5 Messages.....

5.1 Conversational On (Off) mode

In conversational on mode, you can view chat history in chronological order. In conversational off mode, you may have access to the following folders: **Inbox, Outbox, Sent, Broadcast SMS, Voicemail, Drafts**, etc. You can switch between these two modes by selecting "Settings\Conversational mode\On (Off)". Conversational mode is set as the default mode and following instructions are based on this mode.

5.2 Create message

Select "Messages\Write msg" to create text/multimedia message. An SMS will be converted to MMS automatically when: images, videos, audio, slides or attachments are inserted; Subject, C/C/BCC/email address is added; or the message contains more than 8 pages of text.

Timer send

Schedule a SMS/MMS to be sent out at predefined time ("Option\Timer send").

6 Email

Your phone has an email client with the settings predefined for a few popular email services like - GoogleMail, Yahoo, AOL, etc. Besides this, you can set up other POP3 or IMAP4 email accounts that you may be using.

7 Palringo ⁽¹⁾.....

Palringo Instant messaging (IM) allows you to chat with other people using Palringo account. You can also connect to other popular IM services through Palringo, like Yahoo, AIM, GG, ICQ, GTalk, iChat etc. Please note that the services accessible to you will depend on your client version and dynamic Palringo server options.

⁽¹⁾ Depending on your network operator.

8 Directory

8.1 Consulting your directory

To access the Directory, tap from tool bar on main screen, or select "Directory" from main menu.

8.2 Adding a contact

You can add a new contact by tapping .

Birthday reminder

You can set a birthday reminder when editing contact information. This will remind you at regular intervals during the day prior to the set date.

9 Call log

9.1 Access

You may access this function from the main menu "Call log" or by pressing from the main screen.

9.2 Available options

When you tap , you may have access to **Delete, Send message, Save to directory, Edit before call**, etc.

9.2.1 Billing ⁽¹⁾

You can access different items with this option: **Last call cost, Total cost, Max cost, Reset cost, Price per unit, Duration, GPRS counter, Beep duration**.

9.2.2 Call settings ⁽¹⁾

You can access a number of items with this option: **Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial**, etc.

⁽¹⁾ Contact your network operator to check service availability.

10 Media applications

10.1 Music

To access this function, tap to enter the main menu and select . You will have full flexibility of managing music both on your mobile and memory card.

10.2 Image

A library links to the images in "My creations" in phone to be shown in list, slide, or thumbnail, set as Wallpaper, Power on/off display, and Contact ID, or sent by MMS, Email, Bluetooth.

10.3 Video

"My videos" album contains video clips recorded, received or downloaded. All video clips in this folder can be played, set as Power on/off display, sent, deleted, renamed, sorted.

10.4 Radio

Your phone is equipped with a radio ⁽¹⁾ with RDS functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

11 Internet ⁽²⁾

11.1 My friends

It migrates self-contained sub-trees of the websites to let you stay in touch with your friends by flicking through Bebo, Friendster, HIS, Myspace, etc.

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

⁽²⁾ Depending on your network operator. May cause additional network charges for data flow to provide this service. Extra fees might also be charged in roaming states.

11.2 Opera

Not only does Opera Mini give you the full Web experience where you stay in touch with your friends, obtain information, do your online banking etc., but it is also designed to save time by using compressed web pages.

11.3 Wap

Access Wap options: **Homepage, Bookmarks, Go to URL, Last web address, Recent pages, Offline pages, Service inbox, Settings**.

11.4 News

It is a huge time saver providing news updates from a website in a simple form. Once subscribed to a channel, it gives you the ability to track and manage all your favourite RSS content on your mobile phone at anytime, anywhere!

11.5 Weather

Your phone is equipped with a weather function for consulting up to 3-day forecasts of favourite cities.

11.6 Facebook

Facebook is a social utility that connects people with friends and others who work, study and live around them. It provides a number of features with which users may interact: Wall, a space on every user's profile page that allows friends to post messages for the user to see; Pokes, which allow users to send a virtual "poke" to each other; Gifts, a feature allowing users to send virtual gifts which appear on the recipient's profile; Market places, which lets users post free classified goods, etc. To open an account online, please go to: <http://www.facebook.com/>.

11.7 mTweet

Twitter is a social networking and microblogging service that has gained notability and popularity worldwide. This feature enables phone users to exchange news updates and ideas with a community in the form of messages or posts. Posts are displayed on the author's profile page and delivered to the author's subscribers or followers. To open an account online, please go to: <http://twitter.com/>.

12 Entertainment.....

12.1 Stopwatch.....

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement.

12.2 Ebook

A bookshelf contains the electronic books (.txt and .pdb file only). While reading the book, you may add bookmark, or reach the text by searching words, phrases (Options\Find, Options\Jump to).

12.3 Java

Your Alcatel phone may include ⁽¹⁾ some Java™ applications and games. You can also download new applications and games to your phone.

13 Camera

Your mobile phone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them in your "File manager\My creations".
- send them in a multimedia message (MMS) to a mobile phone or an email address.
- send them directly by Email or Bluetooth.
- customise your main screen.
- select them as incoming call image to a contact in your directory.
- transfer them by data cable or microSD card to your computer.

⁽¹⁾ Depending on your network operator.

14 Profiles

With this menu, you may personalise ringtones for different events and environments.

15 File manager.....

You will have access to all audio and visual files stored in phone or memory card in File manager. You can access a number of items with this option: **My audios, My images, My videos, Ebook, My creations, Others, Phone, Memory card and Memory status**.

Inserting the memory card:



- Unclip the cover and insert the MicroSD card into the slot.
- Unclip the cover and gently push the memory card until unlocked. Take out your MicroSD card and clip the cover closed.

16 Bluetooth™

Access this feature by tapping to enter the main menu, then selecting "Bluetooth".

17 Wi-Fi.....

To access this function, tap to enter the main menu, and select .

18 Others

18.1 Calendar

Once you enter this menu from the main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

18.2 Calculator

Access this feature by selecting "Calculator" from the main menu. Enter a number, select the type of operation to be performed, and enter the second number, then press "=" to display the result.

18.3 Notes.....

You can create a note in text or voice format by accessing "Notes" from the main menu.

18.4 Tasks

Enables you to easily manage and track the progress of a task with priorities. All the tasks will be sorted by due date.

18.5 Clock

18.5.1 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

18.5.2 World clock

The World clock shows current local time and the time zone in different cities.

18.5.3 Clock

Allows you to have settings of date and time, including 12/24h format.

18.6 Converter

You can use the Weight and Length conversion by selecting the unit you wish to convert via , then tap to input the digits. Finally confirm with "OK".

13

