



my400V

User Guide

English



You have just purchased a SAGEM phone, we congratulate you; it is recommended that you read this handbook carefully in order to use your phone efficiently and in the best conditions.

Your phone can be used internationally in the various networks (GSM 900 MHz and DCS 1800 MHz or PCS 1900 MHz) depending on the roaming arrangements with your network provider.

We remind you that this phone is approved to meet European standards.

WARNING

Depending on the model, network configuration and associated subscription cards, certain functions may not be available. Ensure that your SIM card is a 3 V SIM type that is compatible with your phone. Inserting an incompatible card will be indicated by a message when your phone is switched on. Contact Vodafone.

Your phone is identified by its IMEI number. Write this number down, and do not keep it with your phone, because you may be asked for it in the event of your phone being stolen, in order to prevent it from being used, even with a different SIM card. In order to display the IMEI on your phone's screen, type: *#06#.

SAGEM™ is a trademark of Sagem Communication SAFRAN Group.

AT@ is a registered trademark of Hayes Microcomputer Products Inc.

Hayes® is a registered trademark of Hayes Microcomputer Products Inc.

T9 is protected by one or more of the following US patents: 5,818,437,

5,953,541, 5,187,480, 5,945,928, 6,011,554 and other patents are being applied for worldwide.

Java™ and all Java™ based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

The WAP navigator and the softwares included are the exclusive property of Openwave. For this reason, it is forbidden to modify, translate, disassemble or even decompile all or part of these softwares.

© 2003 GAMELOFT® - All rights reserved - GAMELOFT® is a registered trademark of GAMELOFT S.A. - All rights reserved.

Wellphone™ and SmartCom™ are registered trademarks owned by SmartCom SARL France.

Contents

| | | | |
|--|-----------|---|-----------|
| Menus | 6 | Displaying a contact..... | 20 |
| Your phone package - Accessories | 7 | Contacts options | 20 |
| Description | 8 | Groups | 22 |
| Navigation principles | 10 | Messaging | 23 |
| Initial screen | 11 | Creating a message..... | 23 |
| Activating your phone | 12 | MMS postcard..... | 25 |
| Information on the Vodafone SIM card | 12 | Receiving messages..... | 26 |
| First use: installing your Vodafone SIM card and the battery | 13 | Inbox | 26 |
| Removing the back cover | 13 | Drafts | 26 |
| Getting started | 14 | Sent Messages | 27 |
| PIN number | 14 | Outbox | 27 |
| Setting time and date | 15 | Messenger | 27 |
| Network | 15 | Voicemail | 28 |
| First call..... | 15 | Templates | 28 |
| Receiving a call..... | 16 | Live! Studio | 28 |
| Switching off..... | 16 | Settings..... | 28 |
| Using your phone | 17 | Local information..... | 29 |
| Freeing the antenna | 17 | Groups | 29 |
| Increase the efficiency of your phone | 17 | Memory..... | 29 |
| Charging the battery | 18 | Camera | 30 |
| Contacts | 19 | Taking and saving a photo..... | 30 |
| Using the phonebook..... | 19 | Taking a video..... | 31 |
| Storing a new contact | 19 | My Files | 32 |
| Speed Dialing..... | 20 | Pictures..... | 32 |
| Calling a contact | 20 | Sounds..... | 33 |
| | | Videos..... | 33 |
| | | Exchanging objects with a PC and your phone | 33 |
| | | Vodafone live! | 34 |

| | | | |
|--|-----------|------------------------------|-----------|
| Games and applications | 35 | Java™ | 62 |
| Organiser | 36 | Troubleshooting | 66 |
| Alarm | 36 | Index | 69 |
| Timer | 36 | | |
| Calendar | 36 | | |
| Calculator and converter | 37 | | |
| Todo | 38 | | |
| Music player | 39 | | |
| Settings | 40 | | |
| Phone | 40 | | |
| Display | 42 | | |
| Messaging | 43 | | |
| Connectivity | 43 | | |
| Calls | 45 | | |
| Networks | 46 | | |
| Security | 46 | | |
| Player Settings | 48 | | |
| Browser | 49 | | |
| Camera | 49 | | |
| Video | 49 | | |
| Technical features | 50 | | |
| Care and safety information | 52 | | |
| SAR | 52 | | |
| Advice for limiting exposure to radiofrequency (RF) fields | 52 | | |
| Safety | 53 | | |
| Environment | 54 | | |
| Warranty | 55 | | |
| End User Licence Agreement (EULA), for the software | 58 | | |

Menus



Entertainment



Vodafone live!

- Vodafone live!
- Enter URL
- Bookmarks
- History
- Settings
- Vodafone Mail
- What's New?
- More Games
- More Sounds
- More Pictures
- News
- Sport



Organiser

- Alarm
- Applications
- Timer
- Calendar
- Calculator
- Todo
- Vodafone Services
- Music player



Camera



Messaging

- Create new
- Inbox
- Drafts
- Sent Messages
- Outbox
- Messenger (*)
- Vodafone Mail
- Voicemail
- Templates
- Live! Studio (*)
- Settings
- Local info
- Groups
- Memory



My Files

- Pictures
- Sounds
- Videos



Call Log



Contacts



Settings


- Phone
- Display
- Messaging
- Connectivity
- Calls
- Networks
- Security
- Player Settings
- Browser
- Camera
- Video
- Help

(*) Service depending on the operator

Your phone package - Accessories

When you open the box, check that all items are present:

- 1 - Phone
- 2 - Charger
- 3 - Battery
- 4 - User guide




Accessories




We advise you the use of SAGEM brand accessories for an optimal operating of your phone and of your accessories. You can also find (as an option) or order the following accessories:

- Pedestrian kit
- Additional battery
- Additional charger
- USB cable (with associated drivers) to connect your phone to a PC
- Cigar lighter charger
- Wellphone CD



Note: The front and back covers are not interchangeable.

Description




- **Hold down:** Switch on/off
In a call context: Reject a call - hang up
In menus: Return to initial screen
- ①
- **Short press:** Activate/Deactivate hands-free mode (**WARNING:** in this mode do not bring the phone up to your ear)
In dialling/phonebook/call log context: Call - receiving a call
-  **Right key:**
In initial screen: Access to Vodafone live! (shortcuts)
In menus: Access to the selection shown on screen in the tab (*)
-  **Left key:**
In initial screen: Access to the main menu (shortcuts)
In menus: Access to the selection shown on screen in the tab (*)
-  The four-directional navigation stick allows you to:
 - Move the cursor on the screen by pushing the stick toward the corresponding direction
 - Confirm your selection by pressing the stick
 - In initial screen:
 - leftwards/rightwards: open **Create new/My Files**
 - downwards/upwards: open **Contacts/Vodafone live!**
- ⏏ ✖ **Press briefly and [OK]:** activate or deactivate keypad locking
- When composing a message:**
Short press: switches from one editing mode to another (upper case/lower case, 123 mode)
Long press: activate/deactivate T9 mode
- ## ↵ **Hold down:** In idle screen: Silent mode
In call reception mode: Short press stops ring tone
In ring tone setting mode: Activate/deactivate ring tone. Stops sound in video or message playing, or in a game
- 2 to 9** **Long press:** access to Speed Dialing

(*) In this manual, when a function is chosen by pressing on this key, square brackets are used (e.g.: [Save]).





Navigation principles

These basic principles bring a great intuitiveness to your phone.

Validate by pressing the  key or the navigation stick.


Cancel by pressing the  key.


The thumbnails at the bottom of the screen refer to the   keys.


In the menus, a title bar reminds you of the previous level.


From the home page, pressing the navigation stick displays the icons of the main menus.

When pressing the navigation stick followed by a figure, you can display a menu directly. For instance, pressing the navigation stick then **8** displays the Phonebook.


The  key is used to go from a menu to a sub-menu.

The  key is used to go from a sub-menu to a menu.

The  key (press briefly) is used to go back to the initial screen (current function is abandoned).

In some menu there is a Help menu () which informs you on the various functions of the sub-menus.

Initial screen



The initial screen contains the following information:

1 - The title bar icons:

| | |
|--|---|
| | Battery |
| | Calls forwarded |
| | Call (establishing the call) |
| | Call (hands free) |
| | Message (reception of a message, message memory full) |
| | FAX communication |
| | DATA communication |
| | Silent mode |
| | Message in answering machine |
| | WAP (@) communication |
| | GPRS |
| | Home zone |
| | Roaming |
| | Only emergency call is possible |
| | Keypad locking |
| | Protected WAP logon |
| | Protected WAP logon icon with certificate |
| | Signal strength level (5 bars). |

2 - Network provider


3 - Date and time, in digital or analog mode

4 - Symbols and thumbnail centred on bottom line:

- The main thumbnail shows that the menu can be accessed via the navigation stick.
- : Short access to the main menu - : Short access to **Vodafone live!** menu
- Information messages on calls, messages or network messages received may also be displayed. They can be deleted by pressing key briefly.

Activating your phone

Information on the Vodafone SIM card



To use your phone, you need Vodafone SIM card. It contains personal information that you can modify:

- Secret codes (PIN(s): Personal Identification Numbers), these codes allow you to protect access to your SIM card and phone
- Phonebook
- Messages
- How special services work.


Your phone is compatible with the SIM 3V cards.

WARNING

This card must be handled and stored with care in order not to be damaged. If you should lose your SIM card, contact Vodafone immediately.

Please keep your SIM card out of reach of young children.

First use: installing your Vodafone SIM card and the battery




- 1 Slide the SIM card, with cut corner as shown on the phone, into the card holder with fold face down.
- 2 Place the battery by positioning first the top of it, as shown on the battery.
- 3 Place the back cover, clicking in first the upper part then the lower.

Removing the back cover

Proceed as follows to remove the back cover (in case of replacement of the battery or the SIM card, for instance):

- Turn the phone back. Press on the centre part at the level of the notch (1) and lift the cover (2).



Getting started

You are now ready to use your phone for the first time.

Switch on the phone by pressing the *** key. A short display appears.

When you switch on your phone for the first time, you must configure it with various settings that will remain by default until you choose to modify them (depending on model).

After entering your PIN code, the phone activates the Vodafone settings and switches on again ; enter your PIN code again then the date and time, make your choice for the following settings: time zone, daylight savings, skin, wallpaper, screensaver, ring tone, volume, vibrate and voicemail number.

If there are contacts saved in your SIM card, you are invited, if you wish, to copy them in the phone contacts memory.

PIN number

This is your SIM's secret code.

If access to the Vodafone SIM card is protected, the device prompts you to enter the PIN number:

Enter the code between 4 and 8 digits given to you when the SIM card was issued. These digits do not appear on the screen for security reasons.

Press **[OK]** or the navigation stick to validate.

If your phone indicates that the SIM is missing, press the *** key to switch off your phone and check that the SIM card is correctly installed.

WARNING

If a wrong PIN number is entered three times in succession, your SIM card is blocked. You must then:

- Enter the PUK (Personal Unblocking Key) code provided by your operator, and validate.
- Enter your PIN number and validate.
- Enter your PIN number again and validate.

After 5 or 10 failed attempts (depending on the type of SIM card), the Vodafone SIM card is definitely locked. You must then contact your operator or your SMC to obtain a new card.

Setting time and date


When you use your phone for the first time, you need to set the date and time.

In due course, when the battery is completely discharged, or if it has been removed, you will be prompted systematically to confirm date and time.

Setting the date

Set the date by entering it directly in numerical form or by using the navigation stick to increase or decrease the default values.

Use the navigation stick to access the next (or last) data input field.

Once the date is correct, press the  key to validate.


Setting the time


Same procedure as for setting the date.

Network

From now on the phone hunts for a network on which it can make calls. If it finds one, it displays the name of the network on the screen. You are then ready to send or receive a call.

If the network icon appears, calls are possible on your operator's network.

If the the icon  and a network name are displayed, calls are possible on the network of a different operator.

If the the icon  is displayed without any network name, only the emergency services are accessible (ambulance, police, fire brigade).

If the network icon flashes, the phone is in permanent search mode. There is no network available. The signal strength indicator received allows you to display the quality of reception. If it indicates less than three bars, search for better reception in order to call in good conditions.

First call


Dial the number of your correspondent.

Press the  key.

During the call, the call in progress icon flashes on screen and tones may indicate the establishment of the call.

Once communication has been established, the call icon stops flashing.

You can adjust the sound level (volume) using the navigation stick.

At the end of the conversation press the  key to hang up.

Calling voicemail

In the initial screen, press and hold down the **1** key.

International call

Press **0** (hold down) to display « + », then dial the country code without waiting for the dial tone, then the number of the called party.

Emergency services

Depending on the operators you can obtain the emergency service with or without SIM card or when the keypad is locked. It is enough to be in an area served by a network.

To obtain the international emergency service, dial **112** then press the **###** key.

Receiving a call

When you receive a call, the number of your correspondent is displayed when it is presented by the network.

Press the **###** key or the **[...]** key to answer, and speak.

To refuse the call, press the ******* key or the **[...]** key.

To stop the ring tone or the vibrate, without refusing the call, press the **#** key.

Hands-free mode

During a call, press the **###** key and validate pressing **OK** (or **[...]**) or press **OK** twice to switch into hands-free mode.

WARNING: in this mode do not bring the phone up to your ear.

All the numbers corresponding to incoming and outgoing calls are logged in the list of recent calls.

When a call is on hand, pressing **[Options]** allows you to have access to different functions: switching to hands-free mode, holding a call, switching to mute mode, ending the call, displaying menus.

Pressing **[Secret mode ON]** allows you to switch off the sound temporarily when you do not want that your correspondent listens when you want to speak to other people.


Switching off

Press the ******* key (long press).

The end message is displayed. The phone switches off.

Using your phone

Freeing the antenna



The antenna is integrated in your phone, under the back cover at the top. Avoid putting your fingers on this area when the phone is switched ON. If your fingers obstruct the antenna, the phone may have to operate with a higher power level than usual; decreasing its efficiency quickly. It could also affect the quality of your communications.

Non ionising radiation


To obtain maximum satisfaction from your phone, use it in a vertical position. Your personal safety can only be improved by doing so.



Increase the efficiency of your phone

- Don't press the keys when not necessary: each keypress activates the backlight, and uses much power.
- Don't obstruct the antenna with your fingers.

Charging the battery



Your phone is powered by a rechargeable battery. A new battery must be charged for 4 hours at least before being used for the first time. It reaches its optimum capacity after a few cycles of use.

When your battery has been discharged, the phone displays the state (empty battery icon flashes). In this case recharge your battery for at least 15 minutes before making any calls in order not to be cut off in the middle of a call.

To recharge the battery:

Connect the charger to a socket.

Plug the end of the cable into the side connector of the phone.

The phone is then charging up. The battery icon is scrolling up and down to indicate that it is charging. When the battery is fully charged, the charging stops on its own. Disconnect the cable.

When charging, the battery may warm up, this phenomenon is normal.

WARNING

There is danger of explosion if the battery is placed in an incorrectly way or if it is exposed to fire. Do not short circuit it.

The battery does not have any part that you can change.

Do not try to open the battery casing.

Use only the appropriate chargers and batteries as shown in the phone manufacturer's catalogue.

The use of other types of chargers or batteries may be dangerous or invalidate the warranty.

Used batteries must be disposed of in the appropriate places.

We advise you to take the battery out if you plan not to use the phone for extended periods.

You are strongly advised not to connect your phone to the charger if it doesn't contain a battery.

The charger is a safety step-down transformer, it is forbidden to modify, alter or replace it by another component (power supply plug, etc).

If the battery has entirely discharged, the phone cannot start. Plug the phone to the charger. The phone will switch on after a few minutes of charge. You can use the phone again when the Start option is displayed on the screen.

Contacts



The phonebook allows you to store numbers that you call regularly. These numbers can be stored in the SIM card or in the phone.

To store a contact in the phone memory, the following fields can be filled: last name, first name, numbers, emails, URL, numbers, address, company, birthday, comments, ringtone, photo.

To store a contact in the SIM card, only the last name and number fields must be filled.

Using the phonebook

Display the **Contacts** menu. The list of your contacts appears.

The location where the contact is stored (SIM card or phone) is indicated by the icon at the top of the screen when the cursor is located on a contact.



contact stored in the SIM card



contact stored in the phone



contact stored in the Fixed Dialling. See **PIN 2 number** and **Fixed dialling** on page 47 for more details about this activation.

Storing a new contact

There are two ways to store a contact:

- 1) by selecting **Contacts**[Options] or **OK**, then **Add phone contact** or **Add SIM contact**.
- 2) **Contacts/Add contact/Telephone** or **SIM card**.
 - Then enter the last name and press **OK**.
 - Enter the number and press **OK**.
 - Press [**Save**] to store it.

Speed Dialing

You can assign a short number to a contact (from 2 to 9).

- From the idle screen, make a long press on the short number selected.
- The Speed Dialing function is displayed.
- Enter the phone number of your contact or press the **[Contacts]** key to select a contact already saved.
- Press **[OK]** to confirm.

Calling a contact

Several ways:

- Select a contact. Press the **■ ■ ■** key to start the call.
- Select a contact, press **OK**, his number is displayed, press **[Call]** to start the call.
- Direct call from the idle screen (only for the contacts stored in the SIM card memory): type the number with which the contact was saved then **■ *** **✕** (example : 21 **■ *** **✕**) or the number then **✚** **↓**, the number is displayed, confirm.

Displaying a contact

Select a contact from the list and press **OK**. The name, the phone number and the order number with which the contact is stored are displayed.

Note: By directly pressing three characters, the phone will display the first contact saved in the phonebook, starting with it. To display the different options, select a contact from the list and press **[Options]**.

Contacts options

To display the various options, select a contact and press **[Options]**.

Edit contact

Modify what you want and validate then select **Save** once the modifications completed.

Send message

To send a SMS or a postcard to a contact (see chapter **Messaging**).

Send By

To send a contact details by message or IrDA (see chapters **Messaging** and **Connectivity**).

Add Speed-Dialing

You can assign one of the numbers proposed to the contact selected (see **Speed Dialing** on page 20).

Copy one to SIM/Copy to phone

This allows you to copy your phonebook contacts from one memory to the other. Only the name and the first phone number will be copied.

My numbers

You can create the entries corresponding to your own numbers in order to consult them when necessary. Enter the different details and validate.

Memory

Select **Memory** and validate. Select **SIM** or **Telephone** and validate.

- **Telephone**: the screen displays the amount of memory used. The memory capacity is shared between the phonebook and various other features. If you lack memory, check if you can free some space from another feature.
- **SIM**: available memory only for contacts.

Delete/Delete all

This allows you to delete the contact selected or all the contacts.

Copy all to phone/Copy all to SIM

This allows you to copy all the SIM card contacts to the phone memory and vice versa.

Set as my card/Business card

The details of a contact stored in the phone memory can be saved in a business card.

- Select a contact and press [**Options**].
- Select **Set as my card** and [**OK**]. The details are saved as **Business card**. Then you can read it, modify it or send it by SMS, MMS or IrDA.

Synchronize

You can synchronize your phonebook with your archives stored in Vodafone's network depending on the options offered by your subscription.

The local synchronisation with your computer is only computer originated, from Wellphone software; you have only to activate infrared or configure your USB connection in your phone.

Contacts synchronisation with a computer

Install Wellphone, software provided on CD, and click on DIRECTSYNC: you can synchronise your contacts stored in the phone memory with those of your Lotus Notes™ or Microsoft Outlook™ bases.

Add to mailing list

This menu allows you to add a contact to a mailing list.

Settings

- **List choice:** this menu allows you to select the default phonebook (SIM, Phone, SIM and Phone) displayed when the phone switches on.
- **Filter criteria:** this menu allows you to select the way to sort contacts in the phonebook (by name or first name).

Groups

A group allows you to send a same message to several recipients at the same time.

- In the phonebook, select the **Groups** tab.
- Press [**Options**].
- Select **Add group**.
- Enter a name and press **OK**.
- Then, on a list press [**Options**]. Select **Add contact** each time you want to add a contact in the list.

Messaging



From this menu, you are able to send SMS and MMS. MMS is the Multimedia Message Service, which allows you to send photos, audio files and other rich content in your messages; these messages can even be composed of several slides. MMS are charged at a different rate to SMS. Please contact Vodafone to get more information on their cost.

This menu has been compiled in collaboration with magic4™.

magic4

Creating a message

Messaging/Create new

The language used is the one selected on the display of the phone (if the language selected is not compatible with the Easy Message T9™, the English language will be automatically selected).

When typing a text, a counter showing the number of characters used is displayed at the top of the screen. This counter is not displayed if an icon or sound is inserted into the message.

When the text has been entered, **[Options]** is used to access the functions offered:

- **Add recipient:** to send the message by entering the recipient's number or selecting it in the phonebook.
- **Add Pictures/Sounds/Videos/Calendar/Visit cards:** to insert various objects into your message.
- **Add Subject:** allows you to precise a subject to your message.
- **Preview:** to display a preview of the message once composed.
- **Slide duration:** allows you to select a duration to make the text scroll automatically before sending the message.
- **Symbols:** to insert accented characters, special characters or punctuation.
- **Input mode: ABC mode/123 mode** (see page 24), **T9 options** (see page 24).
- **Message type:** to select the message type (SMS or MMS).
- **Save to Drafts:** to save a draft in memory.
- **Save as template:** allows you to keep as a template a message in order to use it again.
- **Send Options** (see page 28).
- **Activate/Deactivate Zoom** is used to modify size of characters.

The Easy Message T9™ mode helps you to easily write your messages.

Using T9 Mode

Press once the key corresponding to the letter chosen and compose the word by continuing to press the keys corresponding to the various letters without paying attention to the display: the word is highlighted.

If you agree on the word proposed on the screen, press the **0** key to validate it (the **0** key inserts a space), and go on writing the next word.

However, the same sequence of keys pressed can correspond to several words, existing on the dictionary. If the word that appears is not the word you expected, press **▲** to scroll through the words corresponding to this key sequence.

Once you agree on the word proposed on the screen, press the **0** key to validate it (the **0** key inserts a space), and go on writing the next word.

If the word you are expected is not proposed, please add characters until you get the message **Add a word?** Press **[Yes]** and validate if the word displayed suits you or modify this word before adding it in the dictionary.

Input modes

When composing a message:

- **[Delete]**: deletes last letter
- **[Options]**: message options
- **## ↵ key**:
short press: access to symbol table
- **long press**: change the T9 language
- **ⓐ + ✕ key**:
Short press: switches from one editing mode to another (upper case/lower case/123 mode)
Long press: activate/deactivate T9 mode)

The mode in which you type the text is displayed at the right top of the screen.

The **ABC mode** is used to write words that do not exist in the dictionary. To get a particular character, please press the corresponding key several times.

Mode 123 is used for numbers.

Upper case/Lower case/123 mode

A short press on the **ⓐ + ✕** key switches one editing mode to another.

Punctuation characters

Punctuation characters are obtained by pressing the **1** key (except in **123** mode), or with the help of **Insert** mode (fast access by briefly pressing the **## ↵** key).

Accented characters

Accented characters are generated automatically in T9 mode (long press on the **ⓐ + ✕** key).

In ABC mode accented characters are available by pressing the key supporting the non-accented character repeatedly.



Saving the message

- Select **Save to Drafts**.
- Select where you want to save it (SIM card or phone). It is saved in the **Drafts** menu.

Sending the message

- Once the text entered, press **OK** or press [**Options**] and select **Add recipient**.
- The **Contacts** menu is displayed.
- Select:
 - **Add new number** or
 - **Add new email** or
 - a contact in the list.
- Press **OK** and select **Send**.

Note: It is possible that the voice message format (.amr) is not supported by some PC. See your PC provider.

Warning: *some message sendings may fail if the message content is too big.*

MMS postcard

Messaging/Create new/Live! Postcard

With the MMS postcard option, Vodafone prints on paper a photo you have selected in your phone and Vodafone sends it by post to the receiver.

Select the photo you want to send and press **OK**. Then press **Insert**.

Type the message to be printed on the postcard and press **OK**. Enter the receiver's name, address, Post Code and City and optionally County and Country using **OK** to advance.

Finally, to send the postcard press [**Options**] and select **Send**.

Note: In some countries or models this service may not be supported (check with your local Vodafone Service provider).

Receiving messages

When you receive a message, the phone plays the ring tone that you selected, and a message icon comes on the screen of your phone.

If you do not read the messages, this icon remains displayed on the screen. When it flashes, the memory is full.

Receiving multimedia objects can take several seconds. An icon is flashing when the download of your message is in progress.

Note that you have two different possibilities for receiving MMS: automatically or manually; if « manual mode » is activated, then you will receive only a notification in your Inbox, meaning that a MMS is available on the MMS Server; select Retrieve in the options when you want to retrieve the MMS from the network.

For more details about automatic and retrieval modes, see **Settings** on page 28.

Please contact Vodafone to get more information on multimedia objects downloading.

Received messages are stored in the SIM card or in the phone until you choose to delete them.

Inbox

Messaging/Inbox

Each message shows the presence of any attachments, the time and date the message was received and its size.

Messages are listed in chronological order, the latest one being displayed first.

The quantity of Not Read and Not Retrieved messages is shown. Not Retrieved and Not Read messages are shown in bold.

Select a message and press **OK**. Choose one of the options given.

If there are enclosures in a message, you can extract them in order to be used later on (they are stored in the phone memory).

Drafts

Messaging/Drafts

When you save a message, it is stored among the drafts.

If you select a message and press **OK**, you can modify it.

If you want to send it, press [**Options**] and select **Send**, then enter the recipient's number.

Sent Messages

Messaging/Sent Messages

This menu is used to store all your sent messages if you activated the option **Save sent msgs** in the **Settings** menu (see page 28).

Too many messages saved will quickly fill up the available memory and no further messages will be received.

For each message, its characteristics (shown with an icon) and the time (or date) of sending are displayed on the screen.

Select a message and press **OK**.

Outbox

Messaging/Outbox

This menu displays the messages that have not been sent. You can therefore send them again.

Messenger

(Service depending on the operateur)

Messaging/Messenger

The **Messenger** menu allows you to speak in real time with your contacts having the same connection type, from your phone or your PC.

At any time, wherever you are, you can send them a message as easily as a SMS.

Note: This service leads to a cost. For more information, contact your operator.

Creating an identifier

To use Messenger you need to create an identifier (name) and log on to the operator server: help screens guide the user when logging on for the first time.

After logon, the list of contacts is displayed.

Remark: An icon is displayed on the sleep-mode screen when you are logged on to Messenger.

Adding contacts

To add a contact, go into **"Choice"** and into the **"Add contact"** option, then enter your contact's telephone number or Messenger identifier.

An icon opposite each contact indicates whether your contact is on line, available, etc.

Conversation

To start a conversation with one of your contacts, all you do is select your contact then send a message by going into **"Choice"** then the **"Write"** option: the text you sent and your contact's reply both appear in the conversation screen.

Voicemail

Messaging/Voicemail

This function allows you to call your voicemail.

Note: if your voicemail number has not been entered yet, you must enter it in the menu **Settings/Calls/Voicemail**.

Templates

Messaging/Templates

When composing a message, if you selected the **Save as Template** option, the template is saved in this menu.

The same options as for the drafts are available for the templates.

Live! Studio

(Service depending on the operateur)

Messaging/Live! Studio

With this link, you can view your stored pictures and sounds in the Vodafone live! live! Studio site.

Note: In some countries or models this service may not be supported (check with your local Vodafone Service provider).

Settings

Messaging/Settings

The SMS settings are: Save sent msgs, Delivery report, Period of validity, Message format, Msg centre n°.

The MMS settings are:

- **Save sent msgs:** it is highly recommended that you keep this function deactivated, in order to avoid a full memory.
- **Retrieval mode:** if you are in a poor coverage area, it may be more convenient to choose the manual retrieval mode which gives you the retrieve later option.
- **Priority:** selection of a priority to send a message.
- **Request delivery:** request of a delivery report when sending a message.
- **Period of validity:** during that period, the network provider will try to send the message.

Advanced settings

- **Send delivery rep:** sending a delivery report when receiving a message.
- **MMS ignore:** if you want to deactivate the reception of any MMS in your phone.
- **MMS server:** to select another MMS provider, or set the parameters of a new MMS provider.
- **Display Bcc:** if you want to activate/deactivate this display.
- **Sender visibility:** you choose to display or not your phone number on the receiver's phone screen, with that message.
- **Maximum Size:** if you want to activate/deactivate the option of maximum size supported for the MMS.

Local information

Messaging/Local info

This menu is used to activate reception of local information broadcast by the network. You can choose whether you want to receive this information or not (please contact Vodafone).

Groups

Messaging/Groups

This menu displays the mailing lists created in the phonebook.

Memory

Messaging/Memory

You may know the memory available for saving messages.

Choose one of the options given: SMS or MMS.

The SMS screen displays the memory available either on the SIM card or on the phone.

The MMS screen displays how much memory is used in Kbytes.



This menu allows you to take photos or videos and use them for different purposes. For instance, you can send them to another phone or an Internet address, store them, use them as wallpapers or screensavers.

Taking and saving a photo

Settings before taking a photo

Zoom:

To activate zoom, use the ▲ and ▼ keys or the side keys (+ and -).

Note: if the zoom selected does not match with the storing format, the photo is automatically saved in an appropriate format

Other settings (pressing [Options]):

- **Activate timer:** to take a photo with a 5, 10 or 15 second time delay.
- **Effects:** to select an effect (sepia, negative or grey levels).
- **Exposure:** to select luminosity (indoor, sunny, etc.).
- **Click sound:** to select the sound you will hear when taking a photo.
- **Photo quality:** to select the photo quality.
- **Photo format:** to select the format in which your photo will be saved.
- **Go to video** (see on page 31).

Taking a photo

- Select the **Camera** menu. Look into your phone display and position your subject. Move your phone to position your photo.
- Press **OK** (or on the side key), the photo is taken and stays on the phone display.

Warning: if you press [Back], you will go back to the previous screen and lose the photo you have just taken.

- Press [Save] to save your photo and display the different options:
 - **Send By:** allows you to send the photo by IrDA or MMS.
 - **Take photo:** allows you to take a new photo.
 - **Editor:** various options to modify a photo.
 - Zoom:* allows you to magnify certain parts of your photo,
 - Adjustment:* allows you to improve contrast,
 - Emboss:* allows you to modify a photo with an embossed grey tint,
 - Negative:* allows you to change a photo into negative,
 - Grey Scale:* allows you to change color into black and white,
 - Contrast:* allows you to increase or decrease the contrast of your photo,
 - Sharpen:* allows you to sharpen a photo,

Blur: allows you to add blur to a photo,
Sepia: allows you to change colors into sepia,
Shape: allows you to shape a photo,
Brightness: allows you to increase or decrease the brightness of a photo,
Solarize: allows you to increase or decrease the solarize of a photo,
Saturation: allows you to increase or decrease the color saturation.

- **Rename**: allows you to modify the name of a photo.
- **Add to contact**: allows you to assign a photo to a contact saved in the phonebook.
- **Use as**: allows you to select the photo as wallpaper or screensaver.

If there is not enough memory to save the photo, a warning message appears, prompting you to confirm whether you want to go on.

Note: using the camera during a call may disturb the call quality.

Taking a video

- Select the **Camera** menu.
- Press **[Options]** and select **Go to video** or press the ► key.
- If necessary, select the following settings pressing **[Options]**:
 - **Video sound**: allows you to record whether or not the sound when recording a video.
 - **Size restriction**: allows you to choose a video size.

Press **OK** to record then press **[Stop]** when you want to stop recording.

Note: the phone automatically stops recording when the maximum size available is reached.

- Press **[Options]** to display the options:
 - **Playback**: allows you to play the video.
 - **Save**: allows you to save the video.

Note: the videos are saved in the phone with a 3gp format.

My Files



This menu contains photos and videos taken and saved with your phone, the sounds recorded and all the downloaded objects (pictures, ring tones, etc).

Pictures

My Files/Pictures

To display a picture, select it and press **OK**.

To display others, press **▲** or **▼**.

To display the different options, press **[Options]**.

- **View**: allows you to display the picture.
- **Send By**: allows you to send a picture by MMS or IrDA (**NB**: you may not send any copyrighted picture).
- **Add to contact**: allows you to assign a picture to a contact saved in the phonebook.
- **Use as**: allows you to use the picture as a wallpaper or screen saver.
- **Rename**: allows you to rename a picture.
- **Delete**: allows you to delete a picture.
- **Editor**: see chapter **Camera**.
- **Take picture**: allows you to take a new picture.
- **Details**: properties of the picture selected.
- **Memory**: memory size used by the pictures.

Sounds

My Files/Sounds

To listen to a sound, select it and press **OK**.

To listen to others, press ▲ or ▼.

To display the different options, press [**Options**].

- **Listen**: allows you to listen to the sound.
- **Send By**: allows you to send a sound by MMS or IrDA.
- **Add to contact**: allows you to assign a sound to a contact saved in the phonebook.
- **Ring tone**: allows you to add a sound to the ring tones list.
- **Rename**: allows you to rename a sound.
- **Delete**: allows you to delete a sound.
- **Rec. Sound**: allows you to record a new sound.
- **Details**: properties of the sound selected.
- **Memory**: memory size used by the sounds.

Videos

My Files/Videos

To display a video, select it and press **OK**.

To display it in portrait or landscape mode, press ◀ and ▶.

To display others, press ▲ or ▼.

To display the different options, press [**Options**].

- **Play**: allows you to display the video.
- **Send By**: allows you to send a video by MMS or IrDA.
- **Rename**: to modify the name of a video.
- **Delete**: to delete the video.
- **New video**: allows you to take a new video.
- **Details**: properties of the video selected.
- **Memory**: memory size used by the videos.

Exchanging objects with a PC and your phone

You must connect them with a USB cable or by infrared (see chapter **Connectivity**).

Vodafone live!



Vodafone live! is a mobile internet portal service which allows you to obtain information such as weather conditions, news, sport and download new ringtones, wallpapers, music, videos, etc.

The browser navigator is under licence:



RSA Data Security

The browser navigator and the softwares included are the exclusive property of Openwave. For this reason, it is forbidden to modify, translate, disassemble or even decompile all or part of these softwares.

Vodafone live!: opens the Vodafone live! portal.

Enter URL: allows to enter URL addresses.

Bookmarks: allows to store bookmarks (addresses of Internet sites).

A bookmark stored in the list can be modified, sent or deleted. You can receive bookmarks and add them to this list.

History: backward and forward navigation of the pages displayed are kept in memory.

Settings: allows you to modify profiles or create new ones.

What's New? - News - Sport: connection to information site on Vodafone live! portal.

More Games - More Sounds - More Pictures: allows you to choose more games, ringtones or images to use on your phone. Connect to the Vodafone live! portal.

Games and applications



Entertainment and Organiser/ Applications menus



Each game has a tutorial section to run you through the rules and actions.

And when you've completed these games, why not download some more?




Alarm

Organiser/Alarm

This menu allows you to set and activate the alarm.

To activate the alarm, select **Activate**.

Set the wake-up time by entering the numbers directly and validate.

 *The alarm icon appears on the idle screen.*

The alarm works even when the phone is switched off.


Timer

Organiser/Timer

This menu is used to set and activate the timer.

To activate the timer, select **Activate**.

Set the duration (hours/minutes) by entering the numbers directly and validate.

 *The alarm icon appears on the idle screen.*

Calendar

Organiser/Calendar

This menu gives you access to your diary and get to a day, week, month or specific date. It lets you add events, access the global actions for all the events and manage them by event category.

- **Add Written Evt/Add Vocal Evt:** allows you to add events of the text or voice type. Fill in the different items. Save the event.
- **Delete:** allows you to schedule the deletion of events that took place more than one day, week or month ago.
- **Memory:** allows you to view the memory capacity used by the different functions of your diary.
- **Delete:** allows you to delete the event selected.
- **Delete all:** allows you to delete all the events from your diary.
- **Categories:** allows you to see the different event categories, assign a specific ring tone to each individual category, know the number of events in each category and see them.

- **Synchronize:** You can synchronize your organizer with your archives stored in Vodafone's network depending on the options offered by your subscription.
The local synchronisation with your computer is only computer originated, from Wellphone software; you have only to activate infrared or configure your USB connection in your phone.

The other menus are:

- **Monthly view:** allows you to access events on a month-by-month basis.
- **Weekly view:** allows you to access events on a week-by-week basis.
- **Daily view:** allows you to access the events for the current day and the actions possible on any event (see, modify, delete and send).
- **Date view:** allows you to access events at a specific date.

Calculator and converter

Organiser/Calculator

This menu allows you to use your phone as a calculator.

Use the following keys to make calculations: ▲: Add, ▼: Subtract, ►: Multiply, ◀: Divide, $\frac{\square}{\square}$ * \square \square : Decimal point.

If no calculations are being run, pressing [**Convert**] allows you to convert one currency to another.

Enter a value and press ▲ to convert from one currency to another, or press ▼ to convert back.

Pressing [**Options**] allows you to use the following options:

Rapid exchange

If the Rapid exchange is activated, the converter will work in the idle screen by entering the desired numbers and pressing **OK** to convert.

Exchange rate

Enter the exchange rate corresponding to the chosen currency.

Currency

Enter the two types of currency to be converted.

Goto Calculator

This option allows you to use immediately the value converted in the **calculator**.

Todo

Organiser/ToDo

This menu allows you to write or record tasks, called Todo, access category-based Todo management and delete all the Todo's.

Select the **Todo menu** and press **OK** to display the following options:

- **Write Todo:** allows you to write a text Todo. Fill in the different items. Save the Todo.
- **Record Todo:** allows you to record a voiceTodo. Fill in the different items. Save the Todo.
- **Categories:** allows you to see the different Todo categories, assign a specific ring tone to each individual Todo, know the number of Todo's in each category and see them.
- **Delete all:** allows you to delete all the Todo's from your Todo.
- **Memory:** allows you to view the memory used by the different functions of your Todo.
- **Synchronise:** allows you to synchronise a Todo with a computer (depending on the options offered by your subscription).

To display a Todo, select it in the list and press **OK**.

To display the different options, press **[Options]**.

- **Modify Todo:** allows you to modify the Todo properties.
- **Delete:** allows you to delete the Todo.
- **Send By:** allows you to send the Todo by MMS or IrDA (see chapter **Connectivity**).

This menu allows you to listen to musics in a continuous way like a portable music player.

If you do not have any music in memory, use Vodafone live! to download some or connect your phone to a PC (see chapter **My Files**).

Music player

Two tabs are displayed: **Player** and **Library**.

Select **Library** pressing ►. The directory of the music contained in the phone and in the memory card (if it is present) is displayed.

Select [**Options**]: you can play all the music directly or manage them in lists.

Creating a playlist

- Select [**Options**] in the **Library** tab.
- Select **Create playlist**.
- Type a name for your playlist and press **OK**.
- Select the sound you want in your playlist and press **OK** to add the music to the playlist ; do it again if you want add others or select **Playlist: [Options]/Add to playlist/All** to add them all to the playlist.

When pressing [**Options**] on a playlist, you can display or play the contents, add music, create a new playlist, delete one or modify its name.

Playing your music

Player tab: This tab opens as soon as a music or a list of music, has been selected to be played.

To display the different options, press [**Options**]:

- **Play**: to play musics of the playlist.
- **Remove from list**: to remove the music selected from the playlist.
- **Shuffle**: to play the musics in a random way.
- **Add to Playlist**: to set a new playlist.
- **Play options**: to play the musics one by one or in a continuous way.
- **Send via IrDA**: to send the music by IrDA.
- **Rename**: to rename the music.
- **Details**: properties of the music selected.




Phone

Silent mode

This menu allows you to switch to Silent mode.

Activate or **deactivate** Silent mode and validate.

Silent mode can also be accessed via the idle screen by holding down the **⌘** ↵ key.

 *When the phone is in silent mode, this relevant icon appears on the idle screen.*

In this mode, the ring tone will not function, except for the alarm clock.

Note: if you have activated the silent mode, it does not remain after switching off your phone.

Ringtone

This menu allows you to allocate a ringtone to different functions.

Select the function on which you want to choose a ringtone.

Select the ringtone from the proposed list and validate.

Note: in the list, there are the phone default ringtones and also the ringtones downloaded in **My Files/Sounds**.

Adjust the volume with the **▲** and **▼** keys or side keys from idle screen and validate.

*You can deactivate the sound by pressing the **⌘** ↵ key.*

Vibrate

This menu allows you to activate the vibrate mode for calls.

Select the vibrate mode from the proposed choices and validate.

Languages

This menu allows you to choose your phone's display language.

Select your language and validate.

If you select **Automatic**, the language used will be the one relative to your SIM card.

Beeps

This menu allows you to activate a beep for the battery, the keypad or the network.

Select the type of beep you want to allocate from the proposed choices and validate. Activate or deactivate the beep and validate.

If you select keypad beeps, different options are given.

Master Reset

This menu allows you to reset the phone parameters.

Time and Date

Set Date/Time

This menu allows you to set the date and time of your phone.

- **Date:** set the date by entering it directly in digital form or by using ▼ or ▲.
Use the ◀ or ▶ keys to access the next (or previous) entry field.
Once the date is correct, validate it.
- **Time:** same procedure as for setting the date.

Date update

This menu allows you to choose manual or automatic updating of date and time (after switch off of your phone or when going abroad for instance) (service depending on the network).

Please select Automatic, Manual or On demand and press **OK**.

View

This menu allows you to select the date and time display.

In the list that appears, select the desired display type between:

- Analog,
- Digital,
- None,

and validate.

Time zone

This menu allows you to change time in relation to the GMT time.

Choose the time of the country desired by calculating the time from the GMT time.

Daylight savings

This menu allows you to set your phone to the summer/winter time.

Select 1 h, 2 h **Summer time** or **Winter time** depending on the season, and validate.

Shortcuts

This menu allows you to allocate functions to the directional keys of the navigator, the **OK** key and for **Speed Dialing** function (see on page 20 for the latter function).

Display

Wallpaper

This menu allows you to display the background picture you want on your phone.

Note: you can select wallpapers through the phone default wallpapers, the pictures downloaded in **My Files/Pictures** and the pictures of your memory card.

- *No wallpaper:* select **None**.
- *Several wallpapers in a random way:* select **Random**.
- *A specific wallpaper:* select **My Files**:
 - Press **[Select]** on the wallpaper name, the wallpaper is selected.
or
 - Press **OK**: the picture is displayed. Press **[Select]** to select it as your phone wallpaper or press ▲ and ▼ keys to display others.

Operator logo

This menu allows you to display your operator's logo on the idle screen.

On the menu, please select the menu and **[Select]**.

Select **Activate** or **Deactivate** and press **[OK]**.

Screensaver

This menu allows you to display an animation when the phone is in standby mode.

Select one of the screensavers given and **[Select]**.

Note: there are the phone default screensavers and also the pictures downloaded in **My Files/Pictures**.

The chosen screensaver appears on the screen, select it.

Energy saving

Eco mode

You can select one of the following eco modes:

- **Complete**: the screen is off. Press **OK**, the red or green key to turn on the backlight and see the time. Press * **OK** to light up the screen and enter the menus. This mode gives the maximum efficiency of the battery life.
- **Partial**: the screen is off. Press the red key to light up the screen and enter the menus.
- **Unlocked key.**: the keypad is always active, meaning that when you press any key, it allows you to light up the screen and enter the menus. This mode decreases the battery life.

Backlight

- **Full backlight**: both the screen and the keypad are lit up.
- **Screen only**: only the screen is lit up.

Note: in any case, after a certain time of inactivity, the backlight will be automatically turned off to save battery life.

Contacts

- **Contacts list**: This menu allows you to select the default phonebook (SIM, Phone, SIM and Phone) displayed when the phone switches on.
- **Sorting**: This menu allows you to select the way to sort contacts in the phonebook (by name or first name).

Contrast

This menu is used to adjust screen contrast.

Adjust the contrast using the navigation stick.

Messaging

This menu allows you to set SMS or MMS sending options and to enter the voicemail number (see chapter page 28).

Connectivity

You can exchange with other devices (PC, mobile phones, personal assistants, printers, etc.) various data: pictures, sounds, photos, videos, Todo tasks, organiser events, contacts, etc.

Data exchange can be done through:

- a serial or USB cable,
- an infrared connection,

If you have inserted a memory card in your phone, it is considered as an additional memory in the Windows explorer files directory; you can copy/paste.

If you want to exchange objects between the phone memory and a PC, you must install the Wellphone software provided on CD: select Multimedia to open, from the PC, the phone files explorer.

To save contacts, events or tasks, the Wellphone Multimedia software must be installed on a PC: configure the connection parameters of your computer using the Wellphone CD supplied as an accessory (also available from <http://www.wellphone.com>).

Note: If a call comes in during an exchange of data with your PC, the link will be interrupted and will have to be manually re-started.

Infrared

This menu allows you to activate or deactivate the infrared connection.

Serial Speed

This menu enables you to select the speed to be used for data exchanges via your phone's serial port. Except for specific requirements, it is advisable to stick to the default setting: **Automatic**.

Car kit

Car kit - Headset

These menus allow you to configure the options of the phone with a pedestrian kit or a car kit.

Synchronize

You can synchronize your phonebook, your organizer or your To Dos with your archives stored in Vodafone's network depending on the options offered by your subscription.

The local synchronisation with your computer is only computer originated, from Wellphone software; you have only to activate infrared or configure your USB connection in your phone.

USB Mode

This menu allows you to select a mode to connect the phone to a peripheral with the USB cable available as an accessory.

- **PictBridge:** to connect the phone to a printer (printing photos) without using a PC.
- **At Plugging-in:** If you select this option, when connecting a USB cable, the phone asks you to select the mode you want (**Modem** or **PictBridge**).
- **Modem:** to exchange data between the phone memory and a PC.

Calls

Call divert

Depending on your subscription, this service allows you to forward incoming calls to a different number or to the voicemail. Choose the type of forwarding you want from the options available.

Counters

This menu allows you to consult the duration of the up calls. It can also be used to check the volume of data exchanged in GPRS. Select one of the options given.

Display numbers

This menu allows you to modify the status of the display number function. Select one of the options given: Anonymous mode, My number, Callers' number.

Anonymous mode

You have the ability to mask your number on the phone of the person you are calling.

- **Preset:** network default mode.
- **No:** you choose not to activate anonymous mode and then to display your number.
- **Yes:** you choose to active anonymous mode and then not to display your number.

Call waiting

(Network dependent service)

During a call, you may be informed that a caller is trying to reach you: you hear a special tone. The caller's identity is displayed on the screen (name or number).

You can **activate, deactivate, or status** of the call waiting service in order to check if it is active or not. During a call, if a second caller tries to contact you, the screen displays the call warning.

Automatic redial

This menu allows you to call back a caller you have not managed to reach.

You can set the redial function to inactive, on request or systematic.

If you choose **On demand**, your phone will offer to redial your caller automatically if his number is busy.

Blacklist

The blacklist is used to limit failures on automatic calls (calls generated by the automatic redial function or by applications: data, fax for example).

When several automatic calls failed with a number (number busy or unknown), this number is put in the blacklist and no automatic call will be done with this number any more until you delete it from the blacklist.

Note: this function does not apply to the calls performed manually.

Voicemail

This is used to store your voicemail access number.

Save number

When calling, if you want a prompt asks you to save the number in the phonebook, select **Activate**.

Networks

This menu allows you to configure network preferences.

Choose **Selection** to activate (automatically or manually) one of the networks accessible in the area in which you are located.

Choose **Preferred** to view all the pre-registered networks.

Choose **GPRS** to select the way you want to be attached on the GPRS network: always, or only when needed (when launching a data connection).

Choose **Network type** to select your network: GSM-DCS or PCS (depending on model).

Security

PIN number

This menu allows you to activate and modify your phone's PIN.

To modify the PIN, select **Modify PIN code** and **[Select]**.

Enter old PIN and validate.

Enter new PIN twice and validate.

To activate or deactivate the PIN, select the **Control PIN** menu and **[Select]**.

Enter PIN and validate.

Select **Activate** or **Deactivate** and validate.

PIN 2 number

You have a second PIN number to allow you to access certain functions ().*

Proceed as above in order to activate, deactivate or modify PIN 2 number of your phone.

Phone code

The Phone code menu allows you to activate the phone code so that it is requested and checked whenever the phone is switched on if a different SIM card is used. This code is automatically linked to the SIM card installed when the phone is activated, for example to protect the phone if stolen.

Select **Check** and [**Select**].

Enter 0000 (the factory code, by default) and validate.

Select **Activate** or **Deactivate** and validate.

To modify the phone code, select **Modify** and validate.

Enter old phone code and validate.

Enter new phone code and validate.

Enter phone code again to confirm it and validate.

Confidentiality

This menu allows the activation or deactivation of automatic deletion, after power off/on, of outgoing calls, messages stored or organizer events.

Select **Activate** or **Deactivate** and validate.

Operator

This menu allows you to modify the call barring.

Access to this service depends on your type of subscription.

(*) *These functions may or may not be available depending on your SIM card.*

Call barring

This menu allows you to block the sending or receiving of certain calls.

Before you can use this service, a password will be provided by Vodafone when you take out your subscription.

Access to this service depends on your subscription type.

To activate call barring :

- Select incoming or outgoing calls.
- Select the call type on which you want to activate call barring.
- Select:
 - either All,
 - or If roaming, if you are away from your home country and if roaming is available, only incoming calls will be blocked.
- Select Activation and enter password.

Fixed dialling

This menu allows you to restrict the outgoing calls.

The availability of this menu depends on your SIM.

Enter PIN2 number and validate.

Select **Activate** or **Deactivate** and validate.

Proceed as for any other phonebook.

When activating this function, only the numbers stored in the phonebook can be called.

This phonebook is linked to the SIM card, and its size depends on the card's capacity.

Cost

This menu allows you to control the cost of your calls ().*

The **Cost** menu (*) lets you check the cost of the last call you made and of all the calls you made since you last deleted them.

The **Delete costs** menu (*) lets you delete the cost of your last call and reset the cost counter after entering your PIN 2 code.

Player Settings

- **Play options:** to play the music one by one or in a continuous way.

(*) **WARNING** - *Depending on how the networks and associated subscription cards are configured, some functions may be unavailable (these are marked out with *).*

Browser

This menu allows you to set various parameters needed for Vodafone live! browser connection. You can add or modify URL addresses.

Camera

This menu allows you to set the camera features of your phone.

- **Timer duration:** this menu enables you to take a photo with a 5, 10 or 15 second time delay.
- **Click sound:** This menu allows you to select the sound you will hear when taking a photo.
- **Photo format:** This menu allows you to choose the format in which your photo will be saved.
- **Photo quality:** This menu allows you to select the photo quality.

Video

This menu allows you to set the video features of your phone.

- **Video sound:** This menu allows you to select whether or not to record the sound when taking a video.
- **Video restriction:** This menu allows you to choose a video size.

Technical features

Weight: 84 g

Size: 105 x 46 x 14 mm

Original battery: Lithium ion 850 mAh

Battery life calls/standby: up to 4 h/350 h (these values are theoretical ones and given for information only)

Multimedia objects supported:

- Audio formats: iMelody, Midi, wave, AMR, MP3, AAC
- Video formats: 3gp, svg
- Graphic formats: wbmp, bmp, png, gif, animated gif, jpeg

Size of memory available for messages: up to 200 SMS

Size of memory available for the phonenook and the multimedia objects: 12.0 MB

Maximum size of each message:

- SMS < 160 characters
- MMS < 100 kB for outgoing, 100 kB for incoming messages (depends on the phone configuration and Vodafone reservations)

Using temperature: from - 10°C to + 55°C

Déclaration CE de Conformité

Fabricant **Sagem Communication**
Manufacturer

Adresse **Le Ponant de Paris**
Address 27 rue Leblanc - 75512 Paris cedex 15 - FRANCE

Déclare sous sa responsabilité que le produit
Declares under our sole responsibility that our product

Nom du produit Tri-Band GSM/DCS/PCS - D2005R2 (my400V)
Product Name

est conforme aux exigences des directives européennes suivantes :
conforms to the requirements of the following EEC directives:

EEC Directive 1999/5/CE

Sécurité (Safety) **EN 60950**


CEM (EMC) **EN 301 489-1**
 EN 301 489-7

Réseau (Network) **3GPP TS 51.010-1 v 6.5.0 avec GCF-CC v 3.19.0 inclus**
(3GPP TS 51.010-1 v 6.5.0 selected with GCF-CC v 3.19.0 included)
EN 301 511 V9.0.2

Santé (Health) **EN 50360, EN 50361**

Lieu et date
(Place and date of issue)

Signature

Geoff St Christophe - January 16th, 2006


Care and safety information

SAR

THIS MODEL MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 1.25 W/kg (*). As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide (**).

As SAR is measured utilizing the devices highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a 'hands-free' device to keep the mobile phone away from the head and body. Additional information can be found on the websites of the World Health Organization (<http://www.who.int/emf>)

Advice for limiting exposure to radiofrequency (RF) fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organization (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's' RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page <http://www.who.int/peh-emf> WHO Fact sheet 193: June 2000.

(*) *The tests are carried out in accordance with international guidelines for testing.*

(**) *Please see the Distance of operation section about body worn operation, on page 54.*

Safety

Never attempt to disassemble your phone. You alone are responsible for how you use your phone and any consequences of its use.

As a general rule, always switch off your phone wherever the use of a phone is prohibited.

Use of your phone is subject to safety measures designed to protect users and their environment.

Do not use your phone in damp areas (bathroom, swimming pool...). Protect it from liquids and other moisture.

Do not expose your phone to extreme temperatures lower than - 10°C and higher than + 55°C.

The physicochemical processes created by chargers impose temperature limits when charging the battery. Your phone automatically protects the batteries in extreme temperatures.

Do not leave your phone within the reach of small children (certain removable parts may be accidentally ingested).

Electrical safety

Only use the chargers listed in the manufacturer's catalogue. Using any other charger may be dangerous; it would also invalidate your warranty. Line voltage must be exactly the one indicated on the charger's serial plate.

Aircraft safety

When travelling by plane, you will need to switch your phone off when so instructed by the cabin crew or the warning signs.

Using a mobile phone may be dangerous to the operation of the aircraft and may disrupt the phone network.

Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by these regulations.

Explosive materials

Please comply with warning signs at petrol station asking you to switch your phone off. You will need to comply with radio equipment usage restrictions in places such as chemical plants, fuel depots and at any location where blasting operations are under way.

Electronic equipment

To avoid the risk of demagnetisation, do not let electronic devices close to your phone for a long time.

Electronic medical equipment

Your phone is a radio transmitter which may interfere with electronic medical equipment or implants, such as hearing aids, pacemakers, insulin pumps, etc. It is recommended that a minimum separation of 15 cm be maintained between the phone and an implant. Your doctor or the manufacturers of such equipment will be able to give you any advice you may need in this area.

Hospitals

Always make sure that your phone is switched off in hospitals when so instructed by warning signs or by medical staff.

Road safety

Do not use your phone when driving. In order to give your full attention to driving, stop and park safely before making a call. You must comply with any current legislation.

Distance of operation

This phone model has been tested and meets radiofrequency exposure guidelines when used as follows:

- **against the ear:** place or receive a phone call and hold the phone as you would a wireline telephone,
- **body worn:** when transmitting, place the phone in a carry accessory that contains no metal and positions the phone a minimum of 2.5 cm from your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory and are not holding the phone at the ear, position the phone a minimum of 2.5 cm from your body,
- **data operation:** when using a data feature, position the phone a minimum of 2.5 cm from your body for the whole duration of the data transmission.

Environment

Packaging

To facilitate the recycling of packaging materials, please obey the sorting rules instituted locally for this type of waste.

Batteries

Spent batteries must be deposited at the designated collection points.

The product



The crossed-out waste bin mark affixed to the product means that it belongs to the family of electrical and electronic equipment.

To promote the recycling and recovery of waste electrical and electronic equipment (WEEE) and at the same time safeguard the environment, European regulations require you to obey the sorting rules instituted locally for this type of waste.

Warranty

You must always use your phone for the purpose for which it was designed, under normal operating conditions. Sagem Communication declines all responsibility for any use outside of the scope of its designed purpose and for any consequences of this use.

Any software program in the phone is either the exclusive property of Sagem Communication or is licensed to Sagem Communication by third parties. It is therefore highly prohibited to modify, translate, decompile or disassemble this software program or any part thereof.

Use precautions

Your phone allows you to download ringtones, icons and animated screen savers. Some of these items may contain data that may cause malfunctions of your phone or data losses (virus for example).

For this reason, Sagem Communication rejects all responsibility concerning (1) the reception of downloaded data or losses of the said data, (2) the impact on the operation of the phone and (3) damages resulting from receiving the said downloaded data or loss of said data. In addition, Sagem Communication states that a failure caused by receiving downloaded data that do not comply with the specifications set by Sagem Communication is excluded from the warranty.

Consequently, the diagnosis and repair of a phone infected by the said downloaded data will be at the expense of the customer.

Any content that you download to your phone may be protected by copyright belonging to third parties and consequently you may not have the right to use this content or its use may be restricted.

Consequently it is up to you to ensure that you have permission, such as under the terms of a license agreement, to use any content that you download. Furthermore, Sagem Communication does not guarantee the accuracy nor the quality of any content that you download. You alone are responsible for the content that you download to your mobile phone and how you use it. Sagem Communication cannot be held responsible for this content nor for its use. It is your responsibility to ensure compliance, at your own expense, with the laws and regulations applicable in the country where you use your phone.

Warranty conditions

Whenever you wish to make use of the warranty, please contact your vendor and present him/her with the purchasing paperwork that he/she gave you. If a fault occurs, your vendor will advise you.

1. The new phone (excluding consumables), including new accessories bundled with the phone, are guaranteed by Sagem Communication, parts and labour (apart from travel) against any manufacturing fault for a period of twenty four months (except for batteries for which the period is twelve months) with effect from the sale of the phone to the customer, on presentation of the paperwork stating the purchase date of the phone.

Phones that have been repaired or replaced as standard during the warranty period stated above are guaranteed (parts and labour) until the later of these two dates:

Expiry of the guarantee period of twenty four months stated above or three (3) months with effect from the date of support provided by Sagem Communication.

Your legal rights under the terms of applicable national law as well as your rights in relation to your retailer, as set out in the sales contract, remain applicable and are not in any way affected by this guarantee.

In any disputes, the phone is covered by the legal warranty against the consequences of faults or hidden defects in compliance with articles 1641 and subsequent of the French civil code.

2. All faulty phones under warranty will be replaced or repaired free of charge at Sagem Communication's option (with the exclusion of repair of any other damage), including transport costs between Sagem Communication authorised repair centre and the point of sale. Transport costs between the End User and the point of sale will be borne by the End User. Subject to essential legal provisions, Sagem Communication does not accept any warranty, explicit or implicit, other than the warranty provided expressly in this chapter, nor shall Sagem Communication accept responsibility for any immaterial and/or indirect damages (such as loss of orders, loss of profit or any other financial or commercial damage) under the warranty or not.

3. The acceptance of a phone under warranty demands that a purchase document that is legible and without modification, stating vendor's name and address, date and place of purchase, type of phone and IMEI, are attached to the warranty, and that the information on the phone identification label is legible and that this label or any other seal has not been tampered with.

The warranty applies in normal conditions of use. Prior to sending the phone for repair, it is the customer's responsibility to back up at his expense the customised data stored in the phone (phonebook, settings, wallpapers). A list of backup facilities can be provided by Sagem Communication on request. The responsibility of Sagem Communication cannot be invoked if damage occurs to customer files, programs or data. The information or operating elements and the contents of files will not be re-installed in any case in the event of loss.

Sagem Communication may decide, at its option, to repair the phone with new or reconditioned parts, replace the phone with a new phone or, in any dispute, a phone in good working condition. During its work Sagem Communication reserves the facility to make, where necessary, any technical modifications to the phone where these modifications do not adversely affect its initial purpose. Faulty parts to be replaced during a repair under warranty will become the property of Sagem Communication. The phone repair and standstill time during the warranty period may not lead to an extension of the warranty period as stated in article 1, provided no other vital provisions have been agreed.

The application of the warranty is subject to the full payment of the sums due for the phone when the request for support is made.

4. The following are excluded from the warranty:

Breakdowns or malfunctions due to non-compliance with the installation and use instructions, to an external cause of the phone (shock, lightning, fire, vandalism, malice, water damage of any type, contact with various liquids or any harmful agent, unsuitable electric current...), to modifications of the phone made without the written consent of Sagem Communication, to a servicing fault, as described in the documentation supplied with the phone, to lack of supervision or care, to poor environmental conditions of the phone (especially temperature and humidity, effects of variations in electric voltage, interference from the mains network or earth) or even due to a repair, a call-out (opening or trying to open the phone) or to servicing done by personnel not approved by Sagem Communication.

Damage resulting from inadequate packaging and/or poor packing of the phone sent back to Sagem Communication.

Normal wear and tear of the phone and accessories.

Communication problems linked with a poor environment, especially:

Problems accessing and/or logging onto the Internet, such as breakdowns of the access network, the failure of the subscriber's or his/hers correspondent's line, transmission fault (poor geographic coverage by radio transmitters, interference, disturbance, failure or poor quality of phone lines...), a fault inherent to the local network (cabling, file server, user phone) and/or transmission network fault (interference, disturbance, failure or poor quality of the network...).

Change of parameters of the cellular network made after the phone was sold. Current servicing work: delivery of consumables, installation or replacement of these consumables... Call-outs for phone or software modified or added without the written consent of Sagem Communication.

Faults or disruptions resulting from the use of products or accessories not compatible with the phone. Phones returned to Sagem Communication without having complied with the return procedure specific to the phone covered by this warranty. The opening or closing of a SIM operator key and call-outs resulting in the non-operation of the phone resulting from the opening or closing of SIM operator key done without the agreement of the original operator.

5. In the cases of warranty exclusion and of expiry of the warranty period, Sagem Communication shall draw up an estimate to be given to the customer for acceptance before any call-out. The repair and carriage costs (there and back) given in the accepted estimate will be charged to the customer. These provisions are valid unless a special written agreement has been made with the customer. If one of the provisions turns out to infringe a legally essential rule that consumers could have the benefit of under the national legislation, this provision will not be applied, but all other provisions will remain valid.

End User Licence Agreement (EULA), for the software

CONTEXT AND ACCEPTATION OF THE AGREEMENT

You have acquired a Mobile Phone device ("DEVICE"), manufactured by Sagem Communication (SAGEM), that includes software either developed by SAGEM itself or licensed third party Software suppliers ("SOFTWARE COMPANIES") to SAGEM with the rights to sub-license it to the purchaser of the device. Those installed software products whatever their company of origin, and wherever the name of the company of origin is indicated or not in the DEVICE documentation, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.

IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE DEVICE OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT SAGEM FOR INSTRUCTIONS ON RETURN OF THE UNUSED DEVICE(S) FOR A REFUND. **ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICE, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).**

SOFTWARE includes software already installed on the DEVICE ("DEVICE Software") and Software contained on the CD-ROM disk ("Companion CD"), if any is supplied with the product.

GRANT OF SOFTWARE LICENCE

This EULA grants you the following licence:

DEVICE Software. You may use the DEVICE Software as installed on the DEVICE. All or certain portions of the DEVICE Software may be inoperable if you do not have and maintain a service account with an appropriate Mobile Operator, or if the Mobile Operator's network facilities are not operating or configured to operate with the DEVICE software.

COMPANION CD. If any is supplied, additional software for your personal computer is included with your DEVICE. You may install and use the software component(s) contained in the Companion CD only in accordance with the terms of the printed or online end user license agreement(s) provided with such component(s). In the absence of an end user license agreement for particular component(s) of the Companion CD, you may install and use only one (1) copy of such component(s) on the DEVICE or a single computer with which you use the DEVICE.

Security Updates. The SOFTWARE may include digital rights management technology. If SOFTWARE does contain digital rights management technology, content providers are using the digital rights management technology ("DRM") contained in the SOFTWARE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Owners of such Secure Content ("Secure Content Owners") may, from time to time, request manufacturers or SOFTWARE SUPPLIERS to provide security related updates to the DRM components of the SOFTWARE ("Security Updates") that may affect your ability to copy, display and/or play Secure Content through the SOFTWARE or third party applications that utilise the DRM.

You therefore agree that, if you elect to download a licence from the Internet which enables your use of Secure Content, Suppliers may, in conjunction with such licence, also download onto your DEVICE such Security Updates that a Secure Content Owner has requested that SOFTWARE SUPPLIERS distribute. SAGEM and SOFTWARE SUPPLIERS will not retrieve any personally identifiable information, or any other information, from your DEVICE by downloading such Security Updates.

DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

COPYRIGHT. All title and intellectual property rights in and to the SOFTWARE (including but not limited to any images, photographs, animations, video, audio, music, text and "applets," incorporated into the SOFTWARE), the accompanying printed materials, and any copies of the SOFTWARE, are owned by SAGEM or the SOFTWARE SUPPLIERS. You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants you no rights to use such content. All rights not specifically granted under this EULA are reserved by SAGEM and the SOFTWARE SUPPLIERS

Limitations on Reverse Engineering, Decompilation and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

Single DEVICE. The DEVICE Software is licensed with the DEVICE as a single integrated product. The DEVICE Software installed in the memory of the DEVICE may only be used as part of the DEVICE.

Single EULA. The package for the DEVICE may contain multiple versions of this EULA, such as multiple translations and/or multiple media versions (e.g., in the user documentation and in the software). Even if you receive multiple versions of the EULA, you are licensed to use only one (1) copy of the DEVICE Software.

Software Transfer. You may not permanently transfer any of your rights under this EULA with regard to the DEVICE Software or Companion CD, except as permitted by the applicable Mobile Operator. In the event that the Mobile Operator permits such transfer, you may permanently transfer all of your rights under this EULA only as part of a sale or transfer of the DEVICE, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, this EULA and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the SOFTWARE is an upgrade, any transfer must include all prior versions of the SOFTWARE.

Software Rental. You may not rent or lease the SOFTWARE.

Speech/Handwriting Recognition. If the SOFTWARE includes speech and/or handwriting recognition component(s), you should understand that speech and handwriting recognition are inherently statistical processes; that recognition errors are inherent in the processes; and that errors can occur in the component's recognition of your handwriting or speech, and the final conversion into text. Neither SAGEM nor its suppliers shall be liable for any damages arising out of errors in the speech and handwriting recognition processes.

NOTICE REGARDING THE MPEG-4 VISUAL STANDARD. The SOFTWARE may include MPEG-4 visual decoding technology. MPEG LA, L.L.C. requires the following notice:

USE OF THIS SOFTWARE IN ANY MANNER THAT COMPLIES WITH THE MPEG-4 VISUAL STANDARD IS PROHIBITED, EXCEPT FOR USE DIRECTLY RELATED TO (A) DATA OR INFORMATION (i) GENERATED BY AND OBTAINED WITHOUT CHARGE FROM A CONSUMER NOT THEREBY ENGAGED IN A BUSINESS ENTERPRISE, AND (ii) FOR PERSONAL USE ONLY; AND (B) OTHER USES SPECIFICALLY AND SEPARATELY LICENSED BY MPEG LA, L.L.C.

If you have questions regarding this Notice, please contact MPEG LA, L.L.C., 250 Steele Street, Suite 300, Denver, Colorado 80206; Telephone 303 331.1880; FAX 303 331.1879

Termination. Without prejudice to any other rights, SAGEM may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.

Consent to Use of Data. You agree that SOFTWARE SUPPLIERS may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. SOFTWARE SUPPLIERS may use this information solely to improve their products or to provide customised services or technologies to you. SOFTWARE SUPPLIERS may disclose this information to others, but not in a form that personally identifies you.

Internet Gaming/Update Features. If the SOFTWARE provides, and you choose to utilise, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorise SOFTWARE SUPPLIERS to use this information solely to improve their products or to provide customised services or technologies to you. SOFTWARE SUPPLIERS may disclose this information to others, but not in a form that personally identifies you.

Internet-Based Services Components. The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that SOFTWARE SUPPLIERS may automatically check the version of the SOFTWARE and/or its components that you are utilising and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your Device.

Links to Third Party Sites. The SOFTWARE may provide you with the ability to link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of SAGEM. Neither SAGEM nor its affiliates are responsible for (i) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by SAGEM or its affiliates.

Additional Software/Services. The SOFTWARE may permit SAGEM to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").

If SAGEM provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.

SAGEM reserves the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.

EXPORT RESTRICTIONS. You acknowledge that SOFTWARE is subject to U.S. export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments.

UPGRADES AND RECOVERY MEDIA

- **DEVICE Software.** If the DEVICE Software is provided by SAGEM separate from the DEVICE on media such as a ROM chip, CD ROM disk(s) or via web download or other means, and is labelled "For Upgrade Purposes Only", you may install one copy of such DEVICE Software onto the DEVICE as a replacement copy for the existing DEVICE Software and use it in accordance with this EULA, including any additional EULA terms accompanying the upgrade DEVICE Software.
- **COMPANION CD.** If any Companion CD component(s) is provided by SAGEM separate from the DEVICE on CD ROM disk(s) or via web download or other means, and labelled "For Upgrade Purposes Only", you may (i) install and use one copy of such component(s) on the computer(s) you use to exchange data with the DEVICE as a replacement copy for the existing Companion CD component(s).

RESPONSIBILITIES

SUPPORT AND INFORMATION Should you have any questions concerning this EULA, or if you desire to contact SAGEM for any other reason, please refer to the address provided in the documentation for the DEVICE.

NO LIABILITY FOR CERTAIN DAMAGES. EXCEPT AS PROHIBITED BY LAW, SAGEM SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

FOR APPLICABLE LIMITED WARRANTIES AND SPECIAL PROVISIONS PERTAINING TO YOUR PARTICULAR JURISDICTION, PLEASE REFER TO YOUR WARRANTY BOOKLET INCLUDED WITH THIS PACKAGE OR PROVIDED WITH THE SOFTWARE PRINTED MATERIALS.

You are the owner of a SAGEM mobile phone which gives you the ability to download applications and games to be executed on your phone thanks to the built-in Java™ engine.

However, receiving applications from everywhere implies some basic knowledge of the possible effects of such download.

Thank you for spending a few minutes reading these pages: this will prevent you from performing action without measuring the consequences.

WARNING: *When running a Java™ application, you may be prompted to grant access to protected features. These features are protected because using them could incur you cost, or involve your personal data. Read the security popup message carefully, to understand what feature is requested, and decide whether it is legitimate for the application to perform it. In case of doubt, don't hesitate to refuse access by selecting the "No" button!*

The security configuration menu is an expert feature! You must know exactly what you are doing before attempting to change security parameters of a MIDlet. Misunderstanding changes may render MIDlet non functional and/or lead to higher risks for your private data or impact your airtime consumption. Any changes in the security configuration are done under your responsibility. In no case shall Sagem Communication and/or your network provider be liable for any damages deriving from or arising out of such changes in the security configuration.

You must be aware that applications downloaded to your phone could cause the phone to perform actions for which you will be billed, like making calls and sending SMS. Depending on your operator's billing policy, you may also be charged to download the application because of airtime consumption.

Security considerations

Java™ MIDP technology is an efficient way to provide powerful applications in mobile phones. It allows use, by "over the air" downloaded applications or games, of the great features built-in in a mobile phone (SMS sending and receiving, multimedia playback and recording, network access...).

All these MIDP 2.0 features cannot be simply exposed to any MIDlet installed in the handset: a careful access control system is implemented in the device to protect your private data and airtime consumption.

Access controls are gathered in 9 security groups:

- Network access (GPRS/GSM data airtime consumption, HTTP/web connections...)
- Auto invocation (MIDlet can wake up at a given time or when receiving a SMS)
- Phone call (ability to initiate a phone call)
- Local connectivity (IrDA or serial interfaces use by the MIDlet)

- Messaging receive (SMS,SMS-CB interception by a MIDlet)
- Messaging sending (SMS sending by a MIDlet)
- Read User data (Subscriber identity, Phonebook, Agenda read access from a MIDlet)
- Write User data (New phonebook or agenda entry)
- Multimedia recording (ability to control camera or microphone from a MIDlet)

According to the security status of an installed MIDlet (see below), each of these security groups has one among 5 possible authorizations levels (listed from the more restrictive to the more permissive):

- Never
The security group completely prevents access to the protected features.
- Per use
Each time MIDlet tries to use protected feature, user is prompted to grant access.
- Per session
First time a MIDlet uses a protected function, user is prompted to grant access like in "Per use" authorization but access is granted until the MIDlet terminates.
- Single confirmation
The first time in the whole MIDlet life a MIDlet uses a protected feature, user is prompted to grant access. It remains valid until the MIDlet is removed from the handset.
- Always
The security group unconditionally grants access to protected features.

A MIDlet has a security status which is either "uncertified", or else "certified".

An "uncertified" status means that the source of the MIDlet could not be verified by the mobile phone at installation time. As far as the phone knows, the MIDlet could have been written by anyone.

A "certified" status means that the MIDlet was digitally signed by a known party, whose name is displayed by the mobile phone. This means that the mobile phone successfully authenticated the named party as the source of the MIDlet.

Security permissions are different for "uncertified" or "certified" MIDlets, and may be different for different sorts of named parties. Usually "uncertified" security permissions are more restrictive than "certified" ones.

Security configuration menu

When a MIDlet is installed in the mobile phone, default security authorizations are applied.

This default security configuration may be altered through the "Settings/Security" menu of an installed MIDlet.

Once in the "Security" menu, the security status of the MIDlet is displayed (see "Security considerations" paragraph above).

If you do not want to enter the security menu, simply select "Back" button.

You can proceed by selecting "Ok" button.

The menu displayed allows you to increase or decrease permissions currently applied to the current MIDlet for each of the security groups.

When you set a more permissive authorization to a security group than the current value, mobile phone asks you to confirm your increased risk exposure.

The maximum risk exposure increase is limited by the security status. Depending of the manufacturing configuration, it means, for example, that "Net Access" security group authorization cannot be set to a permissive value higher than "Session" for an "uncertified" MIDlet ("Single confirmation" and "Always" are unavailable in the security configuration menu) but an operator "certified" MIDlet may have all permission values available without any limitations.



What is Java™?

Java™ is a new technology enabling use of powerful applications in the mobile phone area. Business applications and games are easily downloadable by the end-user on a Java™ featured handset.

Your mobile phone is a MIDP 2.0 compliant Java™ platform which implements WMA (SMS support) and MMAPI (Multimedia support) options, providing an exciting environment to run highly graphical, networked and intuitive MIDP applications.

Such applications may be, for example, a wide range of games and appealing applications like action and logic games, agenda, e-Mail reader, Web browser...

What is a MIDlet?

A Java™ application or a game designed to run in a mobile phone is named a MIDlet (MIDP applet). A MIDlet is usually made of 2 files:

- The JAD file
- The JAR file

JAD file stands for **J**ava™ **A**pplication **D**escriptor. It is a small file describing the content of a JAR file (version, vendor name, size...) and displayed by the mobile phone. **JAD file size is usually less than**

2 kilo-bytes large.

JAR file stands for Java™ **A**rchive. It refers to the application data themselves (program, images, sound). **A JAR file may be up to 200 kilo-bytes large.**

NOTE: *In rare circumstances, MIDlet vendors may provide no JAD file and the MIDlet is the JAR file alone. In such a case it is your only responsibility to evaluate the risk to download the JAR file without possibility of consulting the JAD file.*

Downloading a MIDlet (Java™ game or application)

MIDlets are easily downloaded in the mobile phone through the Games or Applications menus or through the WAP browser.

In almost all cases, you will first receive a JAD file which will be displayed on the screen.

Much care must be given in examining the content of the file as explained further.

When you select a JAD file, your mobile phone downloads it, displays data contained and prompts you to acknowledge the JAR file download.

The popup displays information below:

- Name of the MIDlet
- Version
- Size (JAR file size)
- Vendor name
- Security status (**IMPORTANT**: see "Security considerations" paragraph below)
- JAR file URL.

If you do not want to download the main data (JAR file), you shall refuse to acknowledge further airtime consumption by selecting "Cancel" (JAR file is not downloaded).

If you agree on the MIDlet installation, just select "Ok". The MIDlet is installed with security levels set to default values associated with its security status.

Before downloading an application, such a message may appear: "Your handset cannot identify the application, please be sure of the source of the application before installing the application".

You shall read carefully the next two paragraphs to fully understand Java™ MIDP security concerns.

Trademarks

Java™ and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Disclaimer

As explained hereabove, some downloaded items may contain data or may induce actions which may cause malfunctioning of your mobile phone or loss or corruption of data or abnormal increase of your airtime consumption.

YOU EXPRESSLY ACKNOWLEDGE THAT THE DOWNLOAD OF ANY APPLICATIONS INCLUDING JAVA APPLICATIONS OR GAMES IS DONE UNDER YOUR EXCLUSIVE RESPONSIBILITY. IN NO EVENT SHALL SAGEM COMMUNICATION, YOUR NETWORK SERVICE PROVIDER OR THEIR AFFILIATES BE LIABLE FOR ANY LOSS PROFITS OR COSTS OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, LOSS OF PROFITS, INTERRUPTION OF BUSINESS, LOSS OF DATA OR FOR ANY SPECIAL, INDIRECT, INCIDENTAL, ECONOMIC, OR CONSEQUENTIAL DAMAGES ARISING UNDER CONTRACT, TORT, NEGLIGENCE, OR OTHER THEORY OF LIABILITY RELATING TO THE DOWNLOAD OF ANY APPLICATION BY ANY MEANS, INCLUDING JAVA APPLICATIONS OR GAMES IN SAGEM DEVICES. YOU EXPRESSLY ACKNOWLEDGE THAT ANY APPLICATIONS INCLUDING JAVA APPLICATIONS OR GAMES ARE PROVIDED STRICTLY "AS IS". SAGEM COMMUNICATION AND/OR YOUR NETWORK SERVICE PROVIDER EXTEND NO WARRANTY WHATSOEVER THERETO. SAGEM COMMUNICATION AND/OR YOUR NETWORK SERVICE PROVIDER DISCLAIM ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY OF MERCHANTABILITY, FITNESS OF ANY APPLICATIONS INCLUDING JAVA APPLICATIONS OR GAMES FOR A SPECIFIC PURPOSE, SATISFACTORY QUALITY, SECURITY OR OTHERWISE.

Troubleshooting

PROBLEM - SITUATION

ACTIONS

It is impossible to switch the phone on

- Remove and replace the battery.
If you still cannot switch the phone on, charge the battery:
- Put it on charge for at least 15 minutes before switching it back on again.
 - Check if the battery icon is scrolling up and down.
 - If so, the phone is charging.
 - If not, please take the charger out and put it back on again. Please check that the charging icon is scrolling up and down.
 - If you still cannot switch the phone on, please disconnect the charger, put it back on again and please repeat that manipulation several times.
 - If the charging icon is still not scrolling up and down, please contact your after-sales services.
 - When the charging icon has stopped scrolling up and down, the battery is charged.

Battery status unknown

The phone does not recognize the battery. Please check the position of the battery.

LOW BATTERY

This message is displayed when the battery becomes too weak. The phone switches itself off automatically. Put the phone on charge.

SIM not present

Check if the SIM card is present and properly positioned / inserted.
Check the condition of the SIM card. If damaged, please go back to the network shop for advice. Contact your after-sales service if the message persists.

Incorrect PIN code

An incorrect PIN code has been entered. Be careful! Three incorrect PIN codes will block the SIM Card.

SIM BLOCKED

If a wrong PIN number is entered three times in succession, your SIM card is blocked. You must then:

- Enter the PUK (Personal Unblocking Key) code provided by Vodafone, and validate.
- Enter your PIN number and validate.
- Enter your PIN number again and validate.

After 5 or 10 failed attempts (depending on the type of SIM card), the SIM card is definitely locked. You must then contact your network provider to obtain a new card.


PROBLEM - SITUATION

ACTIONS

SIM LOCKED

In certain cases, the handset can only be used with some types of SIM cards. This message means that the SIM card you are using does not fit with the phone. Take the SIM card out, and switch it back on. If the message **SIM not present** appears on the screen, you will need to check its compatibility next to the place where you bought it. If not, please contact your after-sales service.

No call connection

Check that the number you have dialled is correct.
If the icon  is displayed without any network name displayed, only emergency services can be called.
Check the status of your credit.
Check that the SIM Card you are using offers the service you are requesting; check if its validity has not expired.
Check and deactivate the outgoing calls restriction when necessary.
The network could be saturated. Try later.
If the problem persists, please contact your Technical Helpdesk.

No receiving calls

Try to make a call in order to check that the phone and the network are operational.
Check and deactivate the permanent call forwarding (permanent call forwarding icon displayed on the screen).
Check and deactivate the incoming calls restriction when necessary.
If the problem persists, please contact your Technical Helpdesk.

Quality reception when calling

Avoid placing your fingers on the top of the phone, where the aerial is integrated: the phone will have to use full strength to establish a quality transmission.

No voicemail

Check that your subscription does offer this service.
Program the call to be forwarded to voicemail using the information provided by Vodafone, see page 46.
Check that the SIM card used offers this service. Try to make a call to check that phone and network are operational.
Check if the voicemail number is properly configured. To do so, go to the **Settings/Calls** menu, select **Voicemail** and check the number. Otherwise, enter Vodafone voicemail number.

If voicemail icon flashing

Call voicemail and listen to the new messages to make it disappear.

Network provider name does not appear on screen

Go into the **Settings** menu, select **Networks**, then **Selection**. Wait until the network provider name appears, select it and validate.

How do I switch to silent mode?

Hold the  key down unless ring tone sounds, when a short touch is enough.

PROBLEM - SITUATION

How do I delete the envelop icon that appears on the screen?

How do I delete the voicemail icon that appears on the screen?

How do I remove the written message in the idle screen (1 call)?

How do I free up memory to download my objects

How do I free up memory to receive new messages?

How do I free up memory to store new contacts in my Phonebook?

How can I increase the efficiency of my phone?

ACTIONS

The icon means you have received text messages. To delete it, read your message. If the icon flashes, memory is full, you must delete messages.

This voicemail means that you have received a voice message: please call your voicemail and listen to it. Please follow the instructions given.

Press the *** key to go back to the idle screen without messages.

Go into the **My Files** menu and delete some objects.

Manage your Outbox carefully. It is recommended not saving sent messages automatically: too many messages saved will quickly fill up the available memory and no further messages will be received. To delete them, please go into the **Messaging** menu, select **Outbox** then delete some messages. Manage your **Inbox** carefully also.

It is highly recommended to manage your Phonebook carefully. If you have received pictures enclosed in a Vcard, please save or delete them.

The most efficient actions are as follows:

Please keep your phone safely in order to avoid pressing the keys unnecessarily: every time a key is pressed the screen lights up.

You can deactivate the screensaver or select the activation time to be more than every 300 s (the screensaver uses processing power).

Make sure that you don't obstruct the antenna with your fingers when using the phone (see page 17).

Index

A

| | |
|-----------------------|----|
| Accessories | 7 |
| Activating your phone | 12 |
| Alarm | 36 |
| Anonymous mode | 45 |
| Applications | 35 |
| Automatic redial | 45 |

B

| | |
|------------------------|----|
| Battery | |
| Charging the battery | 18 |
| Installing the battery | 13 |
| Beep | 41 |
| Blacklist | 46 |
| Browser | 49 |
| Business card | 21 |

C

| | |
|-----------------|------------|
| Calculator | 37 |
| Calendar | 36 |
| Call barring | 48 |
| Call divert | 45 |
| Call waiting | 45 |
| Calls | 15, 45 |
| Camera | 30, 49 |
| Car kit | 44 |
| Charger | 7 |
| Confidentiality | 47 |
| Connectivity | 43 |
| Contact | 31, 32, 33 |

| | |
|---------------------|--------|
| Contacts | 14, 43 |
| Call | 20 |
| Copy | 21 |
| Delete | 21 |
| Edit | 20 |
| Group | 22 |
| New contact | 19 |
| Send message | 20 |
| Using the phonebook | 19 |
| Cost | 48 |
| Counters | 45 |
| Currencies | 37 |

D

| | |
|-----------------|----|
| Date and time | 15 |
| Display | 42 |
| Display numbers | 45 |

F

| | |
|----------------|----|
| Fixed dialling | 48 |
|----------------|----|

G

| | |
|-----------------|----|
| Games | 35 |
| Getting started | 14 |

H

| | |
|-----------------|----|
| Hands-free mode | 16 |
| Headset | 44 |

I

| | |
|----------------|------------------------|
| Icon | 11 |
| Infrared | 43 |
| Initial screen | 11 |
| Input modes | 24 |
| IrDA | 21, 30, 32, 33, 39, 44 |

K

| | |
|----------------|---|
| Keypad locking | 8 |
|----------------|---|

L

| | |
|-----------|----|
| Languages | 40 |
|-----------|----|

M

| | |
|--------------------|----|
| Mailbox | 46 |
| Master Reset | 41 |
| Menus | 6 |
| Messages | |
| Creating message | 23 |
| Drafts | 26 |
| Groups | 29 |
| Inbox | 26 |
| Local information | 29 |
| Memory | 29 |
| Outbox | 27 |
| Receiving messages | 26 |
| Saving message | 25 |
| Sending message | 25 |
| Sent Messages | 27 |
| Settings | 28 |

| | | | |
|-----------------------|------------|--------------------|----------------|
| Templates | 28 | Silent mode | 40 |
| Vicemail | 28 | SIM card | 12, 13 |
| Messenger | 27 | SMS | 21 |
| MMS | 21, 32 | Sound | 43 |
| Music player | 39 | Sounds | 33 |
| | | Speed Dialing | 20 |
| | | Synchronize | 44 |
| N | | T | |
| Navigation principles | 10 | T9 | 24 |
| Networks | 15, 46 | Time and Date | 41 |
| | | Timer | 36 |
| O | | Todo | 38, 43 |
| Operator | 47 | Troubleshooting | 66, 67, 68 |
| Operator logo | 42 | | |
| Organiser | 43 | U | |
| | | USB cable | 43 |
| P | | USB mode | 44 |
| Phone code | 47 | | |
| Phone settings | 40 | V | |
| Photo | 30, 43, 49 | Vibrate | 40 |
| Pictures | 32, 43 | Video | 31, 33, 43, 49 |
| PIN 2 number | 47 | | |
| PIN number | 46 | W | |
| Player Settings | 48 | Wallpaper | 42 |
| | | Warranty | 55 |
| R | | Wellphone | 44 |
| Ringtone | 40 | | |
| | | Y | |
| S | | Your phone package | 7 |
| Safety information | 52 | | |
| Screensaver | 42 | | |
| Security | 46 | | |
| Serial cable | 43 | | |
| Serial Speed | 44 | | |
| Shortcuts | 42 | | |



Mobile Communication Business Group

www.sagem.com/mobiles

Le Ponant de Paris - 27, rue Leblanc - 75512 PARIS CEDEX 15 - FRANCE

Société Anonyme

Capital 300 272 000 € - 480 108 158 RCS PARIS