



I8910
user manual



using this manual

Read me first!

When you need information, instructions, and tips to learn more about your device, you have several options available:

- **Help System** (on your device) - your device includes Help, which you can access by selecting **Tools** → **Help**. You can also select **Options** → **Help** from most menus. This embedded, searchable help system explains how to use various programs and features.
- **user manual** (online) - on the Samsung website, you will find the user manual in Adobe Acrobat (.pdf) format. You can either view the guide online or download and print the file for your convenience. The user manual contains advanced usage tips and more details about particular functions of your device. To view the file, you must have Adobe Reader or Adobe Acrobat installed- you can download Adobe Reader free from Adobe's website (www.adobe.com).

- **quick start guide** (printed) - this quick start guide has been specially designed to guide you through the functions and features of your device. It contains basic information about your device and features and tips for assembling the device. For any topics not covered in this guide, please refer to the embedded help as described above.

Instructional icons

Before you start, familiarise yourself with the icons you will see in this manual:



WARNING

Warning—situations that could cause injury to yourself or others




CAUTION

Caution—situations that could cause damage to your device or other equipment



Note—notes, usage tips, or additional information

- ▶ **Refer to**—pages with related information; for example: ▶ p. 12 (represents "see page 12")
- **Followed by**—the order of options or menus you must select to perform a step; for example: In Menu mode, select **Messaging** → **New message** (represents **Messaging**, followed by **New message**)
- [] **Square brackets**—device keys; for example: [] (represents the End/Power key).

Copyrights and trademarks

Rights to all technologies and products that comprise this device are the property of their respective owners:

- This product includes software licensed from Symbian Ltd. **symbian**
© 1998-2009. Symbian and OS
Symbian OS are trademarks of Symbian Ltd.
- Java™ is a trademark of Sun Microsystems, Inc.
- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide.
Bluetooth QD ID: B015049
- Windows Media Player® is a registered trademark of Microsoft Corporation.

- Wi-Fi®, the Wi-Fi CERTIFIED logo, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- DivX® is a registered trademark of DivX, Inc., and is used under licence.



CE 0168 ⚠

ABOUT DIVX VIDEO

DivX[®] is a digital video format created by DivX, Inc. This is an official DivX Certified device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX video. Devices certified to play DivX video at the Mobile Theater profile: DivX Certified to play DivX[®] video up to 640x480, including premium content.

ABOUT DIVX VIDEO-ON-DEMAND

This DivX Certified[®] device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX VOD.



contents

Depending on your region or service provider, default applications on your device may vary.

communication	2
Messages	2
Log	13
media	16
Gallery	16
MediaBrowser	17
Communities	17
Radio	18
RealPlayer®	19
Video player	20
Recorder	20
PC Studio	20
personal productivity	22
Contacts	22
Calendar	24
Quickoffice®	25
Adobe® PDF	26
Notes	26
web	28
Browse a web page	29
Change browser settings	29

Add a bookmark	30	Podcasts	50
Use a bookmark	31	Samsung LBS	51
Download files from the web	31	Smart search	51
Use RSS reader	32	Mobile social networking services	52
connectivity	33	managers	53
Access points	33	File manager	53
Wireless LAN (WLAN)	34	Application manager	56
Bluetooth	35	Zip	57
USB	37	Connection manager	57
Connected home	39	settings	58
RoadSync	40	Personal settings	58
additional programs	42	Phone settings	59
Calculator	42	Application manager	61
Clock	42	Calling settings	61
Converter	43	Connectivity settings	62
GPS data	44	troubleshooting	a
Landmarks	46	index	e
Smart reader	46		
Dictionary	47		
Print OTG	47		
Compass	48		
Qik	49		

communication

Your device allows you to send and receive many types of messages over cellular networks and the internet.

Messages

Learn to use messaging functions. For instructions on entering text, see the quick start guide.

Message folders

When you open Messaging, you will see the **New message** function and a list of folders:

- **Inbox:** received messaging, except email and cell broadcast messages
- **Mailbox:** received email messages; when you create a mailbox, the name you specify will appear here; your service provider's email account will appear here
- **Sent:** recent sent messages
- **Drafts:** messages you have not yet sent
- **Outbox:** temporary storage for messages waiting to be sent

- **Delivery reports:** delivery reports of text and multimedia messages; you must request a delivery report in the message options before sending
- **My folders:** message templates and saved messages



- Messages sent via the Bluetooth wireless feature are not saved in the Drafts or Sent folder.
- You may not receive a delivery report for a multimedia message if you send it to an email address.

Inbox icons

In the Inbox, you may see the following icons next to your messages:

Icon	Description
	Unread text message
	Multimedia message notification

Icon	Description
	Unread multimedia message
	Unread smart message
	Unread service message
	Data received via a Bluetooth connection
	Unknown message type

Outbox status

When you are outside your service area or have no connection to the network or email server, your messages will remain in the Outbox folder until you re-establish a connection. The Outbox status explains why a message is being held in the Outbox folder:

- **Sending:** the device is connecting and the message will be sent immediately

- **Waiting:** the message is in cue behind another message and will be sent as soon as possible
- **Resend at (time):** the message has failed to send and will be sent at the specified time
- **Deferred:** the message has been scheduled to send at a later time
- **Failed:** the device has attempted to send the message multiple times, but has failed

Text messages

For instructions on sending and viewing text messages, see the quick start guide.



Text messages longer than 160 characters will be sent as two or more messages and may result in additional charges.

Retrieve messages from a SIM or USIM card

If you have text messages stored on a SIM or USIM card, you must copy them to the device before you can view them.

1. In Menu mode, select **Messaging** → **Options** → **SIM messages**.
2. Select a message → **Options** → **Copy** → **Inbox** or **My folders**.

You can now view the messages from the folder on your device.

Multimedia messages

Before you can send multimedia messages, you must define an access point.






Set an access point

Your service provider may supply access point settings via a smart message. To automatically set an access point using a smart message, see "Save smart message data or settings to your device." ► p. 12

To manually set an access point,

1. In Menu mode, select **Settings** → **Connectivity** → **Destinations** → **Multimedia msg.**
2. Select **Options** → **New access point.**
3. Set access point options according to the instructions provided by your service provider.

Send a multimedia message

1. In Menu mode, select **Messaging** → **New message.**
2. Select the recipient field.
To select a contact, select +.
3. Enter a phone number and select .
4. Select the text input field.
5. Enter your message text and select .
6. Select  → a media type → a media file.
7. Select  to send the message.

Edit a multimedia message

You can edit your multimedia message before sending it:

- To add fields to the message header, select **Options** → **Message header fields** → a field type → **OK**
- To change the message layout, select **Options** → **Place text last** or **Place text first**
- To remove an item, select **Options** → **Remove** → an item



You can add images, sounds, or videos to slides; however, you can only add one type of media type per slide.

View a multimedia message

1. In Menu mode, select **Messaging** → **Inbox.**
2. Select a message.

Listen to voice mail

If your voice mail number is preset by your service provider, you can touch and hold **1** to access your voice mail from the dialling screen.

If the voice mail number is not preset or if you need to change the voice mail number,

1. In Menu mode, select **Tools** → **Call mailbox**.
2. If you change the voice mail number, select **Options** → **Change number**.
3. Select the input field.
4. Enter the voice mail number provided by your service provider and select ✓.
5. Select **OK**.

You can now access your voice mail by touching and holding **1** from the dialling screen.

Email messages

Before you send or receive email messages, you must create a mailbox.

Create a mailbox








1. In Menu mode, select **Messaging** → **Options** → **Settings** → **E-mail**.
2. Select **Mailboxes**.
3. Select **Options** → **New mailbox**.
4. Select **Start** to start the mailbox setup wizard and follow the on-screen instructions.

The new mailbox will automatically appear in Messaging. To change the current mailbox, return to email settings and switch the Mailbox in use to another mailbox.



If you use the POP3 protocol, the mailbox will not update automatically when you are online. You must disconnect and then reconnect to view new messages.

Send an email message

1. In Menu mode, select **Messaging** → an email account → .
2. Select the recipient field.
To select a contact, select +.
3. Enter an email address and select .
4. Select the subject input field.
5. Enter a subject and select .
6. Select the text input field.
7. Enter your message text and select .
8. Select  → a media type → a media file.
9. Select  to send the message.

If you are offline or outside your service area, the message will be held in the Outbox folder until you are online and in your service area.

View an email message

When you open a mailbox, you can view previously retrieved emails offline or connect to the email server to view new messages. After you retrieve email messages, you can view them offline.

To view new messages online,

1. In Menu mode, select **Messaging** → your mailbox.
2. Select **Options** → **Connect**.
3. Select **Options** → **Retrieve e-mail** → **New** or **All**.

To view new messages offline,

1. Repeat steps 1-3 above.
2. Select **Options** → **Disconnect**.

View or save email attachments



Email attachments may contain viruses that can damage your device. To protect your device, open attachments only if you trust the sender.

To view an attachment,

1. From an open email message, select **Options** → **Attachments**.
2. Select an attachment.

The attachment opens with the corresponding application.

To save an attachment,

1. From an open email message, select **Options** → **Attachments**.
2. Scroll to the attachment and select **Options** → **Save**.

Delete an email message

You can delete email messages from your device only or from both your device and the mail server.

To delete a message from your device only,

1. In Menu mode, select **Messaging** → your mailbox.
2. Scroll to an email and select **Options** → **Delete** → **Phone only**.



The email header will remain in your mailbox until you delete the message from the mail server.

To delete a message from both your device and the mail server,

1. In Menu mode, select **Messaging** → your mailbox.
2. Scroll to an email and select **Options** → **Delete** → **Phone and server**.



If you are offline, messages will be deleted from the server the next time you connect. If you are using the POP3 protocol, deleted messages are removed when you close the mailbox connection.

Instant messages

You can send and receive instant messages (IM) if your service provider supports this feature. Before you can send or receive instant messages, you must set up a server.



This menu may be unavailable depending on your region or service provider.

Set up a server

1. In Menu mode, select **Tools** → **IM**.
2. A prompt asks if you want to define a server. Select **Yes** (If the prompt does not appear, select **Options** → **Settings** → **Servers** → **Options** → **New server**).
3. Set the server options according to instructions provided by your service provider.

Log in to the IM server

1. In Menu mode, select **Tools** → **IM**.
2. If the device does not attempt to log in automatically, select **Options** → **Log in**.
3. Enter your user ID and password, and then select **OK**.
4. Select **Yes** to log in automatically when you select **IM** again.
5. Select your ID and change the way you appear to other IM contacts (if necessary).
6. To log out, select **Options** → **Log out**.

Start a conversation

1. In Menu mode, select **Tools** → **IM** → **Conversations**.
2. Select **Options** → **New conversation** → **Enter user ID**.
3. Enter a user ID and select **OK**.
4. Enter your message and select **Options** → **Send**.
5. To end the conversation, select **Options** → **End conversation**.


Accept an invitation

When you receive an invitation, select **Conversations** → the invitation → **Options** → **Join**.

Add IM contacts

You can save IM contact information by selecting **Options** → **Add to IM contacts** during a conversation. You can also add information in IM Contacts by selecting **Options** → **New IM contact**.

When you view your IM contacts, you may see the following icons:



Icon	Description
	the contact is online
	the contact is offline
	the contact is blocked

If you see no icon next to a contact's name, the contact is unknown.

Audio messages

You can send audio messages with voice memos or sound clips. To record a voice memo or sound clip, see "Recorder." ► p. 20

Send an audio message

1. In Menu mode, select **Messaging** → **Options** → **Create message** → **Audio message**.
2. To insert an existing sound clip, select **Options** → **Insert sound clip** → **From Gallery** → a sound clip.
3. To record and insert a new sound clip, select  to begin the recording. When you are finished recording, select **Stop**.
4. Select  to send the message.

Cell broadcast messages

If your service provider supports this function, you can subscribe to cell broadcasts that provide automatic notifications or news updates. To learn about available cell broadcasts, contact your service provider.

Add a cell broadcast topic

1. In Menu mode, select **Messaging** → **Options** → **Cell broadcast**.
2. Select **Options** → **Topic** → **Add manually**.
3. Enter the topic name and number, and then select **OK**.

Subscribe to a cell broadcast

1. In Menu mode, select **Messaging** → **Options** → **Cell broadcast**.
2. Scroll to a topic and select **Options** → **Subscribe**.

Your device will now receive new messages automatically.

3. To cancel a subscription, select **Options** → **Cancel subscription**.



Some connection settings may block cell broadcasts. Contact your service provider for the appropriate connection settings.

View a cell broadcast topic

1. In Menu mode, select **Messaging** → **Options** → **Cell broadcast**.
2. Select a topic folder.
3. Select a topic.

Set automatic notification of new cell broadcast messages

1. In Menu mode, select **Messaging** → **Options** → **Cell broadcast**.
2. Scroll to a topic and select **Options** → **Hotmark**.
3. To stop automatic notifications, select **Options** → **Remove hotmark**.

Smart messages

Your device can receive many kinds of smart messages, including business cards, ringtones, calendar events, browser bookmarks, and settings. Your service provider may send smart messages that you can use to load settings into your device.

Save smart message data or settings to your device

1. In Menu mode, select **Messaging** → **Inbox**.
2. Select a message.
3. Select **Options** and save the data or settings according to the smart message type.

You may also receive an email notification, which tells you how many new emails are in your remote mailbox.

Service messages

You may receive service messages from your service provider that are deleted automatically when they expire. You can view service messages from the Inbox (you may have to download the message from the service provider). Contact your service provider for more information about service messages.

Push email

Using RoadSync, you can receive emails that are transferred from your email server to your device. For more information, see "RoadSync"

► p. 40

Log

Learn to view log information about calls, packet data, and other communication events.

Recent calls

You can view and erase logs of recently missed calls, received calls, or dialled numbers.

View recent call logs

To view recently missed calls, received calls, or dialled numbers,

1. In Menu mode, select **Tools** → **Log** → **Recent calls**.
2. Select a call type.



To call a number from a call log, scroll to the number and press [📞].

Erase recent call logs

You can erase all recent call logs at once, erase a single call log, or delete a single number from a log.

To erase all recent call logs,

1. In Menu mode, select **Tools** → **Log** → **Recent calls**.
2. Select **Options** → **Clear recent calls**.
3. Select **Yes** to confirm.

To erase a single call log,

1. In Menu mode, select **Tools** → **Log** → **Recent calls** → a call type.
2. Select **Options** → **Clear list**.
3. Select **Yes** to confirm.

To erase a single number from a log,

1. In Menu mode, select **Tools** → **Log** → **Recent calls** → a call type.
2. Scroll to a number and select **Options** → **Delete**.
3. Select **Yes** to confirm.

Call duration

To view the durations of your last call, dialled number, received call, or all calls, in Menu mode, select **Tools** → **Log** → **Call duration**.



Packet data

To view the amount of sent or received packet data, in Menu mode, select **Tools** → **Log** → **Packet data**.

Communication log

You can view communication details and filter logs with the communication log.



View the communication log

1. In Menu mode, select **Tools** → **Log**.
2. Select   to switch to the communication log.





Some events, such as a text message split into multiple parts, will appear as one communication event.

Filter log events

1. In Menu mode, select **Tools** → **Log**.
2. Select   to switch to the communication log.
3. Select **Options** → **Filter**.
4. Select a filter type.

Erase the communication log

To permanently erase all of the log contents,

1. In Menu mode, select **Tools** → **Log**.
2. Select   to switch to the communication log.
3. Select **Options** → **Clear log**.
4. Select **Yes** to confirm.

Log duration

You can change the length of time that communication events are stored in the logs. After that time, events are automatically erased to free up memory.

To set a log duration,

1. In Menu mode, select **Tools** → **Log**.
2. Select **Options** → **Settings**.
3. Select **Log duration**.
4. Select a duration.



If you select **No log**, no communication events will be stored in the log.



media

Learn to use the media applications on your device:
Gallery, MediaBrowser, Communities, Radio,
RealPlayer, Video player, Recorder, and PC studio.

Gallery

You can manage all your media files from Gallery.

Open a media file

1. In Menu mode, select **Gallery**.
Your media files are automatically organised by file type.
2. Select a media folder → a media file.

Copy or move a file

1. In Menu mode, select **Gallery**.
2. Select a media folder → a media file.
3. Select **Options** → **Organise** → **Copy** or **Move**.




You cannot move or copy files protected by licences.

Edit images

1. In Menu mode, select **Gallery** → **Images & videos** → an image.
2. Select **Options** → **Edit**.
3. Select **Options** → **Add effect** → an option.

MediaBrowser

You can view and categorise photos and videos.

1. In Menu mode, select **Media** → **MediaBrowser**.
2. Rotate the phone anti-clockwise to landscape view.
3. Select  → a view mode to change the view mode.
4. Scroll left or right to view photos.
Tilt the device to the left or right. Photos will scroll left or right automatically.

Communities

With Communities, you can upload photos and videos to your favourite websites and blogs, and get the latest updates from them.



This is available only if supported by your service provider or region.

Create a new destination

1. In Menu mode, select **Applications** → **Communities**.
2. Select **Yes** to set preferred lists.
3. Select **Accept** (if necessary).
4. Select **Options** → **Settings** → **Preferred lists**.
5. Select websites and blogs and select **Save**.

Upload a file

1. In Menu mode, select **Applications** → **Communities**.
2. Scroll to a website or blog.
3. Select **Options** → **Upload to web**.
4. Select **Tap to add** and select a photo or video.
5. Select **Options** → **Upload to web**.
6. Enter a title for the photo or video and select **Upload**.



You can also upload a photo or video from the Gallery or right after capturing it.

Radio

You can listen to your favourite stations with the FM radio.


Listen to the FM radio

1. Plug a headset into the multifunction jack.
2. In Menu mode, select **Media** → **Radio**.
3. Select ◀ or ▶ to scan through available radio stations.

Set up your favourite radio station list

Once you have set up a station list, you can access the stations.

Save radio stations by automatic tuning

1. From the radio screen, select  to access the station list.
2. Select **Options** → **Auto-save stations**.
3. Select **Yes** to confirm (this will replace any existing stations).

Save a radio station manually

1. To go to the radio station you want, select **Options** → **Manual tuning** and enter the frequency.
2. Select **Options** → **Save station**.
3. Select an empty location.
4. Enter a station name and select **OK**.

RealPlayer®

Your device includes RealPlayer for viewing many types of media files and streaming content from the internet. RealPlayer supports files with the following extensions: 3gp, mp4, rm, rv, divx, avi, and wmv.

Play a media file in RealPlayer

1. In Menu mode, select **RealPlayer** → **Video clips** or **Recently played**.
2. Select a media file.

Add a streaming internet link

1. In Menu mode, select **RealPlayer** → **Streaming links**.
2. Select **Options** → **New link** → a memory location (if necessary).
3. Enter a name and web address and select **OK**.

Play streaming web content with RealPlayer

When you open a link to streaming web content via your web browser, RealPlayer will buffer and play the content. You can then use the touch keys and Volume key to control options for the streaming content.



RealPlayer may stop or skip playback, or display broken images if you are playing the high frame rate or high bit rate of a video clip. If you are running multiple applications in the background, close some applications.

Video player


You can play video files and DivX vod files.

1. In Menu mode, select **Media** → **VideoPlayer**.
2. Select a video.
3. Use the on-screen buttons to control playback.

Recorder

You can record and play back voice memos and sound clips.

Record a voice clip

1. In Menu mode, select **Media** → **Recorder**.
2. Select  to begin the recording.
3. When you are finished recording, select **Stop**.

The voice clip is automatically saved.

Play a voice clip

1. In Menu mode, select **Media** → **Recorder**.
2. Select **Options** → **Go to Gallery**.
3. Select a voice clip.
Playback begins automatically.
4. Use the on-screen buttons to control playback.

PC Studio

PC Studio, which is included on the PC Studio CD-ROM, is a Windows-based program that allows you to manage your personal information and sync files to your device. For more information, install the program and refer to the PC Studio help.

Install PC Studio

1. Insert the PC Studio CD into a Windows-compatible PC.
2. Select a language for the setup program.
3. Follow the on-screen instructions.



During installation, the setup program will automatically install the necessary USB drivers.

Use Samsung PC Studio

To connect your device to a PC with Samsung PC Studio, you must change the device's USB mode (see "Use Samsung PC Studio" ► p. 38).



personal productivity

Learn to manage contacts, schedule calendar events, use Quickoffice, Adobe PDF, and create note.

Contacts

Learn to use contact cards and groups to store personal information, such as names, phone numbers, and addresses.

Copy contact cards

To copy contact cards from one memory location to another,

1. In Menu mode, select **Contacts**.
2. To display the contact cards on a SIM or USIM card, select **Options** → **Settings** → **Contacts to display** → **SIM memory** → **OK**.
3. Select **Back**.
4. Scroll to a contact and select **Options** → **Copy** → **Phone memory** or **SIM memory**.

Set a default number or address

Some contact cards may include more than one number or address.

To assign a single number or address as the default,

1. In Menu mode, select **Contacts**.
2. Select a contact in the device's memory.
3. Select **Options** → **Defaults**.
4. Select a default type.
5. Select a number or address.
6. When you are finished, select **Back**.

Assign a speed dial number to a contact card

You can assign speed dial numbers to up to eight contact cards (**2** through **9**); **1** is reserved as a speed dial number for your voice mail.

To assign a speed dial number,

1. In Menu mode, select **Contacts**.
2. Select a contact in the device's memory.
3. Scroll to a phone number and select **Options** → **Assign speed dial**.
4. Select a speed dial number.
5. Select **Assign**.
6. Select **Yes** to activate the speed dial number.

Assign a ringtone to a contact card or group

You can assign a ringtone to any contact card or group.


1. In Menu mode, select **Contacts**.
2. Select a contact in the device's memory.
3. Select **Options** → **Ringtone**.
4. Select a ringtone.



For an individual contact, your device will use the ringtone that was assigned last to the contact card. For example, if you assign a ringtone to a group and then assign another ringtone to a contact card within that group, the device will use the ringtone assigned to the contact card when that contact calls.

Create a contact group

You can create groups of contacts and send messages to the entire group.

1. In Menu mode, select **Contacts**.
2. Select .
3. Select **Options** → **New group**.
4. Enter a name and select **OK**.
5. Select the new group.
6. Select **Options** → **Add members**.
7. Select each contact you want to add.
8. When you are finished selecting contacts, select **OK** to save them to the group.

Synchronise your contacts

To synchronise your contacts by using the current sync profile,

1. In Menu mode, select **Contacts**.
2. Scroll to a contact in the device's memory and select **Options** → **Synchronisation** → **Start**.
3. Select a sync profile or create a new sync profile.

Calendar



Use the calendar to keep track of meetings, notes, anniversaries, or to-do items.

Change the calendar view

1. In Menu mode, select **Office** → **Calendar**.
2. Select **Options** → **Change view** → a view type.

Create a calendar event

1. In Menu mode, select **Office** → **Calendar**.
2. Scroll to a date and select **Options** → **New entry** → an event type.

You can also create meeting and to-do items from the calendar view by selecting  and .

3. Complete the fields and adjust the settings for your event.
4. When you are finished, select **Done** to save your entry.



In the **Synchronisation** field, you can specify whether an event is **Private** (seen only by you), **Public** (seen by anyone with access to your data after you sync), or **None** (not synchronised).

Stop an event alarm

If you set an alarm for a calendar event, the alarm will sound for one minute at the specified time. To stop the alarm, select **Stop**.

Quickoffice®

With Quickoffice, you can view Word, Excel, and PowerPoint files on your device. To create and edit Word, Excel, and PowerPoint files, purchase a licence.

Create a Quickoffice document

1. In Menu mode, select **Office** → **Quickoffice**.
2. Select **New document**.
3. Select **Document** (Word), **Workbook** (Excel), or **Presentation** (PowerPoint).
4. Create a document and save it.

Open a Quickoffice document

1. In Menu mode, select **Office** → **Quickoffice**.
2. Select a memory.
3. Select a document.

Update Quickoffice

With Quickmanager, you can download program updates, new Quickoffice products, or special offers.

1. In Menu mode, select **Office** → **Quickoffice** → **Updates and upgrades**.
2. Select a Quickmanager item.

Adobe® PDF

With Adobe PDF, you can open and view PDF documents. To create and edit PDF files, purchase a licence.

1. In Menu mode, select **Office** → **Adobe PDF**.
2. Select a memory.
3. Select a file.

4. While viewing a document, select **Options** to use the following options:

Option	Description
Zoom	Magnify part of a document
Find	Search for text
Go to	Skip to another page

Notes

With Notes, you can create text notes and synchronise them with other devices.

Create a note

1. In Menu mode, select **Office** → **Notes**.
2. Select **Options** → **New note**.
3. Select the text input field.
4. Enter text and select ✓.
5. When you are finished entering text, select **Done** to save the note.

Synchronise notes with other devices

1. In Menu mode, select **Office** → **Notes**.
2. Scroll to a note and select **Options** → **Synchronisation** → **Start**.
3. Select a sync profile or create a new sync profile.



web

Your device allows you to connect to the wireless web with the built-in web browser. To connect to the web, you must:

- Subscribe to a wireless network that supports data calls
- Activate the data service for your SIM or USIM card
- Obtain an internet access point from a service provider
- Define your web settings



Your device is preset to access the wireless web. If you cannot connect to the web, contact your service provider to download new browser settings.

Browse a web page

1. In Menu mode, select **Web**.
The device shows the list of bookmarks and folders.
2. Access a web page:
 - Select a bookmark or folder
 - Select **Options** → **Go to** → **New web page**, enter a web address and select ✓ → **Go to**
3. To close the web connection, select **Options** → **Web page options** → **Close**.



- If your device shows "Not enough memory," close other running applications to free up the memory, and then restart the browser.
- The device will show a security indicator (🔒) whenever you have established an encrypted connection.

Change browser settings

From the bookmark list, select **Options** → **Settings**.

General settings

- **Access point:** change the default access point
- **Homepage:** define your homepage
- **History list:** activate the history list
- **Web address suffix:** set the frequently used suffixes
- **Security warnings:** hide or show security warnings
- **Java/ECMA script:** enable or disable scripting
- **Java/ECMA script errors:** enable the web page developer to debug JavaScript and ECMA Script by error messages and notifications, log files, or both
- **Open while downloading:** set to automatically open progressive download files

Page settings

- **Load content:** select whether you want to load images and other objects while browsing
- **Default encoding:** If text characters are not shown correctly, select another according to language for the current page
- **Block pop-ups:** allow or block pop-ups while browsing
- **Automatic reload:** set to automatically refresh the web pages while browsing
- **Font size:** define the font size that is used for web pages

Privacy settings

- **Recently visited pages:** enable or disable automatic bookmark collecting
- **Form data saving:** to save the data you enter on a web page and use it the next time you open the page, select **Off**
- **Cookies:** enable or disable the receiving and sending of cookies.

Web feeds settings

- **Automatic updates:** set web feeds to update automatically
- **Acc. point for auto-update:** set an access point to update web feeds
- **Update when roaming:** set to update web feeds while roaming





Add a bookmark

1. In Menu mode, select **Web**.
2. Select **Options** → **Bookmark options** → **Add bookmark**.
3. Enter the bookmark name, address, and access point, as well as a user name and password if desired.
4. Select **Options** → **Save**.

Use a bookmark

While browsing, you can also access bookmarks (see "Add a bookmark").

Select **Options** → **Go to** → **Bookmarks** to access the following:

Icon	Description
	Folder of recently visited pages
	Folder you have created
	Default folder
	Bookmark

Download files from the web

When you download files from the web, your device stores them in a corresponding folder in Gallery. For example, your device will store downloaded images in the Images folder.



CAUTION

Files you download from the web can include viruses that will damage your device. To lessen your risk, only download files from sources you trust.



Some media files include Digital Rights Management to protect copyrights. This protection may prevent you from downloading, copying, modifying, or transferring some files.

Download applications from the web

Application download provides you an easy and quick way to shop for mobile applications. With this service, you can buy and download various applications directly without searching for applications every time. This is available only if supported by your service provider or region.

1. In Menu mode, select **Applications** → **Download**.
2. Select **Accept**.
3. Select **Connect** → an access point.
4. Select **yes**.
5. Select an application category.
6. Search for an application and download it to the device.



Use RSS reader

Use RSS reader to get the latest news and information from your favourite websites.

Create a new feed

1. In Menu mode, select **Web**.
2. Select **Options** → **Go to** → **Web feeds**.
3. Select **Options** → **Web feed options** → **New feed**.
4. Enter a title and address.
5. Select **Options** → **Save**.

Update feeds

1. In Menu mode, select **Web**.
2. Select **Options** → **Go to** → **Web feeds**.
3. Select a feed and  to update.
To update all feeds, select .

Read RSS feeds

1. In Menu mode, select **Web**.
2. Select **Options** → **Go to** → **Web feeds**.
3. Select a feed to read it.

connectivity

Learn to create access points, connect to a wireless LAN and transfer data to and from your device via the Bluetooth wireless feature or the PC data cable.

Access points

Your device supports packet data connections (network service) and WLAN data connections. To establish a data connection, you must create an access point.



Check the type of access point you need with your service provider for the service you want to access. For availability and subscription to packet data connection services, contact your service provider.

Create a packet data access point

1. In Menu mode, select **Settings** → **Connectivity** → **Destinations**.
2. Select an access point group.
3. Select **Options** → **New access point**.
4. Select **Yes** to search for available connection method.
5. Select **Packet data**.
6. Enter a name for the access point and select **OK**.

Create a WLAN access point

1. In Menu mode, select **Settings** → **Connectivity** → **Destinations**.
2. Select an access point group.
3. Select **Options** → **New access point**.
4. Select **Yes** to search for available connection method.
5. Select **Wireless LAN**.
6. Select a WLAN network.
7. Enter a pre-shared key for WLAN and select **OK** (if necessary).

Wireless LAN (WLAN)


You can activate and connect to a WLAN. When you are in range of a WLAN network, your device can detect and connect to an active WLAN to make calls or send data over the internet, or browse the web.



Your device uses a non-harmonised frequency and is intended for use in the following countries: United Kingdom, Greece, Latvia, Lithuania, Estonia, Sweden, Denmark, Finland, Norway, Portugal, Poland, Italy, Bulgaria, Germany, Austria, France, Switzerland

Search for and connect to a WLAN


1. In range of WLAN network, access an application or menu that needs a wireless connection.
2. In Menu mode, select **Settings** → **Connectivity** → **Wireless LAN**.
3. Select **Options** → **Refresh** to search for available WLANs.
4. Select a WLAN → **Options** → **Connect**.
5. Enter a pre-shared key for WLAN and select **OK**.

When your device is connected to the WLAN,  appear next to the WLAN.

6. To disconnect the WLAN, select **Options** → **Disconnect WLAN**.

Customise WLAN settings



In Menu mode, select **Settings** → **Connectivity** → **Wireless LAN** → **Options** → **Settings**.

- **Show WLAN availability:** set to display  in Standby mode when a WLAN is available
- **Scan for networks:** set how often the device searches for available WLANs
- **Internet connectivity test:** set whether to run the test for internet connectivity


Bluetooth

You can connect with other Bluetooth-enabled wireless devices over a distance of 10 metres (30 feet). Walls or other obstacles between devices may block or impair the wireless connection.

Turn on the Bluetooth wireless feature

1. In Menu mode, select **Tools** → **Bluetooth**.
2. Edit your device's name (if necessary).
3. Select **OK**.
4. Select the circle in the centre to turn on the Bluetooth wireless feature.
5. To allow other devices to locate your device, select  → **On** under **My phone's visibility** → a visibility option → . If you selected **Custom**, set duration that your phone is visible.

Find and pair with a Bluetooth-enabled device

1. In Menu mode, select **Tools** → **Bluetooth**.
2. Select . Your device searches for and displays the list of Bluetooth-enabled devices.

3. Select and drag a device icon into the centre.
4. Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and select **OK**.

When the owner of the other device enters the same code or accepts the connection, pairing is complete.



To pair with another Bluetooth-enabled device, both devices must use the same PIN. Headsets or hands-free car kits may use a fixed PIN, such as **0000**.

5. To allow the device to send and receive data without confirmation, select **Yes**. Otherwise, select **No** to require confirmation.


Send data via the Bluetooth wireless feature

1. Select the file or item from one of your device's applications that you want to send.
2. Select **Options** → **Send** or **Send as business card** → **Via Bluetooth** (when sending contact data, specify which data to send).
3. Select a paired device.
4. Enter a PIN and select **OK** (if necessary).

Receive data via the Bluetooth wireless feature



1. When another device attempts to access yours, select **Yes** to permit the connection.
2. Select **Yes** again to confirm that you are willing to receive data from the device (if necessary).



Accepted items are placed in the Inbox folder. The  icon indicates messages received via Bluetooth.

Activate Remote SIM mode

To use Remote SIM mode with a compatible hands-free car kit,

1. Connect to your device from an authorised hands-free car kit.
2. In Menu mode, select **Tools** → **Bluetooth**.
3. Select  → **On** under **Remote SIM mode** → .

You can now make or answer calls only with the connected hands-free car kit via the SIM or USIM card on your device.



The Bluetooth hands-free car kit must be authorised. To authorise, select the device and select **Set as authorised**.

USB

Learn to connect your device to a PC via USB.

Set a default action for your USB connection

To set your device to perform a default action when you connect the device to a PC with the PC data cable,

1. In Menu mode, select **Settings** → **Connectivity** → **USB** → **USB connection mode**.
2. Set the default USB mode (**PC Studio**, **Mass storage**, **Image transfer**, or **Media transfer**).



You can also set your device to **Ask on connection**, instead of using a default USB mode. If you use this setting, your device will prompt you to choose the USB mode every time you connect to a PC.

Use Samsung PC Studio

1. Change the USB connection to **PC Studio**.
2. Connect your device to a PC with the PC data cable.
3. Run Samsung PC Studio 7.2 or later and manage personal data and media files. Refer to the Samsung PC Studio help for more information.

Copy files to a memory card

1. Insert a memory card (see the quick start guide).
2. Change the USB connection to **Mass storage**.
3. Connect your device to a PC with the PC data cable.
4. Open a folder to view files when a pop-up window appears on your PC.
5. Copy files from the PC to the memory card.
6. When you are finished, disconnect the device from the PC.

Transfer pictures to a PC

1. Change the USB connection to **Image transfer**.
2. Connect your device to a PC with the PC data cable.
3. Open the Microsoft Scanner and Camera Wizard.
4. Select pictures you want to copy.
5. Enter a folder name to save the pictures and select a saving location.
6. Select what you want to do with the pictures.
7. Follow the on-screen instructions.

Synchronise with Windows Media Player


You can copy music files to the device by synchronising with Windows Media Player 11.


1. Change the USB connection to **Media transfer**.
2. Connect your device to a PC with the PC data cable.
3. Open Windows Media Player to synchronise music files.
4. Edit or enter your device's name in the pop-up window (if necessary).
5. Select and drag the music files you want to the sync list.
6. Start synchronisation.

Connected home

Learn to use the DLNA (Digital Living Network Alliance) service that enables you to share media files between DLNA-enabled devices by using the wireless LAN.

1. In Menu mode, select **Applications** → **Connected H...**
2. Select an access point.
3. Enter a password and select **OK** (if necessary).
4. If you access this application for the first time, follow the on-screen instructions to set up the media sharing feature.
5. When you are finished, your device searches for the first device—the one that contains media files.
6. Select a device icon to browse the media files on that device.

If you want to share media files from your device, select your device, select , and activate the media sharing option.

7. Select a media type and a folder.
8. Select media files.
9. If there are no players or other devices to play the media files, select  to update the list of devices.
10. Select a device to start playback.
11. Control playback using icons of your device.

RoadSync

RoadSync provides secure, wireless synchronisation of your email, calendar, contacts, and attachments.

Set up a sync profile

If you do not know which settings to use, contact your IT staff.

1. In Menu mode, select **Applications** → **RoadSync**.
2. Select **Next** to continue.

3. Select **Accept** twice.
4. Enter the required information for a synchronisation profile and select **Verify**.
5. Select an access point and **OK**.
6. Complete the setup by selecting **OK** or **Next**.

Start synchronisation

1. In Menu mode, select **Applications** → **RoadSync**.
2. Select **Options** → **Sync**.

Customise synchronisation settings

1. In Menu mode, select **Applications** → **RoadSync**.
2. Select **Options** → **Settings**.

3. Change the following options:
- **Sync Schedule:** set the peak time and off-peak time schedules for synchronisation
 - **Email Options:** adjust email filtering
 - **Calendar Options:** set to synchronise the calendar on the Exchange Server with your device
 - **Contacts Options:** set to synchronise the contacts on the Exchange Server with your device
 - **Task Options:** set to synchronise the tasks on the Exchange Server with your device
 - **Advanced Options:** change the access point or reset all data



additional programs

Learn to use Calculator, Clock, Converter, GPS data, Landmarks, Smart reader, Dictionary, Print OTG, Compass, Qik, Podcasts, Samsung LBS, and Smart search.

Calculator

1. In Menu mode, select **Office** → **Calculator**.
2. Use the keys that correspond to the calculator to perform basic mathematical operations.

Clock

You can adjust clock settings, set alarms, and create a world clock.

Change clock settings

1. In Menu mode, select **Office** → **Clock**.
2. Select **Options** → **Settings**.
3. Change the clock settings.

Set a new alarm

1. In Menu mode, select **Office** → **Clock** → **New alarm**.
2. Set alarm details.
3. Select **Done**.

Stop an alarm

When an alarm sounds, select **Stop** to end the alarm or **Snooze** to repeat the alarm after a specified time. You can delay the alarm (snooze) up to five times.



Your current profile setting will not affect the volume of a clock alarm.

Create a world clock

With a world clock, you can monitor the time in another region.

To create a world clock,

1. In Menu mode, select **Office** → **Clock** → **World clock**.
2. Select **Options** → **Add location**.
3. Scroll to a city and select it, or enter the first few letters of the city name to search the list.

Converter

With Converter, you can convert measurements or currencies from one unit to another. To convert currencies, you must first set a base currency and exchange rate.

Add currencies and exchange rates



The value of the base currency is always 1. You must enter exchange rates for other currencies as they relate to one unit of the base currency. Exchange rates change often. To ensure an accurate conversion, you must enter a current exchange rate.

To set a base currency,

1. In Menu mode, select **Office** → **Converter**.
2. Select the type field and select **Currency** (if necessary).
3. Select **Options** → **Currency rates**.
4. Scroll to a currency and select **Options** → **Rename currency**.

5. Enter the name of the base currency and select **OK**.

To add other currencies and exchange rates,

1. Repeat steps 1-4 above.
2. Enter the name of a new currency and select **OK**.
3. Scroll to the new currency and enter the exchange rate.
4. Select **Done**.

Convert currencies

1. In Menu mode, select **Office** → **Converter**.
2. Select the type field and select **Currency** (if necessary).
3. Select the unit field and select a currency to convert.
4. Select the amount field and enter the amount to convert.
5. Select the unit field and select a currency to convert to.

The device displays the conversion result.

Convert measurements

1. In Menu mode, select **Office** → **Converter**.
2. Select the type field and select the type of measurement.
3. Select the unit field and select the base unit (if necessary).
4. Select the amount field and enter the base amount.
5. Select the unit field and select the conversion unit (if necessary).

The device displays the conversion result.

GPS data

You can view GPS data to help you navigate, show your position, or monitor trip details. Before you can use GPS data, you must activate a positioning method via a Bluetooth wireless connection or a wireless network connection.



You must be in outdoors for receiving GPS information better.

Activate a positioning method

1. In Menu mode, select **Tools** → **Location** → **Positioning** → **Positioning methods**.
2. Scroll to a positioning method (**Integrated GPS**, **Bluetooth GPS**, or **Network based**) and select **Options** → **Enable**.



If you enable Bluetooth GPS, you must pair with a Bluetooth-enabled device (see "Find and pair with a Bluetooth-enabled device" ► p. 35). Once you activate a positioning method, your device will attempt to open that connection when you launch GPS data.

Navigate with GPS data

1. In Menu mode, select **Tools** → **Location** → **GPS data** → **Navigation**.
2. Select **Options** → **Set destination** → **Coordinates**.

3. Enter the latitude and longitude of your destination and select **OK**.
Your device will display the direction of your destination, your current speed, and the duration of your trip.
4. To stop the GPS navigation, select **Options** → **Stop navigation**.

View your current position

In Menu mode, select **Tools** → **Location** → **GPS data** → **Position**.

Monitor trip details

1. In Menu mode, select **Tools** → **Location** → **GPS data** → **Trip distance**.
2. Select **Options** → **Start**.
Your device will track trip details, including distance, time, and speed.
3. To stop monitoring trip details, select **Options** → **Stop**.

Landmarks

With Landmarks, you can save your current location or manually enter new locations.

1. In Menu mode, select **Tools** → **Location** → **Landmarks**.
2. Select **Options** → **New landmark** → **Current position** or **Enter manually**.



To add your current location automatically, your device must have an active connection.

3. Enter details about the landmark (if necessary).
4. When you are finished entering landmark information, select **Done**.

Smart reader

Smart reader allows you to capture information from a business card and use it to create a new contact in Contacts.

You can also take a photo of a document and convert it to a editable note file.



This feature may be unavailable depending on your region or service provider.

To recognise a business card,

1. In Menu mode, select **Office** → **Smart reader**.
2. Position the device over the business card, so that the frame on the viewfinder aligns with the edges of the business card. See Tips for recognising business cards.
3. Press the Camera key.



As you align the frame in the viewfinder with the edges of the business card, they will change to green. If you can align all four edges of the frame at once, your device will automatically capture the image.


Your device recognises the business card and converts it to contact card format.

4. Select **Options** → **Edit & Save** to edit any contact details that were converted incorrectly.
5. When you are finished editing, select **Done** to save the contact card.

Tips for recognising business cards

- Hold the device steady while capturing a photo of the business card.
- Be careful not to allow any shadows to fall on the business card.
- Place the business card on level, evenly lit surface when capturing information from it.

To capture a document,

1. In Menu mode, select **Office** → **Smart reader**.
2. Select  to take the photo of the document.
3. Position the device over the document.
4. Press the Camera key.
Your device recognises the document and converts it to a note file.

5. Select **Options** → **Edit** to edit any text that were converted incorrectly and select **Done** (if necessary).
6. Select **Options** → **Save to notepad** to save the note.

Dictionary


With Dictionary, you can look up words. The dictionary is available depending on your region.

1. In Menu mode, select **Office** → **Dictionary**.
2. Enter a word.
3. Select a word.

Print OTG

With Print OTG, you can print your images, messages, contact information, and calendar items with the Bluetooth wireless feature or a USB connection.

To print items using the Bluetooth wireless feature,


1. In Menu mode, select **Tools** → **Print OTG**.
2. Select an item type → an item to print.
3. Select  → **Via Bluetooth**.
4. Select **Yes** to turn on the Bluetooth wireless feature (if necessary).
5. Select a Bluetooth-enabled printer and pair with the printer. ► p. 35

To print items using a USB connection,

1. Connect the multifunction jack on your phone to a compatible printer.
2. In Menu mode, select **Tools** → **Print OTG**.
3. Select an item type → an item to print.
4. Select  → **Via USB**.
5. Set print options and print the image.

Compass

1. In Menu mode, select **Tools** → **Compass**.
2. Calibrate the compass by rotating the device around all axes.



The outline colour represents calibration status:

- Red: the compass is not calibrated.
- Yellow: the calibration accuracy is low.
- Green: the compass is calibrated.

- When the outline colour becomes green, hold the device flat in your palm, parallel to the ground and read the direction.



Remove any metal jewellery and avoid coming too close to metal objects or places that affect the compass magnet. This may affect the accuracy of the compass or the calibration.

Qik

Qik allows you to easily broadcast live videos over the internet. You can share your live video with others or store the video so your friends and family can view it later.



This feature may be unavailable depending on your region or service provider.



- In Menu mode, select **Applications** → **Qik**.
- Select **OK**.
- Enter user information and select **Join**.

- Select an access point (if necessary).
- Select **Stream**.

Your video will stream live via the Qik website. To see the live video, visit your personalised webpage: <http://qik.com/username>.

While streaming, you can control the streaming video with the following controls (tap the viewfinder to display or hide the controls):

Icon	Description
	Turn the audio on or off
	Share location information
	Make the stream private (accessibly only by logging in to the Qik website) or public (accessible to anyone)
	Set a title for the video
	Change settings
	Change the quality

Icon	Description
	Turn on or off the flash
	Select a connection profile

6. Select **Stop** to save the streaming video.
7. Enter a title for the video and select **OK**.
The video will be uploaded to your personalised webpage.

Podcasts

Use the podcasts application to search for, download, and listen to podcasts.



This feature may be unavailable depending on your region or service provider.

Search for and subscribe to podcasts

1. In Menu mode, select **Applications** → **Podcasts** → **Search**.

2. Enter a keyword and select **OK**.
Your device searches for related podcasts and displays the results.
3. Select the podcast you want to subscribe to and select **Options** → **Subscribe**.

Play downloaded episodes

1. In Menu mode, select **Applications** → **Podcasts** → **Podcasts**.
2. Select an episode.
3. Select **Options** → **Play**.

Update your podcast library

Once you have subscribed to podcasts, you can easily update your library to listen to the latest episodes. To update your podcast library,

1. In Menu mode, select **Applications** → **Podcasts** → **Directories**.
2. Select **Options** → **Update**.

Samsung LBS

Samsung LBS provides you with various GPS-based applications.






Available applications may vary depending on your region or service provider.

You can enhance the GPS operation by downloading GPS data files. You can improve the speed and accuracy of positioning capability and expand your navigation to areas where cellular networks are not accessible. To download GPS data files,

1. In Menu mode, select **Samsung LBS** → **GPS+** → **Download data**.
2. Select **Yes** to connect to a server and download GPS data files.


You will be additionally charged for accessing the web and downloading data.

Smart search

1. In Menu mode, select **Applications** → **Smart search**.
2. Select , , or .



The search categories may vary depending on your SIM card.

3. Select the search input field.
4. Enter part of a file or folder name and select .
5. Restrict your search by selecting a data type from the drop-down list or select a searching engine from the drop-down list (if necessary).
6. Select **Options** → **Search**.
7. To open an item in the results list, select the item's name.

Mobile social networking services

Your device supports mobile social networking services that allow you to share place information about restaurants and other businesses with others and locate places via GPS.

Upload place information

1. In Menu mode, select **Samsung LBS** → **PlaceMe**.
2. Enter your place information.
3. To add image, video, or sound files, select **Options** → **Insert new** or **Insert media**.
4. When you are finished, select **Options** → **Send**.
5. Select **Yes** to connect to the web service.

Find a friend's current location

1. In Menu mode, select **Samsung LBS** → **SpaceMe**.
2. Select **Options** → **Refresh** to update the friend list.
3. Select **Yes** to connect to the web service.
4. Select a friend.

Search for a place

1. In Menu mode, select **Samsung LBS** → **ExploreMe**.
2. Enter information about a place to search.
3. Select **Options** → **Explore**.
4. Select **Yes** to connect to the web service.

managers

Learn to manage files, applications, zip archives,
and connections.

File manager

With File manager, you can search for and organise your files or folders. You can also back up and restore data, protect a memory card with a password, or view memory details.

Search for a file or folder

1. In Menu mode, select **Office** → **File mgr.**
2. Select **Options** → **Find**.
3. Select a memory type.
4. Select a desired folder.
5. Enter text in the search field and select **Find**.
6. To open a file or folder from the search results, select the file or folder.

Create a new folder

1. In Menu mode, select **Office** → **File mgr.** → a memory type.
2. Select **Options** → **Organise** → **New folder**.
3. Enter a folder name and select **OK**.

Move or copy a file to a folder

1. In Menu mode, select **Office** → **File mgr.** → a memory type.
2. Scroll to a file and select **Options** → **Organise** → **Move to folder** or **Copy to folder**.
3. Select a memory to save the file.
4. Select a folder.
5. If the folder has subfolders, select **Open** and select a subfolder (if necessary).
6. Select **Move** or **Copy**.

Back up data to a memory card

1. Insert a memory card (see the quick start guide).
2. In Menu mode, select **Office** → **File mgr.** → **Backup** → **Backup contents**.
3. Select the items you want to back up and select **OK**.
4. Select **Options** → **Back up now**.
5. Select **Yes**.

To restore data from a memory card, select **Options** → **Restore** → a backup file → **OK** → **Yes**.

Format a memory card



Your device supports FAT16 or FAT32 file systems.

1. Insert a memory card (see the quick start guide).
2. In Menu mode, select **Office** → **File mgr.**

3. Select the inserted memory card.



The name for the memory card may vary depending on the memory card type. To change the name, select the inserted memory card and select **Options** → **Memory card options** → **Rename**.

4. Select **Options** → **Memory card options** → **Format**.

5. Select **Yes** to confirm.

Protect a memory card with a password



Devices that do not support this feature, such as PCs, cannot read the memory card while the password protection is active. Remove the password protection from the memory card to use it with those devices.

1. In Menu mode, select **Office** → **File mgr.** → the inserted memory card.
2. Select **Options** → **Memory card password** → **Set**.
3. Enter and confirm a password (up to 8 characters).
4. Select **OK**.

To remove the password, select **Options** → **Memory card password** → **Remove**.

View memory details

You can view the used and available memory on your device and memory card,

1. In Menu mode, select **Office** → **File mgr.** → a memory type.
2. Select **Options** → **Details** → **File, Folder, Memory card, or Memory**.

Application manager

Your device supports applications made for the Symbian OS and the Java platform, Micro Edition (J2ME™). Your device will not support applications made for other operating systems or Java platforms (including PersonalJava™). To download applications to your device, see "Download files from the web." ► p. 31

Install a new application

1. In Menu mode, select **Settings** → **Application mgr.** → **Installation files**.
2. Scroll to an application and select **Options** → **Install**.

3. Follow any on-screen instructions.



The application manager automatically tries to verify an application's digital signatures and certificates during installation and will show a warning if the application does not meet normal security requirements. To protect your device and your data, do not install applications that do not have valid digital signatures or certificates.

Remove an application

1. In Menu mode, select **Settings** → **Application mgr.** → **Installed apps**.
2. Scroll to an application and select **Options** → **Uninstall**.
3. Select **Yes** to confirm.

Zip

You can create and manage zip archives saved in your phone's memory or the memory card.

Create a new archive

1. In Menu mode, select **Office** → **Zip**.
2. Select **Options** → **New archive**.
3. Enter a name for the archive and select **OK**.
4. Select **Options** → **Add to archive**.
5. Select files to archive.



Extract a file to another folder

1. In Menu mode, select **Office** → **Zip**.
2. Select an archive.
3. Scroll to a file and select **Options** → **Extract** → a memory location.
4. Select a folder to extract the file.

Connection manager

With Connection manager, you can view the details of data connections and close open connections.

View connection details

1. In Menu mode, select **Settings** → **Connectivity** → **Connection mgr.**
2. Scroll to a connection.
 - : packet data connections
 - : WLAN connections
3. Select **Options** → **Details**.

Close an open connection

1. In Menu mode, select **Settings** → **Connectivity** → **Connection mgr.**
2. Scroll to a connection and select **Options** → **Disconnect**.
3. Select **Yes** to confirm.

settings

Learn about your device settings. To access your device settings,

1. In Menu mode, select **Settings**.
2. Select a category (**Personal**, **Phone**, **Applications mgr.**, **Calling**, or **Connectivity**).



You can also access some settings from other menus: select **Options** → **Settings**.

Personal settings

Widgets

- **Widgets:** Select widgets you want to include on the toolbar.
- **Packages:** Check widgets included in a package.

Profiles

Customise and select a profile that controls ringtone, key tones, and alerts.

Themes

Select a theme for the display, such as menu layout and wallpaper.

Home screen

Control the appearance of Standby mode.

Phone settings

Date and time

Control the appearance and behavior of the date, time, and alarms.

Language

Select a display language for all menus and applications, and a writing language for all text editors.

Display

Control the appearance and behavior of the display.

Sensor settings

Set to activate motion-related features.

Touch input

Customise the touch screen for entering text or calibrate the screen so that your phone recognises the input better.

Accessories

Set the device to use the headset, headphone, car kit, or another device as the default enhancement: select **Options** → **Set as default**.

Applications settings

Messaging

Set message settings.

RealPlayer

Control how RealPlayer behaves when playing videos or streaming media.

Camera

Control how the camera behaves when you capture images or videos.

Log

Set how long Log will store call and packet data information.

Positioning

Control the methods and servers your device uses to retrieve global positioning information.

Voice recorder

Control the quality and memory location of voice clips.

Calendar

Change calendar options

Phone management

Auto. keyguard

Set to lock the screen automatically when the display backlight turns off.

Security

Set security codes and manage security certificates or security modules.

Factory settings

Reset settings to their factory defaults. You must enter the lock code to reset the device. After entering the code, the device will restart.

Device manager

Check the current software and install a software update package.

About

View the copyright information.

Application manager

Installed apps.

Check the installed applications.

Installation files

Check applications you can install.

Installation sett.

Set installation options.

Calling settings

Call

Control how your device handles calls with call waiting and other call settings.

Speed dialling

Assign speed dial numbers.

Call mailbox

Change the voice mail number.

Call divert

Divert incoming calls to another number. When you divert calls, you must specify a receiving number or delay time for diverted calls.

Call barring

Restrict outgoing, incoming, and international calls.

Connectivity settings

Network

Control network modes and selection methods.

Wireless LAN

Control the use of wireless LAN availability.

Bluetooth

Control the Bluetooth wireless feature.

USB

Control how your device behaves when you connect it to a PC.

Destinations

Control access point connections, passwords, and homepages.

Connection mgr.

View the details of data connections and close open connections.

Data transfer

Select the data on your device you want to synchronise with data on a PC or other wireless device.



This feature may be unavailable depending on your region or service provider.

Remote drives

Set settings for a remote drive.

Video sharing

Control the use of the video sharing service.

Admin. settings

Packet data

Control packet data connections when using a GPRS network.

Presence

Control the Presence server settings for using IM.

SIP settings

Control how your device handles internet calls and multimedia services.

XDM profile

Set settings for an XDM server.

APN control

Control the use of packet data connections, if your SIM card supports the access point control service.



troubleshooting

While using your device, the following messages may appear:

Message	Try this to solve the problem:
Insert SIM card	Ensure that the SIM or USIM card is installed correctly.
Locked	<p>The autolock feature is enabled. To use the device, you must press the Hold key and enter the code. To disable the autolock feature,</p> <ol style="list-style-type: none">1. In Menu mode, select Settings → Phone → Phone mgmt. → Security → Phone and SIM card → Phone autolock period.2. Set the phone autolock to None.

Message	Try this to solve the problem:
X attempts remaining. Enter PIN code:	<p>When using the device for the first time or when the PIN requirement feature is enabled, you must enter the PIN supplied with the SIM or USIM card. To disable the PIN requirement feature,</p> <ol style="list-style-type: none">1. In Menu mode, select Settings → Phone → Phone mgmt. → Security → Phone and SIM card → PIN code request.2. Set the PIN code request to Off.

Message	Try this to solve the problem:
X attempts remaining. Enter PUK code:	Your SIM or USIM card is blocked, usually as a result of entering your PIN incorrectly several times. You must enter the PUK supplied by your service provider.

Your device does not show a signal (no bars next to the network icon)

- If you just turned on the device, wait about 2 minutes for your device to find the network and receive a signal.
- You may not be able to receive a signal in tunnels or elevators. Move to an open area.
- You may be between service areas. You should receive a signal when you enter a service area.


You forgot a security code, PIN, or PUK

The default lock code is **00000000**. If you forget or lose this or another code, contact the seller or your service provider.

Your display shows white lines

The display may show white lines if you have turned the device on after a long period of disuse or if you removed the battery without first turning off the device. The display should correct itself in a short time.

You enter a number, but the call is not dialed

- Ensure that you have pressed [].
- Ensure that you have accessed the right cellular network.
- Ensure that you have not set call barring for the phone number.

You select a contact to call, but the call is not dialled

- Ensure that the correct number is stored in the contact information.
- Re-enter and save the number, if necessary.

Another caller cannot hear you speaking

- Ensure that you are not blocking the built-in microphone.
- Move the built-in microphone closer to your mouth.
- If using a headset, ensure that it is properly connected.

The sound quality of a call is poor

- Ensure that you are not blocking the internal antenna on bottom of the device.
- When you are in areas with weak signals, you may lose reception. Move to another area and try again.

The battery does not charge properly or sometimes your device turns itself off while charging

- Disconnect the device from the charger, remove and reinstall the battery, and try charging again.
- The battery terminals may be dirty. Wipe both gold-coloured contacts with a clean, soft cloth and try charging the battery again.
- If the battery no longer charges completely, dispose of the old battery properly and replace it with a new battery.


Your device is hot to the touch

When you use several applications at once, your device requires more power and may heat up. This is normal and should not affect your device's lifespan or performance.

Your device prompts you to delete some data

The available memory is low. Move your data to a memory card or delete old items from applications.

An application is frozen (will not respond)

1. Press and hold the Menu key to open the application list.
2. Scroll to the application that is frozen and select .
3. Launch the application again.



Depending on your region or service provider, closing active applications in the background may not be possible.

You cannot find a Bluetooth-enabled device

- Ensure that both devices have activated the Bluetooth wireless feature.
- Ensure that the distance between the devices is not more than 10 metres and that they are not separated by walls or other obstacles.
- Ensure that each device's visibility is not set to **Off**.
- Ensure that both devices are compatible with Bluetooth wireless technology.

index

[access points](#), 33, 62

[Adobe Reader](#), 26

[applications](#)

- installing, 56
- supported, 56
- verifying certificates, 56

[Bluetooth](#)

- activating, 35
- connecting to other devices, 35
- receiving data, 36
- remote SIM mode, 37
- sending data, 36

[calendar](#)

- changing views, 24
- creating events, 25
- stopping event alarms, 25

[calls barring](#), 61

[calls diverting](#), 61

[clock](#)

- changing settings, 42
- creating world clock, 43
- setting alarms, 42
- stopping alarms, 43

[Communities](#), 17

[Connected home](#), 39

[contacts](#)

- assigning default numbers or addresses, 23
- assigning ringtones, 23
- assigning speed dial numbers, 23
- creating contact groups, 24
- synchronising, 24

[converter](#)

- adding currencies, 43
- converting currencies, 44
- converting measurements, 44
- setting exchange rates, 43

date and time, 59

dictionary, 47

enhancement, 59

files and folders

- creating new folders, 54
- file manager, 53
- moving, 54
- searching, 53

FM radio

- listening to, 18
- storing stations, 18

gallery, *see media* 16

GPS

- activating positioning methods, 45

- monitoring trip details, 45
- navigating, 45

images

- editing, 17
- viewing, 17

internet, *see web browser*

landmarks, 46

media

- accessing streaming content, 19
- opening files in Gallery, 16
- playing media files, 16, 19
- playing voice clips, 20
- recording voice clips, 20

Media Browser, 17

memory cards

- backing up data, 54
- formatting, 54
- protecting, 55

mobile social networking services, 52

notes

- creating notes, 26
- synchronising, 27

packet data, 14

PC Studio

- installing, 21
- setting USB mode, 37
- using, 38

PDF, *see Adobe Reader*

podcast

- downloading, 50
- searching and subscribing, 50
- updating, 50

Qik, 49

Quickoffice

- opening documents, 25
- updating quickoffice, 26

radio, see FM radio

RealPlayer, see media

recorder, see media

RoadSync, 40

security, 60

smart reader, 46

web browser

- adding bookmarks, 30
- changing options, 29
- downloading contents, 31

wireless LAN (WLAN), 34

Zip, 57

Declaration of Conformity (R&TTE)

We, **Samsung Electronics**

declare under our sole responsibility that the product

GSM Mobile Phone : I8910

to which this declaration relates, is in conformity with the following standards and/or other normative documents.

SAFETY	EN 60950- 1 : 2001 +A11:2004
SAR	EN 50360 : 2001 EN 62209-1 : 2006
EMC	EN 301 489- 01 V1.6.1 (09-2005) EN 301 489- 01 V1.8.1 (04-2008) EN 301 489- 07 V1.3.1 (11-2005) EN 301 489- 17 V1.2.1 (08-2002) EN 301 489- 17 V1.3.2 (04-2008) EN 301 489- 19 V1.2.1 (11-2002) EN 301 489- 24 V1.4.1 (09-2007)
RADIO	EN 301 511 V9.0.2 (03-2003) EN 300 328 V1.7.1 (10-2006) EN 301 908- 1 V3.2.1 (05-2007) EN 301 908- 2 V3.2.1 (05-2007)

We hereby declare that [all essential radio test suites have been carried out and that] the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex[IV] of Directive 1999/5/EC has been followed with the involvement of the following Notified Body(ies):

BABT, Forsyth House, Churchfield Road,
Walton-on-Thames,

Surrey, KT12 2TD, UK*
Identification mark: 0168




The technical documentation kept at :

Samsung Electronics QA Lab.

which will be made available upon request.
(Representative in the EU)

Samsung Electronics Euro QA Lab.
Blackbushe Business Park, Saxony Way,
Yateley, Hampshire, GU46 6GG, UK*



2009. 11. 12

Yong-Sang Park / S. Manager

(place and date of issue)

(name and signature of authorised person)

* It is not the address of Samsung Service Centre. For the address or the phone number of Samsung Service Centre, see the warranty card or contact the retailer where you purchased your phone.

Some of the contents in this manual may differ from your device depending on the software of the device or your service provider.

SAMSUNG ELECTRONICS



World Wide Web
<http://www.samsungmobile.com>

English (EU). 12/2009. Rev. 1.1